

Mazda

Rotary Pickup
WORKSHOP MANUAL

Mazda

Rotary Pickup

WORKSHOP MANUAL

FOREWORD

This workshop manual was prepared as reference material of the service personnel of authorized Mazda dealers to enable them to correctly carry out the task of rendering services and maintenance on Mazda vehicles.

In order to ensure that the customers are satisfied with Mazda products, proper servicing and maintenance must be provided. For this purpose, the service personnel must fully same time, are recommended to keep the manual in a place where reference can readily be made.

The information, photographs, drawings and specifications entered in this manual were the best available at the time of printing this manual. All alterations to this manual occurring as the result of modifications will be notified by the issuance of Service Informations or supplementary volumes. It is, therefore, requested that the manual be kept up to date by carefully maintaining a follow-up of these materials.

Toyo Kogyo reserves the right to alter the specifications and contents of this manual without any obligation and advance notice.

All rights reserved. No part of this book may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying, recording, or by any informational storage and retrieval system, without permission in writing.

SECTION INDEX	
Name	Section
Pre-Delivery Sequence Guides and Maintenance Schedule	0
Engine	1
Emission Control System	1A
Lubricating System	2
Cooling System	3
Fuel System	4
Electrical System (Engine)	5
Clutch	6
Transmission	7
Automatic Transmission	7B
Propeller Shaft	8
Rear Axle	9
Steering	10
Brakes	11
Wheels and Tires	12
Suspension	13
Body	14
Electrical System (Body)	15
Technical Data	T

0-A. PRE-DELIVERY SERVICE GUIDE

Perform the following operation, (checks, alignment, replenishments, adjustments, corrections, etc.) during the pre-delivery inspection.

1. Under Hood – Engine Off

	Page		Page
Engine oil level	0 : 2	Battery fluid level and state of charge	0 : 2
Steering gear housing oil level	0 : 2	Check battery cables for tightness	0 : 2
Brake & clutch master cylinder fluid level	0 : 2	Drive belt tension	0 : 2
Windshield washer reservoir fluid level	0 : 2	Fuel level	0 : 2
Sub-zero starting assist fluid	0 : 2	Carburetor linkage, choke control and wide open throttle position	0 : 2
Radiator coolant level and specific gravity	0 : 2	Clean and check spark plug	0 : 2

2. Under Hood – Engine Operating and Hot

Check distributor dwell	0 : 3	Fuel, vacuum, coolant and hydraulic lines, fittings connections and components for leaks	0 : 3
Check initial ignition timing	0 : 3	Automatic transmission fluid level	0 : 3
Alternator and regulator – operation	–	Exhaust emission air pump – operation	0 : 3
Carburetor idle mixture and speed adjustments	0 : 3	Exhaust emission idle switch – operation	–

3. On Outside

Latches, keys and locks – operation	0 : 4	Weatherstrips – adhesion and fit	0 : 4
Bonnet, door panels and tail gate for fit, alignment and operation	0 : 4	Wheel nut torque	0 : 4
Bumpers – alignment	0 : 4	Wheel caps – install	0 : 4
		Headlight alignment – adjust if necessary	0 : 4

4. On Inside

Brake & clutch pedal free play	0 : 4	Seat and shoulder belt	0 : 4
Operation of all lights	0 : 4	Inside locks and door latch releases – operation	–
Check upholstery and internal finish	–	Windows and vents – operation and fit	0 : 4
Manual seat control – operation	0 : 4	Cigar lighter – install and test	–

5. On Hoist

Transmission oil level	0 : 4	Tire pressures and inspect tires	0 : 4
Rear axle oil level	0 : 4	Steering linkage and connections	0 : 4
Fuel, coolant and hydraulic lines, fittings, connections and components on underside for leaks	–		

6. Road Test

Ignition switch – operation	–	Automatic transmission shift points and kick down	0 : 5
Neutral switch – operation	0 : 5	Accelerator pedal – operation	0 : 5
Parking brake – operation	0 : 5	Engine performance	0 : 5
Horn, windshield wipers and washers – operation	0 : 5	Steering control	0 : 5
Heater and defroster – operation	0 : 5	Check for noise, squeaks and rattles	0 : 5
Radio and antenna – operation and set push buttons	0 : 5	Speedometer, odometer, fuel and temperature gauges and ammeter – operation	0 : 5
Brake operation	0 : 5	General performance and handling characteristics	0 : 5
Clutch operation	–		
Transmission shift lever – operation	0 : 5		

7. After Road Test

Remove seat protectors, windshield markings and tapes	0 : 5	Check soft trim for soilage and excess sealer	0 : 5
Wash car and check for leaks	0 : 5	Check tool kit, jack and owner's handbook, service coupons and manufacture's warranty booklet	0 : 5
Glass condition	0 : 5		
Inspect for exterior and interior metal and paint damage	0 : 5		

O-B. PRE-DELIVERY SERVICE

O-B-1. Under Hood-Engine Off

a. Engine oil level

Check the oil level dipstick to be sure it indicates the correct quantity of oil in the oil pan (above the L mark). On pre-delivery fill the oil until "F" mark. Be sure the oil is clean. Use only oil meeting specifications.

b. Steering gear oil

The check the oil level, remove the filler plug on the top of the steering gear box and add lubricant meeting specifications if necessary.

c. Brake and clutch fluid level

The fluid level should be kept at least 2/3 full in the reservoir. After checking, the reservoir cap should be neatly cleaned and reinstalled.

Use only brake fluid meeting specifications.

d. Windshield washer fluid level

Fill with water and solvent meeting specifications. Plain water can be used, but a good grade of windshield washer solvent will help it clean better and prevent freezing in cold weather. Do not use radiator anti-freeze as this will cause paint damage.

e. Sub-zero starting assist fluid

The fluid reservoir is installed to the right-hand side of the engine compartment. Check the fluid level and add a 90/10 mixture of high-quality ethylene glycol anti-freeze and water if necessary.

f. Radiator coolant

The coolant should be filled full in the radiator and 1/3 full in the expansion tank. Use recommended mixture of Long Life Coolant (Part No. 0844 77 264) and water to keep the freeze protection at an adequate level for the temperatures which may occur in the area in which the car will be operated. Refer to Par. 3-C and check the specific gravity.

Note:

Avoid injury when checking a hot engine. If the cap must be removed when the engine is hot, let the engine cool down by idling for a few moments before removing the cap. Place a rag or towel wrapped over the cap and turn it slowly counterclockwise and remove.

g. Battery fluid level and state of charge

Remove the caps on top of the battery and check that the level is 10 ~ 20 mm (0.4 ~ 0.8 in) in above the plates. Ordinary tap water can be used except in areas where the water is known to be hard or to have a high mineral or alkali content - use distilled water in these areas. Be careful not to overfill the battery.

Note: Keep fire away from the top of open battery cells. Combustible gas is always present and could explode. Battery fluid is a corrosive acid. Do not

let it touch skin, clothing or painted surfaces. With battery temperature at 20°C (68°F), the battery should have a specific gravity reading of not less than 1.260 (1.280 for cold district). If the reading is below 1.20 (1.22 for cold district), the battery requires recharging.

h. Battery cable

Check the tightness of the terminals to ensure good electrical connections. Clean the terminals and coat the terminals with grease to retard corrosion and oxidation.

i. Drive belt tension

The drive belts should be checked for tension and wear. If the belt appears badly worn, cracked or frayed, it should be changed with a new belt. To check the belt tension, depress the belt halfway with your thumb (approximately 22 lbs) and check the deflection.

	New belt	Used belt
Alternator drive belt	13 mm (0.51 in)	15 mm (0.59 in)
Air pump drive belt	8 mm (0.31 in)	10 mm (0.39 in)

To adjust the alternator drive belt:

Loosen the alternator mounting bolt and adjusting bar bolt on the alternator strap. Move the alternator away from the engine or toward the engine until the tension of belt is sufficient. Tighten the bolts.

To adjust the air pump drive belt:

Loosen the air pump mounting bolt and adjusting bar bolt. Move the air pump on its mounting bracket until the proper deflection is obtained. Tighten the bolts.

j. Fuel level

Refer to Par. 4-A and check the float level, and adjust if necessary.

k. Carburetor linkage

Inspect the throttle linkage for proper installation. Remove the air cleaner, and with the accelerator full depressed, observe the position of the carburetor throttle valve. They should be vertical (wide open position). Check accelerator for sticking or binding and for full return and sufficient height to fully open throttle. Examine the choke control for free operation. Operate the choke valve manually to make sure that it moves freely.

l. Spark plug

Refer to Par. 5-E and check the spark plug.

O-B-2. Under Hood-Engine Operating and Hot

a. Distributor dwell angle

Refer to Par. 5-C and check the dwell angle, and adjust if necessary.

b. Initial ignition timing

Refer to Par. 5-C and check the ignition timing, and adjust if necessary.

c. Engine idling speed

Refer to Par. 4-A and check the engine idling speed, and adjust if necessary.

d. Cooling system hoses and lines

Inspect the cooling system hoses for evident of cracking, checking or extreme weathering. Replace cracked hoses. Check for leaking or porous hoses and tighten or replace. Make sure all supporting brackets for hoses are in place and that the hoses are properly installed in the brackets. Inspect the radiator core and tanks for seepage or leaks. Check all fittings to see that they are tight and in good condition. Examine the hoses at the fittings for cuts or weakness. Replace the hose in questionable condition.

e. Fuel lines and filter

With the engine off, examine the fuel line connections for wetness or washed or stained areas that might indicate a fuel leak. Start the engine and observe all the connections for fuel seepage. Tighten or replace fuel lines as necessary.

f. Automatic transmission fluid level

Make sure that the vehicle is standing level. Then firmly apply the parking brake.

1. Run the engine approximately two minutes at 1,200 rpm. Do not stop engine. Run at slow idle during fluid check.
2. Shift the selector lever through all positions, and place the lever at P. Apply service brake as an extra pre-caution while running selector lever.
3. Clean all dirt from the transmission fluid dipstick cap before removing the dipstick from the filler tube.
4. Pull the dipstick out of the tube, wipe it clean, and push it all the way back into the tube. Be sure it is properly seated.
5. Pull the dipstick out of the tube again, and check the fluid level. Fluid level should be above the "L" mark. If necessary, add enough fluid to the transmission through the filler tube to bring the fluid level between the "L" and "F" marks on the dipstick. Use only fluid meeting specifications. Do not overfill the transmission. Install the dipstick, making sure it is free seated in the tube.

h. Exhaust emission air pump

Check the air pump as follows. (Refer to Group 1A)

1. Disconnect the air pump outlet hose from the air control valve.
2. Connect the T-fitting (49 2113 011) with the plug (49 2113 012) and pressure gauge (49 2113 014).
3. Be sure that the choke knob is pulled all the way in, and then start the engine and run it at specified idling speed.
4. Check the pressure reading. If the reading is less than the following, replace the pump.

	engine speed	air pressure
Manual transmission	900 rpm	0.048 kg/cm ² (0.68 lb/in ²)
Automatic transmission	750 rpm in "D" range	0.034 kg/cm ² (0.48 lb/in ²)

0-B-3. On Outside**a. Latches, keys and locks**

Check for ease of operation of locks, latches and keys on doors, glove compartment, tailgate and bonnet. Adjust, correct and lubricate meeting specifications.

b. Bonnet, door panels and tail gate

Check fit and alignment. Adjust as required.

c. Bumper

Check condition, fit and alignment. Adjust as required.

d. Weatherstrip

Check fit and retention and correct as required.

e. Wheel nut torque

Wheel nuts should be inspected and tightened to specifications at pre-delivery. Loose wheel nuts may cause shimmy and vibration.

f. Wheel caps

Check for correct type of cap and install. Caution should be exercised when installing not to damage cap. Use rubber mallet on outer perimeter.

g. Headlight aiming

Check and adjust the headlight aiming according to the traffic regulation of each country.

0-B-4. On Inside**a. Brake and clutch pedal free play**

Refer to Par. 6-A and 11-A and check, and adjust if necessary.

b. Operation of all light

Check for proper operation of switches and brightness of lights, including operation of oil pressure, alternator warning lights and high beam indicator light. Check detent action and return of turn signal lever by making full left and right turns during road test. Check operation of emergency flasher system.

c. Manual seat control

Check lever for ease of operation. Test freeness of seat movement on track and for solid engagement on both sides with lever released.

d. Seat and shoulder belt

Check belt anchors for secure fit. Check buckle and clasp for proper retention, release, and length adjustment.

e. Windows and vents

Check for ease of operation.

0-B-5. On Hoist**a. Transmission oil level**

1. Clean dirt and grease from the area around the filler plug, and remove the filler plug.
2. The oil level should be maintained at the bottom of the filler plug. If additional oil is required, use only the specified type.

b. Rear axle oil level

1. Clean dirt and grease from the area around the filler plug, and remove the filler plug.
2. The oil level should be maintained at the bottom of the filler plug. If additional oil is required, use only the specified type.

c. Tires and air pressure

Inspect the tire treads, and remove all stones, nails, glass, or other objects that may be wedged in the tread. Check for holes or cuts that may permit air leakage from the tire, and make the necessary repairs. Inspect the tire side walls for cuts, bruises, and other damage. If internal damage is suspected, remove the tire from the wheel for further inspection and repair or replacement. Check the tire valve for air leaks, and replace the valve if necessary. Replace any missing valve caps. The tires should be checked frequently to be sure that the air pressures agree with those specified for the tires and vehicle model.

d. Steering linkage and connections

Check for looseness at the tie-rod ends. Looseness can affect the toe-in readings and adjustment. Check the front suspension ball joints and mountings for looseness. Check the brake caliper attaching bolts. Torque all loose nuts and bolts to specifications. Be sure all cotter pins are correctly installed. Check the steering gear mountings and all steering linkage connections for looseness. Torque all loose mountings to specifications.

0-B-6. Road Test**a. Neutral start switch operation
(Automatic transmission)**

Check ability to start engine with selector lever in both Neutral and Park position only. Adjust Neutral switch if necessary.

b. Parking brake operation

Check the operation of the parking brake. With the vehicle on a hoist and the parking brake fully released, the cable should not have any slack. Also, the rear brakes should not drag when the wheels are turned. If either of the above conditions exist, adjust as required.

c. Horn operation

Check pad-blow horn to be sure horn blow at all pad contact positions.

d. Wiper and washer operation

Check for proper operation, including wiper sweep and park. Adjust if required. Check washer operation and adjust nozzles as required.

e. Heater and defroster operation

Check the following items: leaks, sufficient heat, blower operation, temperature control operation and operation of defroster. Adjust and correct as necessary.

f. Radio and antenna operation

Check type and location specified, and install using installation instructions and template supplied with antenna kit. Do not break plastic adapter when tightening nut. Adjust the antenna trimmer. Set push buttons as follows.

Pull out the push button to be set to unlock the push button mechanism. Tune in the desired station with the manual tuning knob. After the station is clearly tuned in, push the button straight in until it stops, then release it. Repeat this procedure for the remaining buttons. Check for objectionable noise.

g. Brake operation

Depress foot brake pedal to assure good pedal height before road testing. Check and correct, if required, the following conditions: pull in either direction, harshness or noise, excess pedal effort, or spongy feel and operation of the brake warning light.

Avoid sudden hard stops — make slow, gradual stops.

h. Transmission shift lever operation

Check and adjust, if necessary, for smooth crossover action.

i. Automatic transmission shift operation

Check to see that the upshifts and downshifts occur within the specified range, following the Par. 7B-C.

j. Steering control

Check steering wheel return from both directions. Test for steering effort required and inconsistent effort in different directions. If the steering is exceptionally stiff, check the steering effort with a scale on the rim of the steering wheel and with pitman arm disconnected. The effort required to rotate the steering wheel should not exceed the specifications. Check for harshness, noise wander or free play.

k. Running condition

Check speedometer, odometer, fuel and temperature gauges, all warning and convenience lights, and all special optional equipment for proper operation. Test windshield washers and wipers. Operate all heater, defroster and ventilating controls. After road test, repair or adjust all malfunctions noted during road test.

0-B-7. After Road Test

Perform the following:

Remove seat protectors, windshield markings and tapes. Wash the vehicle. Inspect the interior and exterior metal damage. Check for soft trim soilage and excess sealer. Inspect the interior bright metal trim for alignment and retention. If necessary, locate and secure loose screws or clips. Verify information on owner-card in glove compartment with warranty booklet. Be sure Owner's Handbook and Warranty Booklet

are in glove box. These final operations are among the most vitally important procedures in pre-delivery service. All of them affect the appearance of the vehicle, which of course, is the first thing that will come to the customer's attention. The through checks and test you have given the vehicle in the stalls and on the road, and the careful adjustments you have made will be wasted if the vehicle is not delivered to the new owner in a spatlessly shining condition. This is the final evidence that every step has been taken to deliver a quality product in perfect conditions.

0-C. SCHEDULED MAINTENANCE SERVICES GUIDE

0-C-1. Emission Control Systems Required Maintenance Services

Maintenance Operations	Service Intervals Reference Group	Number of months or thousands of miles whichever comes first												
		2	6	10	14	18	22	26	30	34	38	42	46	50
1. Engine														
Engine oil	0	R	R	R	R	R	R	R	R	R	R	R	R	R
Engine oil filter	2		R		R		R		R		R		R	
Drive belts including air pump drive belt	1	I	I	I	I	I	I	I	I	I	I	I	I	I
Metering oil	2	I	I	I	I	I	I	I	I	I	I	I	I	I
Compression pressure	0			I			I			I			I	
Starting assist system	4	Sub-zero weather use only. Inspect seasonally.												
2. Fuel and Evaporative Emission Control Systems														
Idle speed	4	I	I	I	I	I	I	I	I	I	I	I	I	I
Idle mixture	4	I			I				I				I	
Fuel filter	4			R			R			R			R	
Air cleaner element (*)	4	I	I	I	I	I	R	I	I	I	I	I	R	I
Carburetor float level	4	I			I			I			I			I
Carburetor linkage and choke mechanism	4			I			I			I			I	
Fuel line and connections	4	I	I	I	I	I	I	I	I	I	I	I	I	I
Canister	1A						I						I	
Evaporative emission control system, fuel tank and vapor lines	1A			I			I			I			I	
Check valve	1A						I						I	
3. Ignition System														
Ignition timing and advance system	5	I	I	I	I	I	I	I	I	I	I	I	I	I
Distributor breaker points	5	I	I	I	I	I	I	I	I	I	I	I	I	I
Distributor cap, rotor and condenser	5			I			I			I			I	

* Under dusty conditions clean the air cleaner element every 1,000 miles and replace it every 12,000 miles.

Maintenance Operations	Service Intervals Reference Group	Number of months or thousands of miles whichever comes first												
		2	6	10	14	18	22	26	30	34	38	42	46	50
Ignition coil	5			I			I			I			I	
Spark plugs	5	I	I	I	I	I	I	I	I	I	I	I	I	I
Spark plug wires	5			I			I			I			I	
Distributor cam	5			I			I			I			I	
4. Crankcase Emission Control System (Ventilation System)														
Ventilation valve	1A						I							I
Ventilation hoses	1A			I			I			I				I
5. Exhaust Emission Control System														
Air pump	1A			I			I			I				I
Air hoses and vacuum sensing tubes	1A			I			I			I				I
Idle switch	1A	I	I	I	I	I	I	I	I	I	I	I	I	I
Air control valve	1A			I			I			I				I
Check valve	1A			I			I			I				I
Control unit	1A	I		I			I			I				I
Deceleration control valve	1A			I			I			I				I
Thermosensor and thermodetector	1A			I			I			I				I
Thermal reactor	1A			I			I			I				I
Exhaust pipe flange bolts	1A			A			A			A				A
Choke switch, choke relay and carburetor heater	1A			I			I			I				I
Automatic throttle release system	1A			I			I			I				I
Water temperature switch	1A			I			I			I				I
Heat hazard warning system	1A			I			I			I				I
Downshift solenoid (automatic transmission)	1A			I			I			I				I
Altitude compensator	1A						I							I

Maintenance operations: I = Inspect, Correct – Replace if necessary
A = Adjust R = Replace or change

0-C-2. Normal Systems Required Maintenance Services


Maintenance Operations	Service Intervals Reference Group	Number of months or thousands of miles whichever comes first												
		2	6	10	14	18	22	26	30	34	38	42	46	50
1. Cooling System														
Cooling system hoses	3			I			I			I			I	
2. Electrical System														
Battery electrolyte level and specific gravity	5	I	I	I	I	I	I	I	I	I	I	I	I	I
Operation of all kind of lights and meters	0	I	I	I	I	I	I	I	I	I	I	I	I	I
3. Chassis and Body														
Clutch pedal	6	I	I	I	I	I	I	I	I	I	I	I	I	I
Clutch fluid	6	I	I	I	I	I	I	I	I	I	I	I	I	I
Manual transmission oil	7	R			R				R			R		R
Automatic transmission fluid	7B	I	I	I	I	I	I	I	I	I	I	I	I	I
Rear axle oil	9	R			R				R			R		R
Steering gear oil	0			I			I				I			I
Steering wheel play	10	I	I	I	I	I	I	I	I	I	I	I	I	I
Brake pedal	11	I	I	I	I	I	I	I	I	I	I	I	I	I
Brake fluid	11	I	I	I	I	I	I	I	I	I	I	I	I	I
Parking brake	11	I	I	I	I	I	I	I	I	I	I	I	I	I
Drum brake lining	11			I			I				I			I
Disk brake pad	11		I		I		I		I		I		I	
Hoses (automatic transmission)	7B	Replace every four years												
Piston cups of master cylinders and wheel cylinders	11	Replace every two years												
Brake hoses (vacuum hoses of power brake)	11	Replace every four years												
Front wheel bearings	12	Lubricate or replace every 30,000 miles or two years												
Front suspension ball joints and upper arm shafts	13													
Steering ball joints and idler arm	10													

Maintenance operations: I = Inspect, Correct - Replace if necessary
 A = Adjust R = Replace or change

ENGINE

LICENSE NSU-WANKEL

1-A. ENGINE DISASSEMBLY	1 : 4
1-B. INSPECTION AND REPAIR	1 : 8
1-B-1. Inspecting Front, Intermediate and Rear Housing	1 : 8
1-B-2. Regrinding Side Housings	1 : 9
1-B-3. Inspecting Front Stationary Gear and Main Bearing	1 : 9
1-B-4. Inspecting Rear Stationary Gear and Main Bearing	1 : 10
1-B-5. Inspecting Rotor Housing	1 : 10
1-B-6. Inspecting Rotor	1 : 11
1-B-7. Inspecting Rotor Bearing	1 : 12
1-B-8. Inspecting Seal Springs	1 : 12
1-B-9. Inspecting Rotor Oil Seal	1 : 13
1-B-10. Inspecting Apex Seal	1 : 13
1-B-11. Inspecting Side Seal	1 : 14
1-B-12. Inspecting Corner Seal	1 : 14
1-B-13. Inspecting Eccentric Shaft	1 : 15
1-B-14. Inspecting Needle Bearing	1 : 16
1-C. ENGINE ASSEMBLY	1 : 17
1-C-1. Installing Oil Seal	1 : 17
1-C-2. Installing Each Seal	1 : 17
1-C-3. Installing Front Rotor	1 : 18
1-C-4. Installing Eccentric Shaft	1 : 18
1-C-5. Installing Front Rotor Housing	1 : 18
1-C-6. Installing Intermediate Housing	1 : 19
1-C-7. Installing Rear Rotor and Rotor Housing	1 : 20
1-C-8. Installing Rear Housing	1 : 20
1-C-9. Tightening Tension Bolts	1 : 20
1-C-10. Installing Flywheel or Counter Weight	1 : 20
1-C-11. Adjusting Eccentric Shaft End Play ...	1 : 21
1-C-12. Installing Front Cover and Eccentric Shaft Pulley	1 : 22
1-C-13. Installing Oil Strainer and Oil Pan	1 : 22
1-C-14. Installing Water Pump	1 : 23
1-C-15. Installing Distributor	1 : 23
1-C-16. Installing Exhaust Manifold	1 : 24
1-C-17. Installing Intake Manifold	1 : 24
1-C-18. Installing Alternator and Air Pump ...	1 : 24
SPECIAL TOOLS	1 : 25



1. Cooling fan
2. Water pump body
3. Water pump pulley
4. Cooling fan drive
5. Eccentric shaft pulley
6. Eccentric shaft pulley
7. Key
8. Eccentric shaft pulley bolt
9. Eccentric shaft front oil seal
10. Eccentric shaft pulley boss
11. Oil thrower
12. Distributor drive gear
13. Front cover
14. Oil pump driven sprocket
15. Oil pump body
16. Thermostat cover
17. Thermostat
18. Water thermo switch (for air conditioner)
19. Water thermo switch (for choke control)
20. Front housing
21. Thrust washer
22. Needle bearing
23. Thrust plate
24. Spacer
25. Oil filter
26. Intermediate housing
27. Oil filter cover
28. Rear rotor housing
29. Rear housing
30. Apex seal
31. Rear rotor
32. Oil seal (outer)
33. Oil seal (inner)
34. Rear rotor bearing
35. Rear main bearing
36. Flywheel lock nut
37. Key
38. Needle bearing
39. Eccentric shaft
40. Eccentric shaft rear oil seal
41. Oil jet
42. Sealing washer
43. Tension bolt

Fig. 1-1 Engine cross section (1)




Fig. 1-2 Engine cross section (2)

- | | | |
|---------------------------|-------------------------|--------------------------|
| 1. Oil filler cap | 10. Side seal | 19. Intake manifold |
| 2. Distributor | 11. Rotor | 20. Air control valve |
| 3. Dipstick gauge | 12. Coolant drain plug | 21. Thermal reactor |
| 4. Rotor housing | 13. Air cleaner | 22. Apex seal |
| 5. Tubular dowel | 14. Alternator | 23. Corner seal |
| 6. Sealing rubber (outer) | 15. Carburetor | 24. Air injection nozzle |
| 7. Sealing rubber (inner) | 16. Hot air hose | 25. Oil strainer |
| 8. Trailing spark plug | 17. Water thermo sensor | 26. Oil drain plug |
| 9. Leading spark plug | 18. P.C.V. valve | |




Fig. 1-3 Engine cross section (3)

- 1. Thermostat
- 2. Water pump casing
- 3. Distributor drive gear
- 4. Eccentric shaft
- 5. Metering pump drive gear
- 6. Metering pump

- 7. Oil pump outer gear
- 8. Oil pump inner gear
- 9. Oil pump body
- 10. Oil strainer
- 11. Oil pan
- 12. Distributor

- 13. Distributor driven gear
- 14. Oil pump chain adjuster
- 15. Oil pump chain
- 16. Pressure control valve

1-A. ENGINE DISASSEMBLY

Engine disassembly should be done in the following order after removing the engine from the vehicle.

Note: When overhauling a rotary engine, the former method of mounting the engine on to the work stand was to support the rear housing. Henceforth, on this occasion when the '74 year-type of rotary engine is being introduced, we have adopted the method of supporting the front housing by using the **New Hanger** (49 1114 005) for the purpose of facilitating the working procedure. The new hanger can be used for any type of engine now in service.



Fig. 1-4 Engine work stand

1. Remove the oil hose support bracket from the front housing.
2. Mount the engine on the engine work stand (49 0839 000) with the hanger (49 1114 005).
3. Remove the engine hanger bracket from the front cover.
4. Disconnect the vacuum hoses, air hoses and wires, then remove the deceleration valve.
5. Remove the air pump attaching bolts and bar, and remove the air pump and the V-belt.
6. Remove the alternator attaching bolts, and remove the alternator and V-belt.
7. Disconnect the metering oil pump connecting rod, oil tubes and vacuum sensing tube from the carburetor.
8. Remove the intake manifold attaching nuts, and remove the carburetor and intake manifold assembly.



Fig. 1-5 Removing intake manifold ass'y

9. Remove the thermal reactor (or exhaust manifold) attaching nuts and remove it with gaskets.
10. Remove the distributor securing nut and pull it out from the front cover.



Fig. 1-6 Removing distributor

11. Remove the water pump attaching bolts, and remove the pump and gasket.



Fig. 1-7 Removing water pump

12. Invert the engine on the work stand.
13. Remove the bolts attaching the oil pan, and remove the oil pan and gasket.



Fig. 1-8 Removing oil pan

14. Remove the bolts attaching the oil strainer, and remove the oil strainer and gasket.




Fig. 1-9 Removing oil strainer

15. Apply identification marks onto the front rotor housing and rear rotor housing, which are common parts, so that they will be as they were when re-assembling the engine.




Fig. 1-10 Putting identification marks

16. Turn the engine on the work stand so that the top of the engine is up. Then remove the nuts attaching the engine mounting bracket to the front cover and remove the mounting bracket.

17. Attach the ring gear brake (49 1881 060 or 49 1881 055) to the flywheel or drive plate.

18. Remove the eccentric shaft pulley bolt and remove the pulley.




Fig. 1-11 Removing eccentric shaft pulley

19. Turn the engine on the work stand so that the front end of the engine is up.

20. Remove the front cover attaching bolts, and remove the front cover and gasket.




Fig. 1-12 Removing front cover

21. Remove the "O" ring from the oil passage on the front housing.

22. Slide the oil thrower and distributor drive gear off the shaft.

23. Remove the nuts attaching the chain adjuster and remove the chain adjuster.




Fig. 1-13 Removing chain adjuster

24. Remove the lock nut and washer for the oil pump driven sprocket.

25. Slide the oil pump drive sprocket and driven sprocket together with the drive chain off the eccentric shaft and oil pump shaft simultaneously.




Fig. 1-14 Removing chain and sprockets

26. Remove the keys on the eccentric shaft and pump shaft.

27. Slide the balance weight, thrust washer and needle bearing off the shaft.

28. Remove the bolts attaching the bearing housing, and slide the bearing housing, needle bearing, spacer and thrust plate off the shaft.

29. Turn the engine on the work stand so that the top of the engine is up.

30. To remove the flywheel in case of engine mounted with manual transmission, proceed as follows:

1) Remove the clutch pressure plate assembly attaching bolts, and remove the pressure plate assembly and clutch disk.

2) Straighten the tab of the lock washer and remove the flywheel nut using the **special wrench** (49 0820 035).




Fig. 1-15 Removing flywheel nut

3) Remove the flywheel by using the **flywheel puller** (49 0823 300), turning the handle of the puller and lightly hitting the head of the puller.




Fig. 1-16 Removing flywheel

31. To remove the counter weight in case of engine mounted with automatic transmission, proceed as follows.

1) Remove the drive plate, and then remove the **ring gear brake** (49 1881 060).

2) Attach the **counter weight brake** (49 1881 055). Then straighten the tab of the lock washer and remove

the counter weight nut using the **special wrench** (49 0820 035).

3) Remove the counter weight by using the **counter weight puller** (49 0839 305), turning the handle of the puller and lightly hitting the head of the puller.

32. Turn the engine on the work stand so that the rear of the engine is up.

33. Loosen the tension bolts in the sequence shown in Fig. 1-17, and remove the tension bolts.




Fig. 1-17 Tension bolts loosening order

Note:

Do not loosen the tension bolts at one time. Perform the removal in two or three procedures.

34. Lift the rear housing off the shaft.



Fig. 1-18 Removing rear housing

35. Remove any seals stuck to the rotor sliding surface of the rear housing and place them back into their respective original positions.

36. Remove the all corner seals, corner seal springs, side seals and side seal springs from the rear side of the rotor, and place them in the **seal case** (49 0813 250), in accordance with the numbers near each respective groove on the face of the rotor. These marks are made in order to prevent each seal from changing its original position in reassembling.




Fig. 1-19 Removing seals

- 37. Remove the two sealing rubbers and two "O" rings from the rear rotor housing.
- 38. Attach the dowel puller (49 0813 215), and pull the tubular dowels off the rear rotor housing holding the rotor housing down by hand to prevent it from moving up.



Fig. 1-20 Removing tubular dowel

- 39. Lift the rear rotor housing away from the rotor, being careful not to drop the apex seals on the rear rotor. Remove the two sealing rubbers and two "O" rings from the rear rotor housing.



Fig. 1-21 Removing rear rotor housing

- 40. Remove the each apex seal, side piece and spring from the rear rotor and place them in the seal case.
- 41. Remove the rear rotor away from the eccentric shaft and place it upside down on a clean sheet of

- cloth.
- 42. Remove each seal and spring on the other side of the rear rotor, and place them in the seal case as shown in Fig. 1-22.



Fig. 1-22 Removing seals

Note:

- 1) If some of the seals drop off, be careful not to change the original position of each seal on the rotor.
- 2) Apply identification mark onto the rear rotor, which is a common part to front rotor, so that when reassembling the engine the rotor can be installed in its original position.



Fig. 1-23 Putting identification mark

- 43. Remove the oil seals by using the oil seal remover (49 0813 225). Remove the oil seal springs.



Fig. 1-24 Removing oil seal

Note:

- 1) Do not exert strong pressure at only one place to prevent deformation of the oil seal.
- 2) Be careful not to damage the oil seal lip. Use a suitable protector shown in Fig. 1-24.
- 3) Replace the "O" rings in the oil seals when the engine is overhauled.

44. Holding the intermediate housing down by hand, pull the tubular dowel off the intermediate housing using the **dowel puller** (49 0813 215).

45. Lift the intermediate housing off the shaft being careful not to damage the shaft. The intermediate housing should be removed by sliding it beyond the rear rotor journal on the eccentric shaft while holding the intermediate housing up and at the same time pushing up the eccentric shaft.




Fig. 1-25 Removing intermediate housing

46. Lift out the eccentric shaft.
47. Repeat the above procedures to remove the front rotor housing and the front rotor assembly.

1-B. INSPECTION AND REPAIR

1-B-1. Inspecting Front, Intermediate and Rear Housing

1. Check the side housings for traces of gas or water leakage.
2. Remove all carbon on the housings with an extra-



Fig. 1-26 Removing sealing agent

fine emery paper. When using a carbon scraper, be careful not to damage the finished surfaces of the housings.

3. Remove the sealing agent on the housings by using a cloth or a brush soaked in a solution of ketone or thinner.

4. Check for housing distortion by placing a straight edge on the housing surface. Measure the clearance between the straight edge and the housing surface with a feeler gauge, as shown in Fig. 1-27. If the distortion exceeds **0.04 mm (0.0016 in)**, reface or replace the housing.





Fig. 1-27 Checking distortion

5. Check for wear on the rotor sliding surfaces of the housing and joint surfaces with rotor housing. The wear of sliding surface has a tendency of excessive wear occurring at following minor axis area of the housing.




Fig. 1-28 Checking position of wear




Fig. 1-29 Checking wear

The wear of joint surface has a tendency of excessive wear at the hot zone of the engine as shown in Fig. 1-28

If the wear exceeds the following limit, reface or replace the housing.

	Limit	
Sliding surface	0.10 mm	(0.0039 in)
Joint surface	0.05 mm	(0.0020 in)



1-B-2. Regrinding Side Housings

The side housings (front housing, intermediate housing and rear housing) can be reused by grinding them if the required finish can be maintained.

And when this work is performed on the markets, ask the detailed informations of Toyo Kogyo, and follow them.



1-B-3. Inspecting Front Stationary Gear and Main Bearing

1. Check the teeth on the stationary gear for wear, crack or damage.
2. Check the main bearing for wear, scratching, flaking or other damages.
3. Check the clearance between the main bearing and eccentric shaft main journal by measuring the inner diameter of the main bearing and outer diameter of the eccentric shaft main journal.




Fig. 1-30 Checking main bearing clearance

The standard clearance is 0.04 ~ 0.07 mm (0.0016 ~ 0.0028 in). If the bearing clearance exceeds 0.10 mm (0.0039 in), replace the main bearing or eccentric shaft.

To replace the main bearing, proceeds as follows:

- 1) Remove the stationary gear and main bearing assembly from the housing, using the **main bearing replacer** (49 0813 235), shown in Fig. 1-31.



Fig. 1-31 Removing stationary gear assembly

- 2) Remove the adaptor on the main bearing replacer and press the main bearing out of the stationary gear by using the **main bearing replacer** (49 0813 235), as shown in Fig. 1-32.

- 3) Attach the adaptor onto the **main bearing replacer** (49 0813 235), aligning the tang of the bearing and the slot of the stationary gear, and press fit the main bearing into the stationary gear until the adaptor touches the stationary gear flange.




Fig. 1-32 Removing main bearing



Fig. 1-33 Installing main bearing

4. Press in the stationary gear to the housing with the **main bearing replacer** (49 0813 235), aligning the slot of the stationary gear flange and the dowel pin on the housing, as shown in Fig. 1-34




Fig. 1-34 Installing stationary gear

1-B-4. Inspecting Rear Stationary Gear and Main Bearing

1. Check the rear stationary gear and main bearing according to Par. 1-B-3.
 2. Check the "O" ring in the stationary gear for a damage. Replace the "O" ring if necessary.
- To remove and install the stationary gear, proceed as follows:**
- 1) Remove the bolts attaching the stationary gear to

the rear housing.

- 2) Using the **main bearing replacer** (49 0813 235), remove the stationary gear from the rear housing.
- 3) Apply a thin coat of grease on the "O" ring and place it in the groove of the stationary gear.




Fig. 1-35 Assembling stationary gear

- 4) Apply sealing agent onto the stationary gear flange.
- 5) Install the stationary gear to the rear housing being careful not to damage the "O" ring and aligning the slot of the stationary gear with the dowel pin on the rear housing.
- 6) Tighten the bolts attaching the stationary gear.

1-B-5 Inspecting Rotor Housing

1. Check for traces of gas or water leakage along the inner margin of each side face of the rotor housing.
2. Remove all carbon from the inner surface of the rotor housing by wiping with cloth. Soak the cloth in a solution of ketone or thinner if the carbon is difficult to remove.
3. Remove all deposits and rust from the cooling water passages on the housing.
4. Remove sealing agent by wiping with a cloth or brush soaked in a solution of ketone or thinner.



Fig. 1-36 Removing carbon

5. Check the chromium plated surface on the rotor housing for scoring, flaking or any other damage. If any of these condition exists, replace the rotor housing.

6. Check for rotor housing distortion by placing a straight edge at the position shown in Fig. 1-37. Measure the clearance between the straight edge and rotor housing surface with a feeler gauge. If the distortion exceeds **0.04 mm (0.0016 in)**, replace the rotor housing. This check should be done whenever the engine is overhauled.




Fig. 1-37 Checking distortion

7. Check the rotor housing width at points close to the trochoid surface by using a micrometer. The measurements should be taken at least at 4 points. If the difference between the value of **A** point and the minimum value of the points **B C D**, exceeds **0.06 mm (0.0024 in)**, the rotor housing should be replaced with a new one, because there should be possibility of gas or water leakage.




Fig. 1-38 Checking points



Fig. 1-39 Checking rotor housing width

1-B-6. Inspecting Rotor

1. Check the combustion condition and gas leakage. To a certain extent, the combustion condition can be judged as in the case of reciprocating engines by the color and quantity of carbon on the rotor. Combustion can be said to be good if the color of carbon is brown. Generally carbon on the leading side seen from the direction of rotation is brown, while the trailing side shows black color. It should be noted that this color varies according to operating conditions just before the engine is removed.

The gas leakage can be judged by checking the color of the rotor side surface for blow-by traces originating from the side seals and corner seals.

2. Remove the carbon on the rotor by using a carbon remover or emery paper. Carbon in the seal grooves of the rotor should be removed with a carbon remover being careful not to damage the grooves. Wash the rotor in cleaning solution and dry by blowing with compressed air.

3. Carefully inspect the rotor and replace if it is severely worn or damaged.

4. Check the internal gear for cracks, score, worn or chipped teeth.

5. Check the gap between the side housing and the rotor by measuring the rotor housing width and rotor width. The rotor width should be measured at 3 points as shown in Fig. 1-40.

The difference between the minimum width of rotor housing and the maximum width of the rotor should be within **0.10 ~ 0.21 mm (0.0039 ~ 0.0083 in)**.




Fig. 1-40 Checking rotor width

If the clearance is more than the specifications, replace the rotor assembly. If the clearance is less than the specifications, it indicates that the internal gear has come out, so strike the internal gear lightly with plastic hammer being careful not to damage.

1-B-7. Inspecting Rotor Bearing

1. Check the rotor bearing for wear, flaking, scoring or any damage. If any of these conditions is found, replace the bearing.
2. Check the rotor bearing clearance by measuring the inner diameter of the rotor bearing and outer diameter of the eccentric shaft rotor journal. The standard clearance is 0.04 ~ 0.08 mm (0.0016 ~ 0.0031 in). Replace the bearing if it is more than 0.10 mm (0.0039 in).




Fig. 1-41 Checking rotor bearing clearance

To replace the rotor bearing, proceed as follows:

- 1) Place the rotor on the support so that the internal gear is facing downward. Using the rotor bearing replacer (49 0813 240) without the adaptor ring, press the bearing out of the rotor, being careful not to damage the internal gear. If the bearing bore in the rotor is damaged, finish the bore with emery paper and blow with compressed air.




Fig. 1-42 Removing rotor bearing

- 2) Place the rotor on the support with internal gear faced upward. And place the new rotor bearing on the rotor so that the rotor bore is in line with the bearing lug.
- 3) Press fit the new bearing using the rotor bearing

replacer (49 0813 240) with the adaptor removed attaching screws, until the bearing is flush with the rotor boss.




Fig. 1-43 Installing rotor bearing

- 4) Wash the rotor thoroughly and blow with compressed air.

Note:

The rotors are classified into five grades according to their weight and marked a, b, c, d, and e on the internal gear side.

In order to balance the front rotor and rear rotor, the following combinations are adopted in the factory.

Combination of rotor

a - b	c - b, c, d	e - e
b - a, b, c	d - c, d, e	

If it becomes necessary to replace a rotor, use the rotor marked "C" in all cases.




Fig. 1-44 Rotor weight mark

1-B-8. Inspecting Seal Springs

1. Check for weakness, wear or damage of the seal springs, especially the sections of the springs contacting the rotor or seal.
2. Check the free height of the apex seal spring. It should be more than 3.8 mm (0.15 in).

Note:

About the springs of oil seal, side seal and corner seal, confirm the protrusion of seals when installing seals to the rotor.

1-B-9. Inspecting Rotor Oil Seal

1. Check the oil seal for wear or any damage. If the lip width of the oil seal is more than **0.8 mm (0.031 in)**, replace the oil seal.

2. Check the oil seal protrusion as shown in Fig. 1-45 and confirm the free movement by pressing with finger. The protrusion should be more than **0.5 mm (0.02 in)**




Fig. 1-45 Checking oil seal

Note:

When installing oil seal, refer to Par. 1-C-1.

1-B-10. Inspecting Apex Seal

1. Remove all carbon from the apex seal and spring, being careful not to damage the apex seal. **Never use emery paper** as it will damage the apex seal. Wash them with cleaning solution.

2. Check the apex seal for wear, crack or any damage. If any of these conditions is found, replace the apex seal. Check the spring for weakness.

3. Measure the height of the apex seal with a micrometer at two positions shown in Fig. 1-46. Replace if the height is less than **7.0 mm (0.275 in)**.




Fig. 1-46 Apex seal height

4. Check the gap between the apex seal and the groove. To check the gap, place the apex seal in its respective groove on the rotor and measure the gap between the apex seal and the groove with a feeler gauge. The feeler gauge should be inserted until the tip of the



Fig. 1-47 Checking apex seal

gauge reaches the bottom of the groove, for the apex seal tends to wear unevenly as shown in Fig. 1-48. If the gap is more than **0.15 mm (0.0059 in)**, replace the apex seal.




Fig. 1-48 Checking apex seal and groove

5. Check the gap between the apex seal and side housing. To check, measure the length of the apex seal with a micrometer.



Fig. 1-49 Measuring apex seal length

Compare the measured apex seal length with the minimum value among ③ ④ and ⑤ points of the rotor housing (see Fig. 1-38). The standard gap is **0.13 ~ 0.17 mm (0.0051 ~ 0.0067 in)**. If it is more than **0.30 mm (0.0118 in)**, replace the apex seal. If necessary, correct the apex seal length with emery paper.




Fig. 1-50 Clearance of seals

1-B-11. Inspecting Side Seal

1. Remove all carbon from the side seal and spring with a carbon remover.
2. Check the side seal for wear, crack or any other damage and replace if any of these conditions is found.
3. Check the side seal protrusion from the rotor surface, and also confirm the free movement by pressing with finger. The protrusion should be more than **0.5 mm (0.02 in)**.
4. Check the gap between the side seal and the groove



Fig. 1-51 Checking side seal gap




Fig. 1-52 Checking corner seal and side seal gap

with a feeler gauge as shown in Fig. 1-51. The standard gap is **0.04 ~ 0.07 mm (0.0016 ~ 0.0028 in)**. If the gap exceeds **0.10 mm (0.0040 in)**, replace the side seal.

5. Check the gap between the side seal and the corner seal with these seals installed on the rotor.

To check, insert a feeler gauge between the end of the side seal (against the rotating direction of rotor) and the corner seal. If the gap exceeds **0.4 mm (0.016 in)**, replace the side seal.

When the side seal is replaced, adjust the gap between the side seal and the corner seal by grinding the one end of the side seal along the round shape of the corner seal with a fine file so that the gap will be **0.05 ~ 0.15 mm (0.002 ~ 0.006 in)**. And then make respective identification notches on the reverse side of the side seal. If this gap is too large, gas-sealing performance will deteriorate.

1-B-12. Inspecting Corner Seal

1. Remove carbon from the corner seal.
2. Check the corner seal for wear or damage.
3. Check the corner seal protrusion from the rotor surface, and also confirm the free movement by pressing with finger. The protrusion should be more than **0.5 mm (0.02 in)**.
4. Check the gap between the corner seal and the corner seal groove. The standard gap is **0.020 ~ 0.048 mm (0.0008 ~ 0.0019 in)** and the limit is **0.08 mm (0.0031 in)**. This gap enlargement shows uneven wear of the corner seal groove, which occur when the engine is operated with dust entering through a clogged element, damaged air cleaner or any other cause. When the wear is permitted to increase, the engine power will be reduced and the engine will become hard to start. The extent of wear of the corner seal groove is determined by the **bar limit gauge (49 0839 165)** and classified into three conditions.
 - a. Neither end of the gauge goes into the groove. This means that the gap conforms to the specifications.
 - b. While the go-end of the gauge goes into the groove,

the not-go-end does not. This means the gap is more than standard dimension and less than the limit. In this case, replace the corner seal with a **0.03 mm (0.0012 in)** oversize one. **Do not** rebores the groove. **c.** If the both ends of the gauge go into the bore, it means that the gap exceeds the limit of 0.8 mm (0.0031 in). Rebores the corner seal groove with the **Jig and reamer (49 2113 030 and 49 0839 170)** to 11.2 mm (0.4410 in) diameter and use a **0.2 mm (0.0079 in)** oversize corner seal.




Fig. 1-53 Checking corner seal groove

Note:

- a. As the corner seal groove tends to show a heavy wear in the direction of the rotation, the side arcs on the gauge are partially cut off. Be sure to take the measurement in the direction of the maximum wear of the groove.
- b. If the gauge is not available, use a feeler gauge.
- c. The dimensions of the outer diameter of the gauge are as follows:

Go-end	11.0 +0.019 +0.021 mm (0.4331 +0.0007 +0.0008 in)
Not-go-end	11.0 +0.044 +0.046 mm (0.4331 +0.0017 +0.0018 in)

To rebores the corner seal groove, proceed as follows:

- 1) Remove carbon, rust and other deposits from the groove, being careful not to damage.
- 2) Install the **jig (49 2113 030)** onto the rotor and tighten the correct bar being careful not to damage




Fig. 1-54 Reaming corner seal groove

the rotor bearing and apex seal groove.

- 3) Ream the groove with the **Reamer (49 0839 170)** by hand applying sufficient engine oil as a coolant. When feeding the reamer, it must be turned by about 20 rotations or over before the reaming work is accomplished completely.
- 4) Remove the reamer and jig from the rotor.
- 5) Repeat the same procedure when reaming the other grooves of the rotor.
- 6) Thoroughly clean the rotor, and check and confirm by visual inspection the condition of the reaming groove and to see if there is any damage to the rotor.
- 7) Fit a **0.2 mm (0.0079 in)** oversize corner seal into the groove, and check the gap between the corner seal and the groove. The standard gap is 0.020 ~ 0.048 mm (0.0008 ~ 0.0019 in).

Note:

- a. When installing or removing the jig, be careful not to hit the rotor.
- b. If the reaming is carried out without applying oil, it will be difficult to obtain the proper surface roughness no matter how many times the reaming may be repeated.
- c. Avoid two stage reaming, that is, drawing the reamer halfway during the reaming work and then resuming the reaming, because chips may affect the surface roughness.
- d. Before starting the reaming work, it must be confirmed that the reamer diameter is up to specifications, because the reamer could be worn in excess of the limit if it was used many times.

1-B-13. Inspecting Eccentric Shaft

1. Wash the shaft in a cleaning solution and blow the oil passage with compressed air.
2. Check the shaft for cracks, scratches, wear or any other damage. Be sure that the oil passages are open.
3. Measure the diameter of the shaft journals with a micrometer. Replace the shaft if the wear is excessive. The standard diameter is **43 mm (1.6929 in)** on the main journal and **74 mm (2.9134 in)** on the rotor journal.




Fig. 1-55 Measuring rotor journal diameter

4. Check the shaft run-out. To check, mount the shaft on "V"-blocks and apply a dial indicator. Slowly

rotate the shaft and note the reading on the indicator. If the run-out is more than 0.06 mm (0.0024 in), replace the shaft with a new one.




Fig. 1-56 Checking run-out

5. Check the blind plug in the shaft end for oil leakage or looseness. If any oil leakage is found, remove the blind plug with a hexagonal Allen key and replace the "O" ring.




Fig. 1-57 Blind plug

6. Check the needle roller bearing in the shaft end for wear or any damage. Then insert the main drive shaft into the needle roller bearing and check the needle bearing for smooth operation and proper clearance. (Only the car with manual transmission)




Fig. 1-58 Roller bearing and oil jet

To replace the bearing, use the bearing replacer (49 0823 070A).




Fig. 1-59 Removing roller bearing




Fig. 1-60 Installing roller bearing

7. The oil jets are installed in the eccentric shaft. The oil jets open when the number of engine revolutions increases and the oil pressure rises. Check for spring weakness, stick or damage of the steel ball. (Fig. 1-58)

1-B-14. Inspecting Needle Bearing

Check the needle bearing for wear or damage. Inspect the bearing housing and thrust plate for wear or any damage.




Fig. 1-61 Needle bearings

- 1. Thrust washer
- 2. Needle bearing
- 3. Bearing housing
- 4. Thrust plate

1-C. ENGINE ASSEMBLY

The procedures for assembling the engine when the engine is to be completely overhauled are as follows:

1-C-1. Installing Oil Seal

1. Place the rotor on a rubber pad or cloth.
2. Install the oil seal springs in their respective grooves on the rotors with each edge of the spring fitted in the stopper hole, being sure the following points.




Fig. 1-62 Stopper hole of oil seal spring

Caution:

- a. The oil seal springs have been painted in cream or blue color. The **cream-colored** springs must be fitted on the front faces of both front and rear rotors. While the **blue-colored** springs should be on the rear faces of the rotors.
- b. When installing each oil seal spring, the painted side of spring must be faced to the oil seal (upward), that is the square edge of spring faces to the oil seal (upward).




Fig. 1-63 Installing oil seal springs

3. Insert a new "O" ring in each oil seal. Place each oil seal to the groove so that the square edge of spring fit in the stopper hole of the oil seal and push the head of the oil seal slowly with fingers. Be careful not to deform the oil seal.



Fig. 1-64 Installing oil seal

Note:

When replacing the oil seal, confirm the smooth movement of oil seal by placing the oil seal on the oil seal spring in the groove before inserting the "O" ring.

4. Apply sufficient engine lubricant onto each oil seal and groove, and confirm the smooth movement of each oil seal by pressing the head of oil seal.
5. Check the oil seal protrusion. (Ref. Par. 1-B-9)
6. Install the oil seal on the other side.

1-C-2. Installing Each Seal

1. Place the rotor which has been fitted with the oil seals on the rubber pad or cloth.
2. Fit the apex seals without springs and side pieces into their respective grooves so that each side piece positions on the rear side of each rotor.
3. Place the corner seal springs and corner seals into their respective grooves.
4. Fit the side seal springs and side seals into their respective grooves.



Fig. 1-65 Installing side seal

5. Apply engine lubricant onto each spring, and confirm the smooth movement of each spring by pressing its head.
6. Check each seal protrusion. (Ref. Par. 1-B-11, 12)
7. Invert the rotor, being careful not to drop the seals on the rubber pad or cloth, and install the oil seals on the other side in the same manner as above.

1-C-3. Installing Front Rotor

1. Mount the front housing on the work stand (49 0839 000) with the hanger (49 1114 005).
2. Turn the front housing on the work stand so that the top of the housing is up.
3. Apply engine lubricant onto the internal gear of the rotor.
4. Hold the apex seals by using the used "O" ring to keep the apex seals in position and place the rotor assembly on the front housing taking care not to drop the seals. Then turn the front housing with the rotor so that the sliding surface of the front housing faces upward.




Fig. 1-66 Installing front rotor assembly

5. Mesh the internal gear and stationary gear so that one of the rotor apexes is set to any one of the four places shown in Fig. 1-67, and remove the used "O" ring.




Fig. 1-67 Positioning front rotor

Note:

In this case, be careful not to drop the corner seal into the ports.

1-C-4. Installing Eccentric Shaft

1. Lubricate the front rotor journal and main journal on the shaft with engine lubricant.
2. Insert the eccentric shaft being careful not to damage the rotor bearing and main bearing.



Fig. 1-68 Installing eccentric shaft

1-C-5. Installing Front Rotor Housing

1. Apply sealing agent onto the front side of the rotor housing, as shown in Fig. 1-69.




Fig. 1-69 Applying sealing agent

2. Slightly apply vaseline or petrolatum onto new "O" rings and sealing rubbers to prevent them from coming off, and place the "O" rings and sealing rubbers on the front side of the rotor housing.



Fig. 1-70 Installing sealing rubber

Note:

The inner sealing rubber is square type. The wider white line of the sealing rubber should face with

combustion chamber and the seam of the sealing rubber should be placed at the position as shown in Fig. 1-71. Do not stretch the inner sealing rubber.




Fig. 1-71 Positioning inner sealing rubber

When engine overhauling, install the protector to only inner sealing rubber as shown in Fig. 1-72 to improve the durability of the sealing rubber.




Fig. 1-72 Installing sealing rubber protector

3. Invert the front rotor housing being careful not to let the sealing rubbers and "O" rings drop out of the grooves, and mount it on the front housing.
4. Apply engine lubricant onto the tubular dowels and insert the tubular dowels through the front rotor housing holes into the front housing holes as shown in Fig. 1-73.



Fig. 1-73 Installing tubular dowel

5. Apply the sealing agent on the front side of the rotor housing referring to the other side.
6. Place new "O" rings and sealing rubbers on the front rotor housing in the same manner as on the other side.
7. Insert the each apex seal spring confirming the spring direction.
8. Fit the each side piece to its original position. And confirm that the spring should be set correctly on the side piece.




Fig. 1-74 Fitting side piece and spring

9. Apply engine lubricant on the side pieces. And make sure that the front rotor housing is free from any foreign matter and apply some engine lubricant onto the sliding surface of the front housing.

1-C-6. Installing Intermediate Housing

1. Turn the front housing with rotor assembly so that the top of the housing is up, and pull the eccentric shaft about 25 mm (1 in), but do not pull over 35 mm (1.5 in).

Note: As the easy way of installation of the intermediate housing, position the eccentric portion of shaft in diagonally upper right direction.

2. Install the intermediate housing through the eccentric shaft on the front rotor housing, and turn the engine on the work stand so that the rear of engine is up.




Fig. 1-75 Installing intermediate housing

1-C-7. Installing Rear Rotor and Rear Rotor Housing

Refer to steps 1-C-1 to 1-C-5 and install the rear rotor and rear rotor housing.




Fig. 1-76 Installing rear rotor assembly




Fig. 1-77 Installing rear rotor housing

1-C-8. Installing Rear Housing

1. Turn the engine on the work stand so that the rear of engine is up.
2. Apply sufficient engine lubricant onto the stationary gear and main bearing.
3. Install the rear housing on the rear rotor housing. If necessary, turn the rear rotor slightly to engage the rear housing stationary gear with the rear rotor internal gear.



Fig. 1-78 Installing rear housing

1-C-9. Tightening Tension Bolts

1. Place a new sealing washer in each tension bolt.
2. Apply engine oil onto the thread of the bolt.
3. Fit the tension bolts and tighten the bolts gradually in the order shown in Fig. 1-79. The specified torque is 3.2 ~ 3.8 m·kg (23 ~ 27 ft·lb). Do not tighten the tension bolts at one time.

Note:

Replace the sealing washer in the tension bolt when the engine is overhauled.




Fig. 1-79 Tension bolt tightening order

4. After tightening, turn the eccentric shaft and make sure that the rotation is light and smooth.

1-C-10. Installing Flywheel or Counter Weight

a. Manual transmission

1. Apply lubricant to the oil seal in the rear housing.
2. Mount the flywheel to the rear end of the eccentric shaft so that the key fits into the keyway of the flywheel.




Fig. 1-80 Installing flywheel

3. Apply sealing agent to both sides of the flywheel lock washer and place the lock washer in position.




Fig. 1-81 Tightening flywheel nut

4. Fit the flywheel lock nut by the fingers. Hold the flywheel with the **ring gear brake** (49 1881 060) and tighten the lock nut to **45.0 m-kg (350 ft-lb)** using the **special wrench** (49 0820 035).
5. Bent the tab of the lock washer.
6. Hold the clutch disc in its mounting position with the **clutch disc arbor** (49 0813 310). If the arbor is not available, use a spare main drive shaft.
7. Mount the clutch cover and pressure plate assembly on the flywheel, and align the "O" mark on the clutch cover with the reamed hole of the flywheel. Install the attaching bolts and tighten the bolts to 2.0 m-kg (15 ft-lb), using the ring gear brake. Use the two reamer bolts in the reamed holes.

b. Automatic transmission

1. Referring to the above manners (1-C-10, a), fit the key, counter weight, lock washer and nut on the eccentric shaft.
2. Hold the counter weight with the **counter weight brake** (49 1881 055) and tighten the lock nut to **45.0 m-kg (350 ft-lb)** using the **special wrench** (49 0820 035).
3. Fit the drive plate on the counter weight and tighten attaching nuts. After installing the flywheel or counter weight, leave the ring gear brake or counter weight brake on the engine alone.

1-C-11. Adjusting Eccentric Shaft End Play

1. Turn the engine on the work stand so that the front of the engine is up.




Fig. 1-82 Fitting thrust plate

2. Fit the thrust plate with the tapered face down, and slide the spacer and needle bearing onto the eccentric shaft. Then apply sufficient engine lubricant onto them.
3. Place the bearing housing on the front housing. Tighten the attaching bolts with washers.

Note :

If the bearing housing has been installed to the front housing, special care should be taken when installing the spacer.

Install the spacer so that the center of the needle bearing in the bearing housing comes to the center of eccentric shaft, and the spacer should be seated to the thrust plate.

4. Slide the needle bearing onto the shaft, and apply engine lubricant onto it.
5. Slide the balance weight together with the thrust washer onto the shaft.
6. Engage the oil pump drive chain with the driven sprocket and drive sprocket, and then slide the sprockets with chain onto the eccentric shaft and oil pump shaft simultaneously aligning the keyway of the driven gear sprocket with the key on the oil pump shaft. Fit the key onto the eccentric shaft.



Fig. 1-83 Installing chain and sprockets

7. Slide the distributor drive gear onto the eccentric shaft with "F" mark on the gear faced the front of




Fig. 1-84 Eccentric shaft end play

engine, and then slide the spacer and oil thrower onto the eccentric shaft.

8. Install the eccentric shaft pulley onto the shaft aligning the keyway of the pulley with the key.

9. Tighten the pulley bolt to **8.5 m·kg (60 ft·lb)**.

10. Turn the engine on the work stand so that the top of the engine is up.

11. Apply a dial indicator onto the flywheel as shown in Fig. 1-85. Move the flywheel fore and aft, and note the reading of the indicator. The standard end play is **0.04 ~ 0.07 mm (0.0016 ~ 0.0028 in)**.




Fig. 1-85 Checking end play

If the end play is more than **0.09 mm (0.0035 in)**, adjust it by grinding the spacer on a surface plate using an emery paper or replace the spacer. And then recheck the end play in the same manner as above.



Fig. 1-86 Adjusting spacer

Note :

(1) If the end play is below the specified amount, the spacer thickness is too small. If the end play is above the specified amount, the spacer thickness is too big.

(2) The spacers are available in the following thicknesses :

Identification Mark	Thickness
X	8.08 ± 0.01 mm (0.3181 ± 0.0004 in)
Y	8.04 ± 0.01 mm (0.3165 ± 0.0004 in)
V	8.02 ± 0.01 mm (0.3158 ± 0.0004 in)
Z	8.00 ± 0.01 mm (0.3150 ± 0.0004 in)

If the end play is **0.04 ~ 0.07 mm (0.0016 ~ 0.0028 in)**, remove the eccentric shaft pulley, and proceed as follows to install the front cover.

1-C-12. Installing Front Cover and Eccentric Shaft Pulley

1. Turn the engine on the work stand so that the front of the engine is up.

2. Tighten the oil pump driven sprocket nut and bend the tab of the lock washer.

3. Place the chain adjuster in position and tighten the attaching nuts.

4. Place a new "O" ring on the oil passage of the front cover.



Fig. 1-87 Placing "O" ring

5. Place the gasket and front cover on the front housing, and tighten the attaching bolts.




Fig. 1-88 Installing front cover

6. Apply engine lubricant onto the oil seal in the front cover.

7. Install the eccentric shaft pulley onto the shaft and tighten the pulley bolt to **8.5 m·kg (60 ft·lb)**.

1-C-13. Installing Oil Strainer and Oil Pan

1. Turn the engine on the work stand so that the bottom of the engine is up.

2. Cut off the excess gasket on the front cover along the mounting surface of the oil pan.




Fig. 1-89 Cutting off excess gasket

3. Place the oil strainer gasket and strainer on the front housing and tighten the attaching bolts.



Fig. 1-90 Installing oil strainer

4. Apply the sealing agent onto the joint surfaces of each housing.




Fig. 1-91 Applying sealing agent

5. Place the gasket and oil pan in position.
6. Insert the bolts through the stiffeners, and tighten the bolts little by little in turn until the torque becomes 0.55 m·kg (3.5 ft·lb) evenly.

1-C-14. Installing Water Pump

1. Turn the engine on the work stand so that the top of the engine is up.

2. Place the gasket and water pump on the front housing, and tighten the attaching nuts.



Fig. 1-92 Installing water pump

1-C-15. Installing Distributor

1. Rotate the eccentric shaft until the yellow mark or leading side mark on the pulley aligns with the needle on the front cover.

2. Align the tally mark on the distributor housing and driven gear as shown in Fig. 1-93.



Fig. 1-93 Aligning tally mark

3. Insert the distributor so that the distributor lock bolt is located in the center of the slit, and engage the gears.



Fig. 1-94 Installing distributor

4. Rotate the distributor clockwise until the leading contact point starts to separate, and tighten the distributor lock nut.
5. Fit the distributor cap.

1-C-16. Installing Exhaust Manifold

1. Remove the engine from the work stand.
2. Place the gaskets and the thermal reactor in position, and tighten the attaching nuts.
3. Place the hot air duct in position and tighten the attaching nuts.

1-C-17. Installing Intake Manifold

1. Place the carburetor and intake manifold assembly, with the gaskets in position and tighten the attaching nuts.



Fig. 1-95 Installing intake manifold assembly

2. Connect the oil tubes, vacuum tube and metering oil pump connecting rod with the carburetor.
3. Install the deceleration valve and connect the vacuum hoses, air hoses and wires.

1-C-18. Installing Alternator and Air Pump

1. Place the alternator to the bracket with the bolt, and check the clearance (A) as shown in Fig. 1-96.




Fig. 1-96 Adjusting alternator fitting

If the clearance is more than 0.15 mm (0.0059 in), adjust it by using the following adjust shim.

0.15 mm	(0.0059 in)
0.3 mm	(0.0118 in)
0.5 mm	(0.0197 in)

2. Attach the upper end of the alternator flange to the adjusting bar, and fit the "V" belt.
3. Adjust the belt deflection.

The belt deflection should be 15 mm (0.59 in) when thumb pressure of about 10 kg (22 lb) is applied to the middle of the belt between the alternator pulley and eccentric shaft pulley. On a new belt, the deflection should be 13 mm (0.51 in). After adjusting, tighten the bolts and nuts.




Fig. 1-97 Adjusting alternator belt

4. Install the air pump with the attaching bar and bolts. Fit the "V" belt.
5. To adjust the "V" belt tension, push the "V" belt with about 10 kg (22 lb) as shown in Fig. 1-98. The belt deflection should be 10 mm (0.39 in). On the new belt, it should be 8 mm (0.31 in). After adjusting, tighten the bolts and nuts.




Fig. 1-98 Adjusting air pump belt

6. Before removing the engine from the work stand, install the engine hanger bracket to the front cover.

SPECIAL TOOLS

49 0839 000	Engine work stand
49 1114 005	Engine hanger
49 0820 035	Special wrench
49 0823 300	Flywheel puller
49 0839 305	Counter weight puller
49 0813 250	Seal case
49 0813 215	Tubular dowel puller
49 0813 235	Main bearing replacer
49 0813 240	Rotor bearing replacer
49 0813 225	Oil seal remover
49 0839 165	Bar limit gauge (for corner seal groove)
49 2113 030	Reboring jig (for corner seal groove)
49 0839 170	Reamer (for corner seal groove)
49 1881 060	Ring gear brake
49 1881 055	Counter weight brake
49 0877 435	Special wrench (for automatic transmission)
49 0813 310	Clutch disk arbor
49 0823 070A	Eccentric shaft bearing replacer
49 1881 135	Special wrench (for P.C.V. valve)
49 1881 125	Special wrench (for thermal reactor)



1974 EMISSION CONTROL SYSTEM

DESCRIPTION	1A : 2	1A-D. PROTECTIVE SYSTEM	1A : 14
1A-A. EXHAUST EMISSION CONTROL SYSTEM	1A : 2	1A-D-1. Heat Hazard Sensor and Heat Hazard Warning Lamp	1A : 14
1A-A-1. Air Injection and Thermal Reactor System	1A : 2	1A-E. MAINTENANCE SCHEDULE	1A : 15
a. Air pump	1A : 3	1A-E-1. Air Pump	1A : 15
b. Check valve	1A : 3	1A-E-2. Check Valve (Air injection system)	1A : 15
c. Air injection nozzles	1A : 3	1A-E-3. Thermal Reactor	1A : 15
d. Air control valve	1A : 3	1A-E-4. Air Control Valve	1A : 16
e. Thermal reactor	1A : 5	1A-E-5. Thermosensor	1A : 16
1A-A-2. Ignition and Air Flow Control System	1A : 5	1A-E-6. Thermodetector	1A : 17
a. Thermosensor	1A : 6	1A-E-7. Control Unit	1A : 17
b. Thermodetector	1A : 6	1A-E-8. Deceleration Control Valve	1A : 18
c. Control unit	1A : 7	1A-E-9. Altitude Compensator	1A : 19
d. Idle switch	1A : 8	1A-E-10. Water Temperature Switch	1A : 20
1A-A-3. Additional Air Control System	1A : 8	1A-E-11. Idle Switch	1A : 20
a. Deceleration control valve	1A : 8	1A-E-12. Choke Switch (For semi-automatic choke system)	1A : 21
b. Altitude compensator	1A : 9	1A-E-13. Ventilation Valve	1A : 21
1A-A-4. Kick-down Control System (For automatic transmission only)	1A : 10	1A-E-14. Evaporative Line	1A : 21
a. Water temperature switch	1A : 11	1A-E-15. Charcoal Canister	1A : 22
b. Choke switch (Semi-automatic choke system)	1A : 11	1A-E-16. Condense Tank	1A : 22
1A-B. CRANKCASE EMISSION CONTROL SYSTEM (VENTILATION SYSTEM)	1A : 11	1A-E-17. Check Valve (Evaporative emission control system)	1A : 22
1A-B-1. Ventilation Valve	1A : 11	1A-E-18. Heat Hazard Warning System	1A : 22
1A-C. EVAPORATIVE EMISSION CONTROL SYSTEM	1A : 12	1A-E-19. Hoses and Tubes (All systems)	1A : 23
1A-C-1. Charcoal Canister	1A : 12	1A-F. TROUBLE SHOOTING	1A : 24
1A-C-2. Condense Tank	1A : 13	SPECIAL TOOLS	1A : 29
1A-C-3. Check Valve	1A : 13		




Fig. 1A-1 Emission control system

DESCRIPTION

The emission control system consists of an exhaust emission control system, a crankcase emission control system (ventilation system), an evaporative emission control system and a protective system.

1A-A. EXHAUST EMISSION CONTROL SYSTEM

The exhaust emission control system, consisting of an air injection and thermal reactor system, an ignition and air flow control system, an additional air control system and a kick-down control system (automatic transmission), reduces air polluting hydrocarbon and carbon monoxide contained in the exhaust gas of the operating engine.

1A-A-1. Air Injection and Thermal Reactor**System and Secondary Air Control System**

The air injection and thermal reactor system, consisting of a thermal reactor, an air pump, a check valve, air injection nozzles and an air control valve, injects into the exhaust ports secondary air necessary for oxidation

of hydrocarbon and carbon monoxide contained in the exhaust gas.

The air sucked from the air cleaner by the air pump is sent into the air control valve. The air (secondary air) from the air control valve ordinarily flows into the exhaust ports through the check valve and the air injection nozzles. However, under the conditions mentioned below, the flow of the secondary air into the exhaust ports is stopped by the ignition and air flow control system as well as protective system (operation of air cut valve), and the air (cooling air) flows into the thermal reactor cooling air jacket to properly maintain the temperature of the reactor.

1. When the engine speed is over 4,000 rpm (in case of automatic transmission, 4,800 rpm when engine is cold and 3,400 rpm when engine is hot) – operation of ignition and air flow control system
2. When the engine speed is over 1,200 rpm during deceleration (1,400 rpm in case of automatic transmission) – operation of ignition and air flow control system
3. When running under full load (throttle valve is nearly wide open)
4. When the floor temperature is over approximately




Fig. 1A-2 Air injection and thermal reactor system

120°C (248°F) = operation of protective system
 The timing of supplying the secondary air into the exhaust ports and the cooling air into the thermal reactor cooling air jacket is controlled in accordance with the operating conditions of the vehicle (See Par. 1A-A-2).

a. Air pump

The air pump is a vane type driven by the V-belt mounted on the eccentric shaft pulley. The air pump sucks fresh filtered air from the air cleaner, compresses the air and injects it through the air control valve, check valve and air injection nozzles into the exhaust ports adjacent to the thermal reactor.




Fig. 1A-3 Air pump

b. Check valve

The check valve opens and closes according to the




Fig. 1A-4 Check valve

pressure difference between secondary air and exhaust gas to prevent exhaust gas from backflowing into the air injection system and scorching the air pump, hoses, etc. When the pressure of secondary air in the air injection system exceeds the exhaust gas pressure, the secondary air opens the check valve and flows through the air injection nozzles into the exhaust ports.

When the secondary air pressure drops lower than the exhaust gas pressure due to failure of the air pump belt, breaking of the secondary air hose, etc., the check valve closes to prevent the backflow of the exhaust gas into the air injection system.

c. Air injection nozzles

The air injection nozzles are attached to each of the front and rear rotor housings. The secondary air channeled via the air pump and the check valve is injected through the nozzles into the exhaust ports adjacent to the thermal reactor.




Fig. 1A-5 Air injection nozzle

d. Air control valve

The air control valve, consisting of an air cut valve, a No. 1 relief valve and a No. 2 relief valve, has the following functions.




Fig. 1A-6 Air control valve




Fig. 1A-7 Air control valve cross section

1. When the air cut valve is not operating, it becomes the passage of the secondary air from the air pump into the exhaust ports through the check valve and air injection nozzles. — operation of air control valve —

2. When the engine speed is over 4,000 rpm (in case of automatic transmission, 3,400 rpm when the engine is hot and 4,800 rpm when it is cold), the supply of the secondary air into the exhaust ports stops and the secondary air (cooling air) flows into the thermal reactor cooling air jacket to cool the reactor to properly maintain the temperature of the reactor. — operation of air cut valve —

3. When the engine speed is over 1,200 rpm during deceleration (1,400 rpm in case of automatic transmission), supply of the secondary air into the exhaust ports stops and the secondary air (cooling air) flows to the thermal reactor cooling air jacket. The secondary air cutting in this instance prevents excessive supply of the secondary air into the exhaust ports and deteriorated reaction efficiency of the exhaust gas in the reactor. — operation of air cut valve —

4. When the air pressure in the air injection system exceeds, the supply of the secondary air into the exhaust ports is adjusted properly and the excessive secondary air (cooling air) is relieved to the thermal reactor cooling air jacket to cool the reactor. — operation of No. 1 relief valve and No. 2 relief valve —

The air cut valve opens and closes according to the difference of pressure between the vacuum chamber and the air chamber. This valve, which is connected to the diaphragm, is closed during normal operation by the intake manifold vacuum.

When the engine speed exceeds 4,000 rpm (in case of automatic transmission 3,400 rpm at warm condition, 4,800 rpm at cold condition), the control unit actuates the solenoid to close the vacuum sensing way. This equalizes the pressures in the two chambers, the spring force causes the valve to open and the air in the air injection system is channeled to the thermal reactor cooling air jacket before being expelled to the atmos-

phere. At the same time, the air cut valve closes the secondary air passage to cut secondary air supply into the exhaust ports.

During deceleration with the accelerator pedal released completely when the engine speed is over 1,200 rpm (1,400 rpm in case of automatic transmission), the solenoid of the air control valve closes the vacuum sensing way between the intake manifold and the air control valve by means of the low speed switch in the control unit and the idle switch. Consequently, the spring force causes the valve to open and the air in the air injection system is channeled to the thermal reactor cooling air jacket before being expelled to the atmosphere. At the same time, the air cut valve closes the secondary air passage to cut secondary air supply into the exhaust ports.

When the engine is running with full load, the difference of pressure between the vacuum chamber and the air chamber of the air control valve diminishes because the intake manifold vacuum which is led to the vacuum chamber decreases. Consequently, the spring force causes the valve to open and the air in the air injection system is channeled to the thermal reactor cooling air jacket before being expelled to the atmosphere. At the same time, the air cut valve closes the secondary air passage to cut secondary air supply into the exhaust ports.

The No. 1 relief valve is opened and closed in accordance with air pressure in the air injection system and the force of the return spring. When the air pressure in the air injection system increases, the No. 1 relief valve is opened and the air is led to the thermal reactor cooling air jacket to cool it before being expelled to the atmosphere, thus the secondary air flow rate being controlled. When the air pressure decreases, the spring closes the valve.

The No. 2 relief valve is opened and closed in accordance with air pressure in the air injection system and the force of the return spring. When the air pressure in the air injection system exceeds the specified value, the No. 2 relief valve is opened and the air is led to

the thermal reactor cooling air jacket to cool it before being expelled to the atmosphere, thus the secondary air flow rate being controlled. When the air pressure decreases, the spring closes the valve.

e. Thermal reactor

The thermal reactor is mounted just outside the exhaust ports. It oxidizes the unburned exhaust gas expelled from the engine, to reduce the noxious components such as hydrocarbon and carbon monoxide. When the engine speed is high or during deceleration or full load running, the air control valve feeds fresh air from the air pump to the thermal reactor cooling air jacket to properly maintain the temperature of the reactor. The non-return valve which prevents backflow of exhaust gas from the reactor is attached at the air inlet of the reactor.




Fig. 1A-8 Thermal reactor




Fig. 1A-9 Cooling air circuit

1A-A-2. Ignition and Air Flow Control System

The ignition and air flow control system consists of a thermosensor, a thermodetector, an idle switch, and a control unit including high speed switch, low speed switch, thermoswitch and trailing ignition switch. This system ignites and cuts the trailing spark plug to suit engine temperature and engine speed in order to enhance the reactivity of the thermal reactor when the engine is cold. This system has an additional function of regulating the air control valve and the deceleration control valve.

The operating time of the ignition and air flow control system is shown by the following table.

Secondary Air Injection Cut

Manual transmission

Operating time	Parts that operate coordinately
When engine speed is over 4,000 rpm	solenoid of air control valve, air cut valve, high speed switch
During deceleration when engine speed is over 1,200 rpm	solenoid of air control valve, air cut valve, low speed switch, idle switch
When running under full load (throttle valve is nearly wide open)	air cut valve
When floor temperature is over approximately 120°C (248°F) (Protective system)	heat hazard sensor, control unit, solenoid of air control valve, air cut valve

Automatic transmission

Operating time	Parts that operate coordinately
When engine speed is over the specified value 4,800 rpm when cold 3,400 rpm when hot	solenoid of air control valve, air cut valve, high speed switch, thermosensor, thermoswitch (the last two parts when engine is hot)
During deceleration when engine speed is 1,400 rpm	solenoid of air control valve, air cut valve, low speed switch, idle switch
When running with full load (throttle valve is nearly wide open)	air cut valve
When floor temperature is over approximately 120°C (248°F) (Protective system)	heat hazard sensor, control unit, solenoid of air control valve, air cut valve

Control of Trailing Spark Plug Ignition

Manual transmission

Operating time	Parts that operate coordinately
1. Trailing spark plug does not ignite. (Only leading spark plug ignites.)	
During cruising and acceleration (deceleration excluded) when engine speed is 1,200 ~ 4,000 rpm at cold condition	low speed switch, high speed switch, idle switch, trailing ignition switch
2. Trailing spark plug ignites. (Both leading and trailing spark plugs ignite.)	
When engine is hot	thermosensor, thermostwitch, trailing ignition switch
During cruising, acceleration and deceleration when engine speed is below 1,200 rpm or over 4,000 rpm at cold condition	low speed switch, high speed switch, trailing ignition switch, idle switch

Automatic transmission

Operating time	Parts that operate coordinately
1. Trailing spark plug does not ignite. (Only leading spark plug ignites.)	
During cruising and acceleration (deceleration excluded) when engine speed is 1,400 ~ 4,800 rpm at cold condition	low speed switch, high speed switch, idle switch, trailing ignition switch
2. Trailing spark plug ignites. (Both leading and trailing spark plugs ignite.)	
When engine is hot	thermosensor, thermostwitch, trailing ignition switch
During cruising, acceleration and deceleration when engine speed is below 1,400 rpm or over 4,800 rpm at cold condition	low speed switch, high speed switch, trailing ignition switch, idle switch

a. Thermosensor

The thermosensor, which is placed in the cooling water passage, detects the water temperature and sends the signal to the control unit.

When the water temperature rises to the specified value, the thermostwitch and the trailing ignition switch in the control unit close by means of the thermosensor. The electric current then flows to the trailing side ignition coil and the trailing spark plug is ignited. In case of automatic transmission, the opening/closing time of the high speed switch in the control unit becomes from 4,800 rpm when the engine is cold to 3,400 rpm when it is hot. Consequently, when the engine speed is over 3,400 rpm at hot condition, the high speed switch closes and the electric current flows to the solenoid of the air control valve and the solenoid cuts the vacuum sensing

way between the intake manifold and the air chamber of the air control valve. The air cut valve of the air control valve then stops the supply of the secondary air into the exhaust ports by means of the spring force. The secondary air flows into the thermal reactor cooling air jacket to cool the reactor.

b. Thermodetector

The thermodetector which detects the ambient temperature corrects the operating temperature of the thermosensor to resume the ignition of the trailing spark plug after the minimum time required for the thermal reactor warm-up.



Fig. 1A-10 Thermosensor



Fig. 1A-11 Thermodetector

c. Control unit

In the control unit are the thermosthwitch, trailing ignition switch, low speed switch and high speed switch. The functions are as follows. (Refer to electric diagram in Fig. 1A-14)



Fig. 1A-12 Control unit

1. In the whole operating range at hot condition, the thermosthwitch and the trailing ignition switch close and the electric current flows to the trailing side ignition coil and the trailing spark plug is ignited. — operation of thermosthwitch and trailing ignition switch —
2. When the engine speed is over 3,400 rpm at hot condition, the thermosthwitch and the high speed switch close and the electric current flows to the solenoid of the air control valve. Consequently, the solenoid cuts the vacuum sensing way between the intake manifold and the vacuum chamber. This actuated the air cut valve to stop the supply of the secondary air into the exhaust ports and the air flows into the thermal reactor cooling

3. When the engine speed becomes over 4,000 rpm (in case of automatic transmission, 4,800 rpm at cold condition and 3,400 rpm at hot condition), the high speed switch closes and the electric current flows to the solenoid of the air control valve. The solenoid consequently cuts the vacuum sensing way between the intake manifold and the vacuum chamber of the air control valve. This actuates the air cut valve to stop the supply of the secondary air into the exhaust ports and the air flows to the thermal reactor cooling air jacket. — operation of high speed switch —
4. Whether at cold or hot condition, when the engine speed is over 1,200 rpm (1,400 rpm in case of automatic transmission), point (A) of the low speed switch closes and the electric current flows to the idle switch, during deceleration when the accelerator pedal is relieved completely, point (A) of the idle switch closes, and so the electric current from the low speed switch flows to the solenoid of the air control valve. The solenoid then closes the vacuum sensing way between the intake manifold and the air control valve, and this actuates the air cut valve to stop the supply of the secondary air into the exhaust port and the air flows into the thermal reactor cooling air jacket. At the same time, since the electric current to the solenoid of the coasting valve stops, the solenoid opens the atmospheric pressure sensing line. This actuates the coasting valve and the fresh air from the air cleaner enters the intake manifold and prevents afterburn. — operation of low speed switch —
5. When the engine speed is below 1,200 rpm (1,400 rpm in case of automatic transmission), point (B) of the




Fig. 1A-13 Electric diagram of control unit

low speed switch closes. The electric current flows to the trailing side ignition coil through the trailing ignition switch, and ignites the trailing spark plug. — operation of low speed switch and trailing ignition switch —

d. Idle switch

The idle switch detects the deceleration condition of the car. It sends the decelerating condition signal to the control unit and the coasting valve.




Fig. 1A-14 Idle switch

The functions are as follows. (Refer to electric diagram in Fig. 1A-14)

1. While deceleration (with the accelerator pedal released) when the engine speed is over 1,200 rpm (1,400 rpm in case of automatic transmission), point (A) of the idle switch closes and the electric current flows to the air control valve solenoid from the low speed switch. The solenoid consequently cuts the vacuum sensing way between the intake manifold and the vacuum chamber of the air control valve. This actuates the air cut valve to stop the supply of the secondary air into the exhaust ports and the air flows to the thermal reactor cooling air jacket.

2. At the same time, since the electric current to the solenoid of the coasting valve stops, the solenoid opens the atmospheric pressure sensing line. This actuates the coasting valve and the fresh air from the air cleaner enters the intake manifold and prevents afterburn.

3. When the point (B) of the low speed switch and point (A) of the idle switch are closed, the electric current flows to the trailing side ignition coil through the trailing ignition switch, and ignites the trailing spark plug.

1A-A-3. Additional Air Control System

The additional air control system consists of the deceleration control valve and the altitude compensator. During deceleration and gear shifting and immediately after turning off the ignition switch, the additional air control system sends the fresh air from the air cleaner to the intake manifold and adjusts the excessively rich fuel-air mixture preventing afterburn and reducing emissions during deceleration. (operation of deceleration control valve) In order to adjust the excessively rich fuel-air mixture in running in the highland area, the air is supplied to the intake manifold to improve the

combustion. (operation of altitude compensator)

a. Deceleration control valve

The deceleration control valve consists of an anti-afterburn valve and the coasting valve and the functions are as follows.




Fig. 1A-15 Deceleration control valve

1. When the engine speed is over 1,200 rpm (1,400 rpm in case of automatic transmission), and during deceleration when the accelerator pedal is relieved completely, the deceleration control valve sends the fresh air from the air cleaner to the intake manifold. — operation of coasting valve —

2. Immediately after deceleration and during gear shifting, the deceleration control valve sends the fresh air from the air cleaner to the intake manifold. — operation of anti-afterburn valve —

3. Immediately after turning off the ignition switch, the deceleration control valve sends the fresh air from the air cleaner to the intake manifold. — operation of anti-afterburn valve and coasting valve —

The anti-afterburn valve operates by pressure difference between the vacuum chamber and the air chamber, and the spring force. The balance hole in the diaphragm connects the vacuum chamber and the air chamber to control the duration of valve opening.

The intake manifold vacuum rises during deceleration and gear shifting, and the pressure difference between the two chambers opens the valve connected to the diaphragm, so that fresh air from the air cleaner is led into the intake manifold to correct overrich mixture, thus preventing afterburn. When the balance hole equalizes pressure difference, the valve is closed to shut off air. When the ignition switch is turned on, the solenoid shuts the atmospheric pressure sensing line leading to the air chamber. When the engine is switched off the solenoid opens the sensing line, and, due to the resulting pressure difference between the vacuum chamber and the air chamber, the valve connected to the diaphragm is opened, and fresh air is led from the air cleaner into the intake manifold to prevent afterburn. The coasting valve operates by pressure difference between the vacuum chamber and the air chamber, and the spring force. The rise of intake manifold vacuum




Fig. 1A-16 Deceleration control valve cross section

during deceleration and gear shifting causes the valve to open, and air from the air cleaner is supplied into the intake manifold to prevent afterburn and to keep the thermal reactor operating. During deceleration when the engine speed is above 1,200 rpm (1,400 rpm for automatic transmission), the control unit and idle switch command solenoid to open the atmospheric pressure sensing line leading to the air chamber, and, due to resulting pressure difference between the vacuum chamber and the air chamber, the valve connected to the diaphragm is opened, and fresh air is led from the air cleaner into the intake manifold to prevent afterburn. When the ignition switch is turned on, the solenoid shuts the atmospheric pressure sensing line leading to the air chamber. When the engine is switched off the solenoid opens the sensing line, and, due to the resulting pressure difference between the vacuum chamber and the air chamber, the valve connected to the diaphragm is opened, and fresh air is led from the air cleaner into the intake manifold to prevent afterburn.

b. Altitude compensator

In order to prevent the fuel-air mixture from becoming excessively rich because of the low atmospheric pressure in the highland area, the altitude compensator sends the air to the intake manifold and adjusts the fuel-air mixture.



Fig. 1A-17 Altitude compensator




Fig. 1A-18 Additional air control system




Fig. 1A-19 Altitude compensator cross section

In the highland area, especially during idling, part of the inhaled air is controlled by the altitude compensator and enters the intake manifold directly. This enables the overrich mixture to be properly adjusted. The hoses for altitude compensator are colored in Blue for identification.

**1A-A-4. Kick-down Control System
(For automatic transmission only)**

As well as the normal kick-down operation for the transmission shifting, the kick-down solenoid is energized to cause the kick-down when the choke system is in operating condition (the choke switch is closed) for semi-automatic choke system or when the engine water temperature is cold (the water temperature switch is closed) for full-automatic choke system, in order to

obtain quicker warm-up.

**a. Water temperature switch
(Full-automatic choke system)**

The water temperature switch detects the engine water temperature and sends the signal to the kick-down solenoid. And it operates the kick-down solenoid when the engine is cold.




Fig. 1A-20 Water temperature switch




Fig. 1A-21 Water temperature switch

b. Choke switch (Semi-automatic choke system)

The choke switch is equipped in order to detect whether the choke knob is pulled or not and it sends the signal to the kick-down solenoid. The choke switch has the function to operate the kick-down solenoid when the choke knob is pulled.



Fig. 1A-22 Choke switch




Fig. 1A-23 Choke switch

**1A-B. CRANKCASE EMISSION CONTROL SYSTEM
(VENTILATION SYSTEM)**

The crankcase emission control system channels blow-by gas into the intake manifold to burn it up in the combustion chamber and helps to control air pollution caused by engine blow-by gas. This system consists mainly of a ventilation valve and hose necessary to connect the ventilation valve. All connecting hoses in a ventilation system are colored in Red for identification. The air and blow-by gases flow in the ventilation system as shown in Fig. 1A-25. Ventilating air from the air cleaner enters the engine air space. The ventilating air with blow-by gas enters the ventilation valve which regulates the amount of air flow to meet the change of operating conditions and then is directed to the engine.




Fig. 1A-24 Crankcase emission control system

1A-B-1. Ventilation Valve

The ventilation valve is operated by the difference of the pressure between the intake manifold and engine air space. When there is no difference of the pressure (engine at stall condition) or the pressure of the intake manifold is more than that of the engine air space




Fig. 1A-25 Ventilation valve operation (1)

(backfire) the ventilation valve is closed by the tension of valve spring as shown in Fig. 1A-26. If there is large difference (during idling or deceleration), the high vacuum of the intake manifold overcomes the tension of the valve spring, and the valve is pulled towards intake manifold side by the manifold vacuum as shown in Fig. 1A-27. Therefore, the air passes through the restricted passage in the valve.




Fig. 1A-26 Ventilation valve operation (2)

When the difference is small (at normal operation), the valve is balanced by the tension of valve spring and intake manifold vacuum. This increases the flow of blow-by gas. (Fig. 1A-28)




Fig. 1A-27 Ventilation valve operation (3)




Fig. 1A-28 Evaporative emission control system

1A-C. EVAPORATIVE EMISSION CONTROL SYSTEM

The evaporative emission control system is so designed as to prevent the escape of fuel vapor into the air from the fuel system. The fuel vapor rising from the surface of fuel in the fuel tank due to the ambient temperature is channeled into the condense tank and then fed back to the fuel tank when the engine is not running.

Any fuel vapor that has not condensed in the condense tank is led into the charcoal canister in the air cleaner and into the air space of the engine, and is trapped there. When running, the fuel vapor trapped in the charcoal canister is vaporized again by fresh air from the air cleaner and by the engine temperature, and goes to the ventilation valve from which it is sucked into the intake manifold together with the full vapor trapped in the air space of engine and blow-by gas to be burned up in the combustion chamber.

The fuel vapor from the condense tank when the engine is running is directly sucked into the intake manifold via the ventilation valve to be burned up in the combustion chamber.

All connecting hoses in an evaporative emission control system are colored in Red for identification as same as ventilation hoses.

1A-C-1. Charcoal Canister

While the engine is stopped, some of the fuel vapor generated in the fuel tank does not condense in the condense tank and, when channeled into the engine air space without being fed back to the fuel tank, still cannot be trapped in the air space. Such vapor is absorbed by the charcoal canister.

While the engine is running, the fuel vapor trapped in the charcoal canister is released into the intake manifold together with fresh air from the air cleaner and burned



Fig. 1A-29 Charcoal canister

up in the engine. The canister is always being purged by fresh air during engine operation.

1A-C-2. Condense Tank

The condense tank condenses the fuel vapor coming from the fuel tank and returns it to the fuel tank.




Fig. 1A-30 Condense tank

1A-C-3. Check Valve

The check valve located between the condense tank and the charcoal canister in the air cleaner works appropriately when the conditions mentioned below take place, relating to the completely sealed ventilation type fuel system.




Fig. 1A-31 Check valve

1. When the evaporative system is normal, the flows of fuel vapor and ventilation during engine operation are as shown in Fig. 1A-33.




Fig. 1A-32 Check valve cross section

2. If the hose between the check valve and the canister is clogged or frozen, system would not be ventilated at all and as the result, the fuel supply to the engine is cut off. Therefore, when the evaporative line is clogged, the valve (a) is opened by the negative pressure in the fuel tank and the ventilation passage to the atmosphere is opened.




Fig. 1A-33 Check valve operation (1)

3. When the fuel vapor in the fuel tank is expanded due to intense heat, the pressure in the fuel tank will increase. In order to prevent the increase of the pressure in the fuel tank, the valve (b) is opened to release the pressure to the atmosphere.




Fig. 1A-34 Check valve operation (2)

1A-D. PROTECTIVE SYSTEM




Fig. 1A-35 Protective system

This system consisting of a heat hazard sensor and a heat hazard warning lamp is employed to prevent potential heat hazard to the vehicle due to excessive heat radiation from the exhaust system under specific driving conditions. This system is not operative under a normal driving condition, but it is operative under such a specific driving condition as the engine idle speed is kept raised intentionally for a considerable period so that efficient air conditioning may be obtained while the vehicle is standing.

1A-D-1. Heat Hazard Sensor and Heat Hazard Warning Lamp

When the floor temperature becomes more than 120°C (248°F), the heat hazard sensor becomes operative and the heat hazard warning lamp on the instrument panel lights up. At the same time, the electric current from the heat hazard sensor flows to the solenoid of the air control valve through the control unit. Consequently, the solenoid closes the vacuum sensing way between the intake manifold and the air control valve, and so the air cut valve of the air control valve actuates and stops the supply of the secondary air into the exhaust ports, which prevents the floor temperature from rising. When the floor temperature becomes lower than the

specified value (approximately 120°C), the heat hazard sensor becomes inoperative and the heat hazard lamp goes off and at the same time, the electric current stops flowing to the solenoid of the air control valve, and so the secondary air is injected into the exhaust ports.

The heat hazard sensor is located under the seat as shown in Fig. 1A-37.




Fig. 1A-36 Heat hazard sensor and warning lamp



1A-E. MAINTENANCE PROCEDURE

This section explains the procedures for checking, adjusting and replacing the parts of the exhaust emission control system.

1A-E-1. Air Pump

a. Checking air pump

1. Check to see that the air pump "V" belt tension is proper.
2. Check to see that air hoses are free of air leaks.
3. Attach the **air pump gauge set** (49 2113 010) as shown in Fig. 1A-38.
4. Run the engine at idle speed (Manual transmission: 900 rpm, Automatic transmission: 750 rpm in "D" range). If the pressure gauge reading is more than 0.048 kg/cm^2 (0.68 lb/in^2) for manual transmission or 0.034 kg/cm^2 (0.48 lb/in^2) for automatic transmission, the air pump is normal.




Fig. 1A-37 Checking air pump

b. Removing air pump

1. Remove the hot air duct for the air cleaner.
2. Disconnect the air inlet hose (air cleaner ~ air pump) and outlet hose (air pump ~ air control valve) from the air pump.
3. Remove the air pump mounting and adjusting bolts.
4. Remove the "V" belt.
5. Remove the air pump.




Fig. 1A-38 Checking belt tension

c. Installing air pump

Mount the air pump in the reverse sequence, and adjust the tension of the "V" belt in the procedure described below.

d. Adjusting air pump "V" belt

When a 10 kg (22 lb) pressure is given to a spot midway between the air pump pulley and water pump pulley, belt deflection should be $8 \sim 10 \text{ mm}$ ($0.32 \sim 0.39 \text{ in}$); when new, the belt should have a deflection of $7 \sim 8 \text{ mm}$ ($0.28 \sim 0.32 \text{ in}$).

1A-E-2. Check Valve (Air injection system)

a. Checking check valve

1. Disconnect the air hose (air pump ~ air control valve) from the air control valve.
2. Run the engine at idle speed.
3. Hold a finger over the inlet of the air control valve (the inlet from which the air hose is removed). If exhaust gas flow is felt, replace the check valve, spring and gasket.




Fig. 1A-39 Check valve

b. Removing check valve

1. Remove the air control valve as described in Par. 1A-E-4.
2. Remove the gasket, valve and spring.

c. Installing check valve

Install the check valve in the reverse sequence.

1A-E-3. Thermal Reactor

a. Checking thermal reactor

1. Check to see that the thermal reactor is not damaged or cracked.




Fig. 1A-40 Checking non-return valve

- Remove the air hose leading to the air control valve and check to see that the non-return valve works smoothly.
- Start the engine and keep it running at idle speed.
- Make sure that most exhaust gas is not released from the tail of cooling air pipe.

b. Removing thermal reactor

- Remove the air control valve as described in Par. 1A-E-4.
- Remove the bolts attaching the heat insulator to the intake manifold and remove the heat insulator.
- Raise the front of vehicle and support with stands.
- Disconnect the exhaust pipe from the thermal reactor.
- Remove the engine under cover attaching bolts and remove the engine under cover.
- Remove the nuts attaching the thermal reactor to the engine.

Note: The upper nuts should be removed with the **thermal reactor remover** (49 1881 125).

- Remove the thermal reactor.




Fig. 1A-41 Thermal reactor remover

1A-E-4. Air Control Valve

a. Checking air control valve

- Check the air pump according to the procedures in Par. 1A-E-1.
- Connect the connector of the solenoid terminal to the battery and check the operation of the solenoid. If the clicking sound is audible, the solenoid is normal.
- Attach the pressure gauge as shown in Fig. 1A-43.
- Remove the air hose from outlet (A) of the air control valve.
- Start the engine and keep it running at idle speed (900 rpm for manual transmission, 750 rpm in "D" range for automatic transmission). Check to see that there is no air leak from outlet (A) of the air control valve.




Fig. 1A-42 Checking air control valve

Manual transmission:

Make sure that the pressure gauge reads $0.12 \sim 0.20 \text{ kg/cm}^2$ ($1.2 \sim 2.8 \text{ lb/in}^2$) when the engine speed is 3,500 rpm and that there is air leak from outlet (A).

Automatic transmission:

Make sure that the pressure gauge reads $0.12 \sim 0.18 \text{ kg/cm}^2$ ($1.2 \sim 2.6 \text{ lb/in}^2$) when the engine speed is 3,000 rpm and that there is air leak from outlet (A).

- Connect the solenoid terminal to the battery. Make sure that the pressure gauge reads $0 \sim 0.053 \text{ kg/cm}^2$ ($0 \sim 0.75 \text{ lb/in}^2$) and that air flows from outlet (A) of the air control valve.
- Simply checking of air control valve (check every valve incorporated). When the No. 1 relief valve, No. 2 relief valve or the air cut valve is faulty, the air sent from the air pump during idling flows into the air cooling pipe.

b. Removing air control valve

- Remove the hot air duct for the air cleaner.
- Disconnect the air hose (air pump ~ air control valve) from the air control valve.
- Disconnect the cooling air hose (air control valve ~ thermal reactor) from the air control valve.
- Disconnect the vacuum and atmospheric sensing tubes from the air control valve.
- Disconnect the lead wire for the air control valve solenoid at the quick disconnect.
- Remove the air control valve attaching nuts and remove the air control valve.

c. Installing air control valve

Install the air control valve in the reverse sequence.

1A-E-5. Thermosensor

a. Checking thermosensor

- Make sure that there is no boot breakage.
- Connect the ohm meter as shown in Fig. 1A-44, and check the resistance. The readings as shown below indicate that the thermosensor is normal;
Over $7 \text{ k}\Omega$ before warm-up the engine [when ambient and water temperatures are under 30°C (86°F)].



Fig. 1A-43 Checking thermosensor




Fig. 1A-44 Checking thermosensor

Under $2.3\text{ k}\Omega$ after warm-up the engine [when temperature is over 70°C (156°F)].

b. Removing thermosensor

1. Remove the air cleaner.
2. Remove the deceleration control valve and remove the starting motor if necessary.
3. Disconnect the multiple coupler from the thermosensor.
4. Remove the rubber boot from the thermosensor.
5. Remove the nuts attaching the thermosensor to the engine and remove the thermosensor.

c. Installing thermosensor

Install the thermosensor in the reverse sequence.

1A-E-6. Thermodetector




Fig. 1A-45 Checking thermodetector




Fig. 1A-46 Resistance of thermodetector

a. Checking thermodetector

Connect the ohm meter to the terminals of the thermodetector as shown in Fig. 1A-46, and check the resistance. If the ohm meter readings are within the range shown in Fig. 1A-47, the thermodetector is normal.

b. Removing thermodetector

1. Remove the front grille.
2. Disconnect the multiple coupler of thermodetector.
3. Remove the screw attaching the thermodetector and remove the thermodetector.

c. Installing thermodetector

Install the thermodetector in the reverse sequence.

1A-E-7. Control Unit

a. Checking control unit

1. Make sure that the fuse of the control unit is in good condition.




Fig. 1A-47 Checking control unit fuse

2. Disconnect the couplers of thermosensor and idle switch. And check the following points:

- 1) Connect the timing light to the high tension cord of the trailing side distributor. Check to see that the timing light does not go on when the engine speed is under $3,600 \sim 4,400\text{ rpm}$ (Automatic transmission: $4,320 \sim 5,280\text{ rpm}$), and goes on when the engine speed is raised to more than $3,600 \sim 4,400\text{ rpm}$ (Automatic transmission: $4,320 \sim 5,280\text{ rpm}$).



Fig. 1A-48 Checking control unit (I)

2) Connect an ammeter to the air control valve solenoid. Check to see that the current does not flow to the solenoid when the engine speed is under **3,600 ~ 4,400 rpm** (Automatic transmission: **4,320 ~ 5,280 rpm**), and there is flow to the solenoid when the engine speed is above **3,600 ~ 4,400 rpm** (Automatic transmission: **4,320 ~ 5,280 rpm**).




Fig. 1A-49 Checking control unit (2)

3. With the thermosensor connector terminal short-circuited as shown in Fig. 1A-51, check the following points:




Fig. 1A-60 Connector short-circuit

Fig. 1A-50 Connector short-circuit

1) Connect the timing light to the high tension cord of the trailing side distributor and check to see that the timing light goes on in the whole range of revolution including under **3,600 ~ 4,400 rpm** (Automatic transmission: **4,320 ~ 5,280 rpm**).

2) Only automatic transmission:
Connect an ammeter to the air control valve solenoid. Check to see that the current does not flow to the solenoid when the engine speed is under **3,060 ~ 3,740 rpm**, and there is flow to the solenoid when the engine speed is above **3,060 ~ 3,740 rpm**.

4. Connect the thermosensor coupler as before. With the idle switch coupler removed, check the following point:

1) Connect an ammeter to the coasting valve solenoid and check to see that there is current flow to the ammeter when idling.




Fig. 1A-51 Checking control unit (3)

2) Disconnect the hose (air cleaner ~ deceleration control valve) from the deceleration control valve and plug the air suction port of the deceleration control valve.




Fig. 1A-52 Blinding deceleration control valve

3) When the engine speed is gradually lowered from 2,000 ~ 3,000 rpm, the current begins to flow at **1,100 ~ 1,450 rpm** (Automatic transmission: **1,250 ~ 1,650 rpm**).

4. Connect the idle switch coupler as before.
5. Connect the hose to the deceleration control valve.

b. Removing control unit

1. Fold the seat back forward.
2. Disconnect the multiple coupler of control unit.
3. Remove the control unit attaching nuts and remove the control unit.

c. Installing control unit

Install the control unit in the reverse sequence.

1A-E-8. Deceleration Control Valve

a. Checking deceleration control valve

1. Disconnect the hose (air cleaner ~ deceleration control valve) from the air cleaner.
2. Run the engine at idle speed.
3. Make sure that air is not sucked in through the air suction hose of the deceleration control valve.
4. Stop the engine.
5. Disconnect the hose (coasting valve ~ intake mani-




d. Adjusting idle switch
 1. Install the idle switch in the reverse sequence.
 2. Warm up the engine until the water temperature rises about 70°C (159°F).
 3. Set the engine speed to 900 rpm (Automatic transmission: 750 rpm in "D" range) by turning the air adjusting screw.
 4. By increasing and decreasing the engine speed with the accelerator pedal, make sure that switch changes over from "OFF" to "ON" or "ON" to "OFF" at the engine speed of 1,000 ~ 1,100 rpm (1,100 ~ 1,250 rpm for Automatic transmission).
 5. If the switch doesn't change within the range of specified RPM, adjust it by turning adjusting screw of

b. Removing idle switch
 1. Remove the air cleaner.
 2. Disconnect the multiple coupler of idle switch.
 3. Remove the bolts attaching the idle switch and remove the idle switch.
c. Installing idle switch
 Install the idle switch in the reverse sequence.

duction between terminal (A) and (C), and there is conduction between terminal (A) and (B) when an external force is applied (when the primary throttle valve is open), the idle switch is normal.

Fig. 1A-59 Checking idle switch (2)




1. Remove the idle switch coupler.
 2. If there is conduction between terminal (A) and (C) (Fig. 1A-59), and there is no conduction between terminal (A) and (B) when an external force is not applied to the idle switch lever (when the primary throttle valve is idle position) and if there is no con-

a. Checking idle switch
1A-E-11. Idle Switch
 Install the water temperature switch in the reverse sequence.

b. Removing water temperature switch
 1. Drain the coolant from the radiator until the coolant level is below water temperature switch.
 2. Remove the alternator and "V" belt if necessary.
 3. Disconnect the multiple coupler from the water temperature switch.
 4. Loosen and remove the water temperature switch.
c. Installing water temperature switch
 Install the water temperature switch in the reverse sequence.

Fig. 1A-57 Checking water temperature switch



1. Make sure that the conduction between the terminals of the switch are disconnected. If the two terminals switch is in good condition.
 3. If there is something extraordinary in the steps 1 and 2, replace the switch with a new one.

a. Checking water temperature switch
1A-E-10. Water Temperature Switch

idle switch lever. Turn the adjusting screw counter-clockwise when the setting revolution is higher than specified RPM. Turn it clockwise when the setting revolution is lower than specified RPM.

6. Repeat the above procedure (4, 5) and set the engine speed within the range of specified RPM.

7. Make sure that the engine speed in 900 rpm (Auto-matic transmission: 750 rpm in "D" range) by carrying out no load running two or three times.

1A-E-12. Choke Switch
(For semi-automatic choke system)

a. Checking choke switch

1. Remove the choke switch terminal.
2. If the two terminals of the switch are disconnected by pulling the choke control knob about 10 mm (0.4 in) or 25 mm (1.0 in) for automatic transmission and conducted by returning the knob, the choke switch is normal.



Fig. 1A-61 Checking choke switch (1)




Fig. 1A-62 Checking choke switch (2)

1A-E-13. Ventilation Valve

a. Checking ventilation valve

1. Check to see that the air cleaner element is not clogged.
2. Install a vacuum gauge as shown in Fig. 1A-64.
3. Start the engine. When the engine speed is raised

to 2,500 ~ 3,000 rpm, the vacuum reading must be under 60 mm-Hg.

b. Removing ventilation valve

1. Remove the deceleration control valve, as described in Par. 1A-E-8.
2. Remove the starting motor if necessary.
3. Disconnect the ventilation hose at the ventilation valve.
4. Loosen and remove the ventilation valve with the ventilation valve wrench (49 1881.135).

c. Installing ventilation valve
Install the ventilation valve in the reverse sequence.

1A-E-14. Evaporative Line

a. Checking evaporative line

1. Disconnect the evaporative hose from the "T" joint which is connected to the ventilation hose.
2. Connect the disconnected hose to the "U" type manometer as shown in Fig. 1A-65.
3. Apply a compressed air gradually into the manometer and the difference of water level should be 356 mm (14.0 in). After that, blind the inlet of the manometer.
4. Leave the manometer for five minutes, with the inlet blind. Then, if the difference of water level is over 343 mm (13.5 in), the evaporative line will be in good condition. If the difference is not within the specifications, inspect the following parts. If any defect, repair or replace.

- (1) Leaky or loosen hoses
- (2) Leaky condense tank
- (3) Leaky fuel tank
- (4) Leaky or loosen fuel line
- (5) Leaky filler cap
- (6) Leaky fuel gauge unit




Fig. 1A-63 Checking ventilation valve




Fig. 1A-64 Checking evaporative line

1A-E-17. Check Valve

(Evaporative emission control system)

- a. **Checking check valve**
 1. Remove the check valve.
 2. Blind one end of the check valve by hand, and install the pressure gauge to the other end as shown in Fig. 1A-67.




Fig. 1A-66 Checking check valve

3. Breathe in and out the check valve with the pressure of about 0.5 kg/cm^2 (7.1 lb/in^2), and if the valve operates, it will be satisfactory. But, if not, replace it with new one.

- b. **Removing check valve**
 1. Raise the rear end of the vehicle and support with stands.
 2. Disconnect the hoses from the check valve.
 3. Remove the bolts attaching the check valve and remove the check valve.

c. **Installing check valve**
Install the check valve in the reverse sequence.

1A-E-18. Heat Hazard Warning System

- a. **Checking heat hazard warning system**
 1. Remove the heat hazard sensor from the body.

1A-E-15. Charcoal Canister

a. **Checking charcoal canister**

1. Check to see that the air cleaner element is not clogged.
2. Visually check the adhering condition of oil. When the whole surface is damp with oil, measure the ventilation resistance.
3. Attach a vacuum gauge as shown in Fig. 1A-65. Check to see that when the engine speed is raised to 2,500 ~ 3,000 rpm, the vacuum gauge reads under 60 mm-Hg.




Fig. 1A-65 Checking charcoal canister

Note: The charcoal canister and air cleaner cover should be replaced as an assembly only.

1A-E-16. Condense Tank

- a. **Removing condense tank**
 1. Remove the condense tank cover.
 2. Disconnect the hoses from the condense tank.
 3. Remove the bolts attaching the condense tank and remove the condense tank.

b. **Installing condense tank**
Install the condense tank in the reverse sequence.

1. Inspect all hoses and tubes for deterioration or holes and all tubes for cracks or holes.
 2. Check all hoses and tubes for improper connections.
 3. If any defect is suspected, fit properly or replace if necessary.

- a. Inspecting hoses and tubes**
1. Inspect all hoses and tubes for deterioration or holes and all tubes for cracks or holes.
 2. Check all hoses and tubes for improper connections.
 3. If any defect is suspected, fit properly or replace if necessary.

- b. Removing heat hazard sensor**
1. Remove the seat.
 2. Disconnect the multiple coupler from the heat hazard sensor.
 2. Remove the screws attaching the heat hazard sensor and remove the heat hazard sensor.




Fig. 1A-69 Heating up heat hazard sensor




Fig. 1A-67 Checking heat hazard warning system

3. Place it in engine oil with a thermometer. Be sure to prevent the oil entering into the inside of the sensor.
 4. Gradually heat the oil so as to raise its temperature at the rate of one degree a minute. The test lamp which is connected to the air control valve lead and the heat hazard warning lamp should light at the temperature of $120 \pm 5^\circ\text{C}$ ($248 \pm 10^\circ\text{F}$) when the engine is running at idle speed.

2. Disconnect the air control valve lead and connect the test light as shown in Fig. 1A-69.




Fig. 1A-68 Connecting test lamp




Fig. 1A-64 Checking evaporative line

1A-E-17. Check Valve

(Evaporative emission control system)

a. Checking check valve

1. Remove the check valve.
2. Blind one end of the check valve by hand, and install the pressure gauge to the other end as shown in Fig. 1A-67.




Fig. 1A-66 Checking check valve

3. Breathe in and out the check valve with the pressure of about 0.5 kg/cm^2 (7.1 lb/in^2), and if the valve operates, it will be satisfactory. But, if not, replace it with new one.

b. Removing check valve

1. Raise the rear end of the vehicle and support with stands.
2. Disconnect the hoses from the check valve.
3. Remove the bolts attaching the check valve and remove the check valve.

c. Installing check valve

Install the check valve in the reverse sequence.

1A-E-18. Heat Hazard Warning System

a. Checking heat hazard warning system

1. Remove the heat hazard sensor from the body.

1A-E-15. Charcoal Canister

a. Checking charcoal canister

1. Check to see that the air cleaner element is not clogged.
2. Visually check the adhering condition of oil. When the whole surface is damp with oil, measure the ventilation resistance.
3. Attach a vacuum gauge as shown in Fig. 1A-66.

Check to see that when the engine speed is raised to 2,500 ~ 3,000 rpm, the vacuum gauge reads under 60 mm-Hg.




Fig. 1A-65 Checking charcoal canister

Note: The charcoal canister and air cleaner cover should be replaced as an assembly only.

1A-E-16. Condense Tank

a. Removing condense tank

1. Remove the condense tank cover.
2. Disconnect the hoses from the condense tank.
3. Remove the bolts attaching the condense tank and remove the condense tank.

b. Installing condense tank

Install the condense tank in the reverse sequence.

1A-F. TROUBLE SHOOTING

1A-F-1. Symptoms, Causes and Remedies

The possible faults and their remedies are listed in the

following table. When the symptoms of troubles are detected, proper care must be taken immediately before proceeding to the next probable cause.

Symptoms and probable causes	Remedies
<p>1. Poor acceleration</p> <ul style="list-style-type: none"> * The engine does not fully respond to the depression of the accelerator pedal. * The accelerative force is poor. * The climbing capacity is insufficient. * The max. speed can not be obtained. <ol style="list-style-type: none"> 1) Improper ignition timings for leading and trailing plugs 2) Improper opening of carburetor secondary throttle valve 3) Fouling and excessive gap of spark plugs (Fouling by lead or carbon) 4) Burned or improperly adjusted distributor contact point 5) Lack of fuel supply at high speed running 6) Clogging of air cleaner 	<p>See 5-C-2 Adjust Check See 5-E Clean or replace See 5-C-1 Replace if necessary See 4-B Replace if necessary Clean</p>
<p>2. Rough engine idling and hard starting</p> <ul style="list-style-type: none"> * The idling speed can not be lowered. * Too much engine vibration at idling. * The engine starting is too hard. * The engine stalls immediately even if it starts. <ol style="list-style-type: none"> 1) Air leak from each hose 2) Clogging of carburetor jets 3) Improper seating of carburetor secondary throttle valve 4) Fouled spark plug 5) Burned or improperly adjusted distributor contact point 6) Improper ignition timings of leading and trailing plugs 7) Defective ventilation valve 8) Internal disconnection of leading and trailing ignition coils 9) Air leak from air intake system 10) Defective deceleration control valve 11) Low compression pressure 12) Defective altitude compensator 	<p>See 1A-E-19 Replace if necessary Clean Check See 5-E-3 Clean or replace See 5-C-1 Clean or replace See 5-C-2 Adjust See 1A-E-13 Replace if necessary Replace Repair or replace if necessary See 1A-E-8 Replace if necessary Repair See 1A-E-9 Replace if necessary</p>
<p>3. Noisy air pump</p> <ul style="list-style-type: none"> * The noise is generated by the air pump when the engine is idling. * The noise is generated by the air pump when the engine is racing. <ol style="list-style-type: none"> 1) Improperly adjusted "V" belt 2) Defective air pump 3) Disconnected or leaky air hose 4) Insufficient tightening of pump attaching bolts 	<p>See 1A-E-1 Adjust See 1A-E-1 Replace Connect and replace Tighten</p>
<p>4. Improper fuel connection between slow and main zones (Flat spot)</p> <ul style="list-style-type: none"> * Shock is felt when depressing the accelerator pedal to accelerate from the low speed cruising condition. * Shock is felt when depressing the accelerator pedal after turning left at low speed. <ol style="list-style-type: none"> 1) Improper injection of carburetor accelerator pump 2) Clogging of carburetor jets 3) Fouled leading spark plug 4) Excessively low carburetor fuel level 5) Continuously opened anti-afterburn valve 	<p>See 4-A-5 Clean See 5-E-3 See 4-A-3 Adjust See 1A-E-8 Replace if necessary</p>
<p>5. Improper fuel connection between primary and secondary zones</p> <ul style="list-style-type: none"> * Shock is caused when accelerating from running at around 3,000 rpm by depressing the accelerator pedal. * Shock is caused when promptly accelerating from the middle speed or the decelerating condition. 	

Symptoms and probable causes	Remedies
1) Clogging of carburetor jets 2) Excessively low carburetor fuel level 3) Serious clogging of air cleaner element 4) Continuously opened anti-afterburn valve and coasting valve (deceleration control valve)	Clean See 4-A-3 Adjust Clean or replace See 1A-E-8 Replace if necessary
6. Large car knocking during cruising * It is impossible to cruise constantly in any gear. * Shock is sometimes caused during running in top gear. Note: These phenomena are more or less inevitable. Therefore, unless the car knocking is excessive, it can be regarded to be normal. 1) Clogging of carburetor jets or excessively low fuel level 2) Trailing side ignition does not occur. 3) Air leak from each hose 4) Air leak from each valve 5) Fouled spark plug 6) Improper distributor vacuum advance (no advance)	Clean or adjust (See 4-A-3) Check and replace if necessary See 1A-E-19 Repair and replace if necessary Replace if necessary See 5-E-3 Clean or replace See 5-C-4 Repair and replace parts
7. Abnormally large engine knocking 1) Improper ignition timings of leading and trailing sides (excessive advance) 2) Excessive distributor vacuum advance 3) Excessive distributor centrifugal advance 4) Too poor fuel 5) Insufficient heat range or extreme gap erosion of spark plug	See 5-C-2 Adjust See 5-C-4 Adjust See 5-C-4 Adjust Clean See 5-E-1 Adjust or replace
8. Pre-ignition or spit back * Large noise comes from the engine compartment at high speed running, e.g. on the free way, and the engine horsepower falls. Note: If the car is run continuously under the condition mentioned above, the insulator of the spark plug is broken and bites into the combustion chamber, causing the vehicle to be inoperable. Pre-ignition Spit back 1) Excessive spark plug gap for trailing side 2) Excessive advance of trailing side ignition 3) Excessive advance of leading side ignition 4) Insufficient heat range of spark plug 5) Insufficient metering oil 6) Sticky apex seal 7) Improper alignment of high tension cords	
9. Large car bucking or deceleration vibration * Within the range where the coasting valve should operate (when decelerating from 1,200 rpm [automatic transmission: 1,400 rpm] or over) large car bucking occurs. Note: Even if the car bucking happens to occur within the range of engine speed less than 1,200 rpm (automatic transmission: 1,400 rpm) where the coasting valve does not operate, it may be regarded as normal. 1) Improper operation of coasting valve (deceleration control valve) 2) Defective control unit 3) Improper idle fuel flow or idle speed 4) Air leak from each hose 5) Air leak form each valve 6) Defective idle switch 7) Improperly adjusted idle switch 8) Fouled spark plug	See 1A-E-8 Replace See 1A-E-7 Replace See 4-A-1 Adjust See 1A-E-19 Repair and replace if necessary Repair and replace if necessary See 1A-E-11 Replace See 1A-E-11 Adjust Clean and replace

Symptoms and probable causes	Remedies
<p>10. Afterburning</p> <ul style="list-style-type: none"> * Extremely annoying afterburning occurs during deceleration. * Afterburning occurs when turning off the ignition switch. <ol style="list-style-type: none"> 1) Deceleration control valve not opening properly 2) Coasting valve (deceleration control valve) not opening properly 3) Rich idle mixture 4) Gas leak from exhaust system 5) Too low idle revolution 	<p>See 1A-E-8 Replace See 1A-E-8 Replace See 4-A-1 Adjust Repair and replace parts See 4-A-1 Adjust</p>
<p>11. Over flow from carburetor</p> <ol style="list-style-type: none"> 1) Dust biting into needle valve 2) Improper seating of needle valve 3) Improper movement of float 4) Large fuel pressure of fuel pump 	<p>Clean Clean and replace parts Adjust and replace parts See 4-B Replace if necessary</p>
<p>12. The engine brake does not work even if the accelerator pedal is released.</p> <ul style="list-style-type: none"> * Even if the accelerator pedal is released when running, the engine brake does not work, which causes the overrunning and makes the driver uneasy. <ol style="list-style-type: none"> 1) Improper returning of carburetor primary throttle valve 2) Improper returning of carburetor secondary throttle valve 	<p>Clean Clean</p>
<p>13. The air jets out from the tail pipe for the forced air cooling during idling.</p> <ol style="list-style-type: none"> 1) Improper operation of air control valve 2) Electric current flowing from the control unit to air control valve 	<p>See 1A-E-4 Replace if necessary See 1A-E-7 Replace</p>
<p>14. Factors which adversely affect overall emissions under proper procedure</p> <ol style="list-style-type: none"> 1) Improper operation of air control valve (Air cut valve, No. 1 relief valve and No. 2 relief valve) 2) Defective control unit 3) Trailing side spark plug is not controlled. (when the engine is cold) 4) Improper ignition timings of leading and trailing plugs 5) Improper engine idling speed 6) Defective carburetor (improper fuel level, jet, etc.) 7) Improper operation of deceleration control valve 8) Fouled spark plug 9) Breakage of reactor 10) Air leak from secondary air passage 11) Air leak from each sensing tube to intake manifold 	<p>See 1A-E-4 Replace if necessary See 1A-E-7 Replace See 1A-E-7 Replace if necessary See 5-C-2 Adjust See 4-A-1 Adjust See 4-A Adjust or repair See 1A-E-8 Replace if necessary See 5-E-3 Clean or replace See 1A-E-3 Replace Repair and replace Repair and replace</p>
<p>15. Factors which adversely affect idling emissions</p> <ol style="list-style-type: none"> 1) Improper idling speed or mixture 2) Defective spark plug 3) Improper ignition timings of leading and trailing sides 4) Defective distributor contact point 5) Deteriorated air pump 6) Improper operation of air control valve 7) Defective control unit 8) Air leak from each valve into intake manifold 9) Breakage of reactor 	<p>See 4-A-1 Adjust See 5-E Clean or replace See 5-C-2 Adjust See 5-C-1 Clean or replace See 1A-E-1 Replace See 1A-E-4 Replace if necessary See 1A-E-7 Replace Repair and replace See 1A-E-3 Replace</p>
<p>16. Factors which adversely affect deceleration emissions</p> <ol style="list-style-type: none"> 1) Improper idling speed and fuel flow 2) Improper operation of deceleration control valve 3) Improper operation of air control valve (Air cut valve, No. 1 relief valve and No. 2 relief valve) 4) Defective idle switch 5) Breakage of reactor 	<p>See 4-A-1 Adjust See 1A-E-8 Replace if necessary See 1A-E-4 Replace if necessary See 1A-E-11 Replace See 1A-E-3 Replace</p>

Symptoms and probable causes	Remedies
17. Factors which adversely affect acceleration emissions	
1) Improper air pump flow	See 1A-E-1 Replace
2) Defective air control valve (Air cut valve, No. 1 relief valve and No. 2 relief valve)	See 1A-E-4 Replace if necessary
3) Trailing side spark plug also ignited (when the engine is cold)	See 1A-E-7 Replace if necessary
4) Defective thermosensor	See 1A-E-5 Replace
5) Defective thermodetector	See 1A-E-6 Replace
6) Defective carburetor (improper fuel level and other)	See 4-A Adjust
7) Defective control unit	See 1A-E-7 Replace
8) Defective reactor	See 1A-E-3 Replace
9) Defective spark plug	See 5-E Replace

1A-F-2. Detects, Conditions of Trouble and Causes of Defects Related to Each System

a. Air control valve

Possible troubles	Corresponded item
1. Number of revolutions during idling decreases.	B
2. Emission during idling becomes unfavourable.	B, C
3. Emission during acceleration becomes unfavourable.	B
4. Emission during cruising becomes unfavourable.	B
5. Emission during deceleration becomes unfavourable.	B
6. Damage is liable to occur on reactor.	A
7. Rough engine idling.	B
Conditions of trouble of system	Corresponded item
A. Remains constantly open (air inject)	a, b
B. Remains constantly closed (air cut)	a, b
C. Excessive air leakage from valve	b
Probable causes	
a. Defective control unit	
b. Defective air control valve	

b. Thermosensor

Possible troubles	Corresponded item
1. Exhaust emission becomes abnormally unfavourable.	A
2. Possibility of the reactor being damaged is great.	B
3. Penalty in fuel economy	B
4. Power drop	B
Conditions of trouble of system	Corresponded item
A. Trailing ignition does not cut off in driving ranges other than "idling, deceleration or wide open throttle" at normal temperature cold start.	a, b
B. Trailing ignition remains constantly off in driving ranges other than "idling, deceleration, or wide open throttle" when the engine is warm.	a, b
Probable causes	
a. Defective control unit	
b. Defective thermosensor	

c. Thermodetector

Possible trouble	Corresponded item
1. Trailing ignition does not cut off at normal temperature cold condition and 4 plugs are in operation.	A, B
Conditions of trouble of system	Corresponded item
A. Disconnection of connector	a
B. Broken connection of wires inside thermodetector	a
Probable cause	
a. Defective thermodetector	

d. Control unit

Possible troubles	Corresponded item
1. Exhaust emission becomes abnormally unfavourable. 2. Power drop 3. Driveability shows abnormally deterioration.	A, C, B, C B,
Conditions of trouble of system	Corresponded item
A. Trailing ignition does not cut off when engine is cold. B. Trailing ignition remains constantly off. C. Deceleration control valve or air control valve operate improperly.	a, b a, b a
Probable causes	
a. Defective control unit b. Defective thermosensor	

e. Fuse of the control unit

Possible troubles	Corresponded item
1. Possibility of the reactor being damage 2. Rough engine idling 3. Abnormal CO, HC readings at engine idling and decelerating 4. Flat spot occurs during driving. 5. Excessive periodical engine knocks (Serzing) 6. Flat spot occurs during light acceleration from low speed running or deceleration condition. 7. Engine idle speed becomes high.	A B B B B B B
Conditions of trouble of system	Corresponded item
A. Air control valve remains open (air injection). B. Deceleration control valve (coasting valve) remains open.	a, b, c a, b, d,
Probable causes	
a. Fuse of control unit blows. b. Defective control unit c. Defective air control valve d. Defective deceleration control valve	

f. Deceleration control valve

Possible troubles	Corresponded item
1. Extremely annoying afterburning occurs during deceleration or after turning off the ignition switch. 2. Rough engine idling 3. Hard engine starting 4. Abnormal CO, HC readings at engine idling and decelerating 5. Flat spot occurs during driving. 6. Excessive periodical engine knocks (Serzing) 7. Flat spot occurs during light acceleration from low speed running or deceleration condition. 8. Engine idle speed becomes high.	B, C A, C A, C A, C A, C A, C A, C A, C
Conditions of trouble of system	Corresponded item
A. Valve stay open or delay to close B. Valve stay closed or delay to open C. Excessive air leak at valve	a, b, c a, b, c a
Probable causes	
a. Defective idle switch b. Defective control unit c. Defective deceleration control valve	

g. Idle switch

Possible troubles	Corresponded item
<ol style="list-style-type: none"> 1. Exhaust emission becomes abnormally unfavourable. 2. Driveability deteriorates. 3. Abnormal afterburn occurs. 4. Car bucking becomes abnormally excessive. 	<p>B</p> <p>A</p> <p>B</p> <p>B</p>
Conditions of trouble of system	Corresponded item
<ol style="list-style-type: none"> A. Coasting valve remains constantly open at acceleration. B. Coasting valve does not open during deceleration. 	<p>b, c</p> <p>a, b, c, d</p>
Probable causes	
<ol style="list-style-type: none"> a. Defective control unit b. Defective coasting valve solenoid c. Defective idle switch d. Improper return of the carburetor primary throttle valve 	

h. Ventilation valve

Possible troubles	Corresponded item
<ol style="list-style-type: none"> 1. Misfiring frequently occurs during idling and fluctuations in number of revolutions increase. 2. Number of revolutions at idling decreases. 3. Dilution of engine oil with gasoline increases. 4. Defective purging occurs in charcoal canister. 	<p>B</p> <p>A</p> <p>B</p> <p>A</p>
Conditions of trouble of system	Corresponded item
<ol style="list-style-type: none"> A. Remains constantly close B. Remains constantly open 	<p>a</p> <p>a</p>
Probable cause	
<ol style="list-style-type: none"> a. Defective ventilation valve 	

SPECIAL TOOLS

49 2113 010	Air pump gauge set
49 2113 011	T-fitting
49 2113 012	Plug
49 2113 014	Pressure gauge
49 1881 125	Thermal reactor remover
49 1881 135	Ventilation valve wrench

LUBRICATING SYSTEM

- 2-A. LUBRICATING CIRCUIT 2 : 1
- 2-B. OIL PUMP 2 : 2
 - 2-B-1. Disassembling Oil Pump..... 2 : 2
 - 2-B-2. Inspecting Oil Pump 2 : 2
 - 2-B-3. Assembling Oil Pump 2 : 3
- 2-C. OIL PUMP DRIVING..... 2 : 3
 - 2-C-1. Chain Adjuster Inspection..... 2 : 3
 - 2-C-2. Oil Pump Chain and Sprocket Inspection 2 : 3
- 2-D. PRESSURE CONTROL VALVE 2 : 4
 - 2-D-1. Checking Pressure Control Valve 2 : 4
- 2-E. OIL COOLER 2 : 4
 - 2-E-1. Repairing Oil Cooler 2 : 4
- 2-F. BY-PASS VALVE 2 : 4
 - 2-F-1. Checking By-pass Valve 2 : 4
- 2-G. PRESSURE REGULATOR 2 : 5
 - 2-G-1. Checking Pressure Regulator 2 : 5
 - 2-G-2. Checking Oil Pressure 2 : 5
- 2-H. OIL PRESSURE SWITCH 2 : 5
- 2-I. OIL FILTER 2 : 5
 - 2-I-1. Replacing Oil Filter 2 : 6
- 2-J. METERING OIL PUMP 2 : 6
 - 2-J-1. Checking Metering Oil Pump 2 : 6
 - 2-J-2. Adjusting Metering Oil Pump 2 : 7
 - 2-J-3. Disassembling Metering Oil Pump 2 : 7
 - 2-J-4. Assembling Metering Oil Pump 2 : 7
- 2-K. CHECK VALVE 2 : 9
- 2-L. OIL PAN 2 : 9
 - 2-L-1. Oil Pan Removal 2 : 9
 - 2-L-2. Oil Pan Inspection 2 : 9
- SPECIAL TOOL 2 : 9



2-A. LUBRICATING CIRCUIT

1. The oil pump which is driven by the eccentric shaft, draws up the oil from the oil pan through the strainer and sends it to the oil cooler through the pressure control valve.
2. The pressure control valve sends the surplus oil back to the oil pan when the oil pressure exceeds 11 kg/cm^2 (156 lb/in^2) in order to prevent the oil cooler and the oil hose from damage by the exceeding pressure which is generated at the starting in the very cold weather.
3. The by-pass valve is installed on the oil cooler in order to prevent drop of oil supply which is caused by resistance of oil cooler in the cold weather and regulate the temperature of the oil circulating in the engine. The oil is sent directly to the engine without passing through the oil cooler when the difference of the oil pressure of inlet and outlet pipes is more than 3.56 kg/cm^2 (50.7 lb/in^2) at 70°C (158°F) and/or the temperature of the oil is under 60°C (140°F).
4. The oil from the oil cooler is forced to the pressure regulator on the rear housing.
5. The oil of which pressure is regulated to 5 kg/cm^2 (71.1 lb/in^2), is forced to the oil filter.
6. The oil that has been filtered by the oil filter is forced to the front main bearing through the tubular

dowel and to the rear main bearing through the passage of the rear housing.

7. The oil that has passed through the oil holes of the bearings, lubricate the front and rear main bearings and enters the oil passage provided in the eccentric shaft.

8. The oil passing through the eccentric shaft passage lubricates the rotor bearings.

9. Needle bearings which are provided in front of the front housing are lubricated by the oil forced through the little hole led to the oil passage of the eccentric shaft and the oil coming after lubricating the front main bearing.

10. The eccentric shaft is equipped with two oil jets. The oil in the passage of the eccentric shaft is injected through the oil jets into the front and rear rotors and cools the rotors.

11. Stationary gears and internal gears are lubricated by the oil coming after cooling the rotors and after lubricating the main bearings.

12. The oil passing through the tubular dowel is sent to the front cover and led to the metering oil pump.

13. From the metering oil pump, the oil is forced to the carburetor and is supplied into the combustion chambers together with the air-fuel mixture to lubricate the apex seals, corner seals, side seals and housings.




Fig. 2-1 Lubricating circuit

2-B. OIL PUMP

The oil pump is of a rotor type based on a trochoid curve and consists of the parts as shown in Fig. 2-5. The feeding capacity is 6 liters/min. (12.7 U.S. pints/min., 10.6 Imp. pints/min.) at 1,000 rpm of engine speed.

2-B-1. Disassembling Oil Pump

1. Remove the oil pump from the front housing.
2. Remove the snap ring from the shaft, and remove the rear rotors and key.
3. Remove the middle plate attaching screw and remove the middle plate.
4. Remove the front rotors and key from the shaft.

2-B-2. Inspecting Oil Pump

1. Check the clearance between the lobes of the rotors with a feeler gauge, as shown in Fig. 2-3. The standard clearance is 0.01 ~ 0.09 mm (0.0004 ~ 0.0035 in). If the clearance exceeds 0.15 mm (0.006



Fig. 2-3 Checking rotor clearance

in), replace both inner rotor and outer rotor. 2. Check the clearance between the outer rotor and pump body with a feeler gauge as shown in Fig. 2-4. The specified clearance is 0.20 ~ 0.25 mm (0.008 ~ 0.01 in). If the clearance is more than 0.30 mm



Fig. 2-2 Removing oil pump



Fig. 2-4 Checking outer rotor clearance




Fig. 2-5 Oil pump components

1. Oil pump driven sprocket
2. Oil pump chain
3. Pump body
4. Shaft
5. Keys
6. Outer rotor
7. Inner rotor
8. Middle plate
9. Snap ring
10. Slipper head
11. Spring
12. Body

(0.012 in), replace the rotor(s) or body.

3. Check the end float of the rotors. Place a straight edge across the pump body and measure the clearance between the rotor and straight edge with a feeler gauge. The standard end float is 0.03 ~ 0.13 mm (0.001 ~ 0.005 in). If the total end float exceeds 0.15 mm (0.006 in), correct the pump body or replace both rotors.




Fig. 2-6 Checking end float

2-B-3. Assembling Oil Pump

1. Attach the key of the front side rotor to the shaft.
2. Install the front side inner rotor to the shaft so as to align the key groove of the inner rotor with the key on the shaft.
3. Mount the inner rotor and shaft assembly to the




Fig. 2-7 Installing rotors




Fig. 2-8 Tightening intermediate plate

pump body.

4. Install the outer rotor to the body so as to see the identification marks of triangle. Apply oil to the rotors. (Fig. 2-7)
5. Install the middle plate to the body. Tighten the set screw. (Fig. 2-8)
6. Attach the key of the rear side rotor to the shaft.
7. Install the rear side inner rotor and outer rotor.
8. Fit the snap ring on the shaft. Apply oil to the rotors.



Fig. 2-9 Fitting snap ring

9. Mount the oil pump assembly on the front housing and fix it with the bolts. Rotate the shaft by hand to see whether it rotates smoothly.

2-C. OIL PUMP DRIVING

2-C-1. Chain Adjuster Inspection

1. Check the amount of protrusion of the chain adjuster, as shown in Fig. 2-10. If the protrusion exceeds 12 mm (0.47 in), replace the adjuster or chain.
2. Check the rubber on the contacting surface of the chain adjuster for wear or damage and spring for weakness. If necessary, replace the chain adjuster.




Fig. 2-10 Checking chain adjuster

2-C-2. Oil Pump Chain and Sprocket Inspection

1. Check the chain for broken links.
2. Check the sprockets for cracks and worn or damaged teeth. If any defects are found, replace with new parts.

2-D. PRESSURE CONTROL VALVE

The pressure control valve mounted on the front cover sends the surplus oil back to the oil pan when the pressure exceeds 11 kg/cm^2 (156 lb/in^2) in order to prevent the oil cooler and the oil hose from damage by the exceeding pressure which is generated at the starting in the very cold weather.




Fig. 2-11 Pressure control valve

2-D-1. Checking Pressure Control Valve

Remove the cap of the pressure control valve from the front cover.

Examine the spring and the plunger for corrosion or any damage. If it is severe, replace with new ones. Measure the free length and replace with new spring if it is not in the specifications.

2-E. OIL COOLER

The rotor is cooled by the lubricating oil, and the oil cooler is employed to cool the oil. The oil cooler is of the corrugated fin type like a water radiator and is mounted under the radiator through insulation rubber. The oil cooler is made of aluminum which has outstanding cooling efficiency.

2-E-1. Repairing Oil Cooler

The inner pressure of the oil cooler is much higher than the cooling radiator, so it should be repaired by




Fig. 2-12 Oil cooler

aluminum welding when damaged.

2-F. BY-PASS VALVE

The by-pass valve is installed on the oil cooler in order to prevent drop of oil supply which is caused by the resistance of the oil cooler in the cold weather and regulate the temperature of the oil circulating in the engine. The oil is sent directly to the engine without passing through the oil cooler when the difference of the oil pressure of inlet and outlet pipes is more than 3.56 kg/cm^2 (50.7 lb/in^2) at 70°C (158°F) and/or the temperature of the oil is under 60°C (140°F).




Fig. 2-13 By-pass valve




Fig. 2-14 By-pass valve

2-F-1. Checking By-pass Valve

1. Remove the cap nut and pull out the by-pass valve.

2. Soak the by-pass valve in hot oil of 75°C \sim 80°C (167°F \sim 176°C). If the protrusion of piston is more than 5 mm (0.2 in), the by-pass valve is normal. (Fig. 2-15)




Fig. 2-15 Checking by-pass valve

3. Check the spring and the valve for corrosion or any damage. If it is severe, replace with new ones.

2-G. PRESSURE REGULATOR

The pressure regulator is provided on the rear housing. When the engine revolution becomes high and excessive oil pressure develops in the system, the pressure regulator opens to relieve the pressure and to send the excess oil to the oil pan. Thus, the oil pressure is maintained within the maximum pressure of 5 kg/cm^2 (71.1 lb/in^2).




Fig. 2-16 Pressure regulator

- | | |
|-------------------|-----------|
| 1. Lock nut | 4. Spring |
| 2. Regulator body | 5. Plug |
| 3. Plunger | |

2-G-1. Checking Pressure Regulator

Remove the cap or regulator assembly from the rear housing.

Check the spring and the plunger for corrosion or any damage. If it is severe, replace with new ones. Measure the free length and replace with new spring if it is not in specifications.

2-G-2. Checking Oil Pressure

To check the oil pressure, proceed as follows :

1. Warm up the engine to the normal operating temperature and remove the oil pressure switch and install an oil pressure gauge (49 0187 280) in its place.




Fig. 2-17 Checking oil pressure

2. Run the engine at **3,000 rpm** and take a reading of the gauge. If the reading of the gauge is 5.0 kg/cm^2 (71.1 lb/in^2), the oil pressure is normal.

3. Run the engine at idling speed and take a reading of the gauge. If the reading of the gauge is 2.5 kg/cm^2 (35.6 lb/in^2), the idling pressure is normal.

If the oil pressure is extremely low, check the following points :

1. Ensure that the oil level is between the "F" and "L" marks of the dipstick gauge.
2. Check the oil pump, as described in Par. 2-B-2.
3. Check the pressure regulator for wear on the plunger and fatigue on the spring. The free length of the spring is 46.4 mm (1.827 in).

2-H. OIL PRESSURE SWITCH

The oil pressure switch fitted to the rear housing is connected by the wiring to the oil pressure warning lamp. The safe minimum pressure is 0.3 kg/cm^2 (4.3 lb/in^2) at idle. If the oil pressure drops below 0.3 kg/cm^2 (4.3 lb/in^2) the warning lamp lights up to indicate a trouble in the lubricating system. Therefore, when the warning lamp goes on, the oil pressure should be checked immediately.



Fig. 2-18 Oil pressure switch

2-I. OIL FILTER

The oil filter is of a cartridge type. The element of the filter is sealed in the container as a unit. The oil filter is provided with a relief valve. If the

oil filter is clogged by impurities in the oil and the filtering resistance reaches 1.0 kg/cm^2 (14.2 lb/in^2), the oil can not pass through the element. In this case, the oil pushes the relief valve open and unfiltered oil is supplied to the engine. The oil filter should be replaced every 12,000 km (8,000 miles).

2-1-1. Replacing Oil Filter

1. Remove the oil filter cartridge with a suitable oil filter wrench.



Fig. 2-19 Removing oil filter

2. Apply oil onto the rubber gasket on the new filter cartridge.

3. Place the cartridge on the cover and screw in until it just touches the cover.

4. Tighten the cartridge further 2/3 turn but absolutely no more.

Do not use the oil filter wrench.

5. Start the engine and check to see that the oil is not leaking from the joints. Top up with oil if necessary.

2-J. METERING OIL PUMP

The oil enters the metering oil pump from the lubricating oil passage in the front cover and the oil which is measured and discharged from the metering oil pump enters the carburetor through a hose. The oil entering the carburetor is discharged from a portion of venturi to the working chamber to lubricate



Fig. 2-20 Metering oil pump

the gas seals. The plunger type metering oil pump is provided to send the proper amount of oil to the carburetor and is driven by the distributor drive gear.

2-J-1. Checking Metering Oil Pump

As sufficient consideration is being given on the performance and durability of the metering oil pump in its production process, generally there is no need of adjustment.

But as previously mentioned, the metering oil pump is the heart of the operation of the gas seals and insufficient amount of oil discharge could cause troubles such as drop in engine power and development of noise, because of insufficient lubrication, while excessive amount of oil discharge could cause problems as white smoke.

Therefore, the amount of oil discharge should always be within the proper range.

In case the engine tends to show any of the above troubles, the amount of oil discharge should be checked, proceeding as follows.

1. Disconnect the connecting rod by removing the cotter pin.

2. Disconnect the 2 metering oil hoses from the carburetor.

3. Install the tachodwell tester and set the engine at a constant speed of 2,000 rpm. Wait until the oil discharge from the end of the metering oil hoses becomes steady and, when it is steady receive the oil in the measuring cylinder and start measuring the time simultaneously.

4. Stop the engine after 6 minutes and check the amount of oil discharge. If it is within the proper range shown below, the discharge is satisfactory. Otherwise, adjust the oil metering pump.

2.2 cc / 6 min. / 2,000 rpm

Note : As lubricating oil is not being supplied to the gas seals while the measurements are being taken, a proper amount of clean engine oil should be added into the carburetor or the engine should be run on mixed gasoline into which oil has been mixed at the ratio of 100 : 1.




Fig. 2-21 Checking oil discharge

2-J-2. Adjusting Metering Oil Pump

If the amount of oil discharge measured by the procedure shown in the previous paragraph is not proper it would be adjusted by the adjusting screw.




Fig. 2-22 Adjusting screw of metering oil pump

The amount of oil discharge increases when the adjusting screw is tightened, and decreases when loosened. As the amount of oil discharge changes by $0.2 \sim 0.3$ cc/6 min./2,000 rpm per rotation of the screw, adjust the screw after calculating the number of rotations necessary to obtain the proper adjustment.

Also check to ensure that the lock nut of the adjusting screw will lock without fail and be sure not to bend the lever when adjusting. After adjustment has been completed, measure the amount of oil discharge again and make sure that it is within the proper range.

In case the metering oil pump cannot be adjusted, it should be replaced as a damaged parts or a pump assembly.

Connecting rod setting

Set the clearance of connecting rod stopper pin and metering oil pump lever to $0 \sim 1.0$ mm ($0 \sim 0.04$ in) by using a suitable washer.




Fig. 2-23 Connecting rod setting

2-J-3. Disassembling Metering Oil Pump

1. Remove the control lever, return spring and cap by loosening the nut.

2. Remove the front plate carefully as it is the spring-

loaded, and remove the sub plunger, plunger spring and oil seal ring.

3. Remove the rear plate and oil seal ring.

4. Push in the plunger slightly from the rear plate side by using a small screw driver and pull the control pin out from the pump body.

5. Pull the driving worm with the worm bearing out from the pump body by using a plier and remove the thrust plate.

6. Push out the plunger and differential plunger from rear side to front side.

2-J-4. Assembling Metering Oil Pump

Wash all the parts in clean kerosene before reassembling them. As the pump has a highly delicate mechanism, the greatest possible care should be taken in reassembling the pump not to admit any foreign matter in it and not to cause any small scar.

1. Apply the clean oil in the cylinder. Slide the plunger into the body from front side of the body and then slide the differential plunger into the body until the gear of the plunger reaches the position of the hole for the driving worm.




Fig. 2-24 Assembling plunger

Note :

Make sure that the slot of the differential plunger matches the key of the plunger.

2. Carefully insert the thrust plate, driving worm and worm bearing.



Fig. 2-25 Assembling drive worm




Fig. 2-26
Metering oil pump component

1. Worm bearing
2. Driving worm
3. Plunger
4. Rear plate
5. Control pin
6. Control lever
7. Body
8. Differential plunger
9. Sub plunger
10. Front plate

3. Insert the control pin.



Fig. 2-27 Inserting control pin

6. Insert the plunger spring and sub plunger from the front side of the body.




Fig. 2-29 Inserting sub plunger

4. Place the oil seal ring on the groove.
5. Fit the rear plate on the body making sure the stopper for the control pin facing the control lever.




Fig. 2-28 Fitting rear plate

7. Place the oil seal ring on the groove and fit the front plate.
8. Install the spring, control lever and connectors.




Fig. 2-30 Installing control lever

2-K. CHECK VALVE

The check valve operates to prevent oil from flowing back into the metering oil pump. Confirm the tapered shoulder of the check valve before installing it so that the direction of the check valve will not be mistaken for upside down. It should face to the metering oil pump.




Fig. 2-31 Direction of check valve

2-L. OIL PAN

2-L-1. Oil Pan Removal

1. Raise the vehicle and support with stands.
2. Drain the engine lubricant.
3. Remove the bolts attaching the engine under cover, and remove the engine under cover.
4. Remove the bolts attaching the oil pan, and remove the oil pan and gasket.

2-L-2. Oil Pan Inspection

Scrape off any dirt or metal particles from the inside of the oil pan. Wash the oil pan in a solvent and dry it with compressed air. Check the oil pan for any cracks and damaged drain plug threads. Inspect for damage (uneven surface) at the bolt holes caused by over-torquing the bolts. Straighten surfaces as required. Repair any damage, or replace the oil pan if repairs can not be made satisfactorily.

SPECIAL TOOL

49 0187 280	Oil pressure gauge
-------------	--------------------



Fig. 2-32 Installing oil pressure gauge

Fig. 2-33 Installing control pin



The cooling system consists of a compressor (in type radiator with pressure cap expansion tank) vented to the atmosphere. The radiator is connected to the engine by hoses. The expansion tank is connected to the radiator. The cooling system should be checked every two years or 48,000 miles (77,000 km).

3-B. FLUSHING OF COOLING SYSTEM

The cooling system should be flushed every two years or 48,000 miles (77,000 km). The flushing procedure is as follows: Open the drain plug and drain the coolant. Flush the system with clean soft water.

COOLING SYSTEM



DESCRIPTION	3 : 1
3-A. COOLANT CIRCULATION	3 : 1
3-B. FLUSHING OF COOLING SYSTEM	3 : 1
3-C. COOLANT	3 : 2
3-C-1. Checking Coolant Leakage	3 : 2
3-D. RADIATOR	3 : 2
3-D-1. Checking Radiator	3 : 2
3-D-2. Repairing Radiator	3 : 2
3-D-3. Radiator pressure cap	3 : 2
3-E. FAN DRIVE	3 : 2
3-E-1. Checking Fan Drive	3 : 2
3-F. THERMOSTAT	3 : 3
3-F-1. Removing Thermostat	3 : 3
3-F-2. Inspecting Thermostat	3 : 3
3-G. WATER PUMP	3 : 4
3-G-1. Inspecting Water Pump	3 : 4
3-G-2. Removing Water Pump	3 : 4
3-G-3. Disassembling Water Pump	3 : 5
3-G-4. Assembling Water Pump	3 : 5
SPECIAL TOOL	3 : 5




Fig. 3-1 Cooling System

DESCRIPTION

The cooling system consists of a corrugated fin type radiator with pressure cap, expansion tank, centrifugal water pump, wax pellet type thermostat, and a eight-blade fan.

The radiator and the expansion tank are connected by hose. When engine is overheated, the coolant in the radiator flows out and led into the expansion tank through the hose. The coolant is then returned to the radiator by negative pressure which builds up in the cooling system when the engine cools down. The coolant should be changed every two years or every 48,000 km (30,000 miles).

3-A. COOLANT CIRCULATION

The water pump is driven by the eccentric shaft pulley over a V-belt and discharges the cooling water to the front housing. The water circulates from the front housing through the water passage provided in each housing and flows to the rear housing. From the rear housing, the water is returned to the front housing. At low engine temperature, the thermostat is closed to keep the water from entering the radiator. The water is then recirculated directly to the water pump and discharged to each housing. As the thermostat opens when the engine is warmed up, the water flows into the radiator. The cooled water flows from the radiator to the water pump through the connecting

hose and cools the engine by circulation.

3-B. FLUSHING OF COOLING SYSTEM

The cooling system should be flushed every two years or 48,000 km (30,000 miles).

The flushing procedures are as follows:

1. Open the drain plugs and drain the coolant.
2. Close the drain plugs and supply clean soft water.



Fig. 3-2 Radiator drain plug

Note:

If necessary, use cleaning solution to loosen rust and scale, by following the instructions given by the maker of the cleaning solution.




Fig. 3-1 Cooling circuit




Fig. 3-3 Engine drain plug

3. Run the engine for about one hour, at the normal operating temperature.
4. Drain the water completely.
5. Fill with soft water (demineralized water) and genuine long life coolant, referring to Par. 3-C.

3-C. MAZDA GENUINE LONG LIFE COOLANT

MAZDA genuine long life coolant (Part No. 0880 77 264) is used in the cooling system of MAZDA ROTARY PICKUP. This coolant includes the anti-freeze solution and anti-corrosive solution. The mixing rate of water and genuine long life coolant is shown in the following table.

Freezing point	Mixture ratio %		Specific gravity of mixture at 20°C (68°F)
	Coolant	Water	
-20°C (-4°F)	35	65	1.051
-45°C (-49°F)	55	45	1.078

Note:

- (a) Always use soft water (demineralized water) in the cooling system.
- (b) If the MAZDA genuine long life solution is not available, use anti-freeze solution (for aluminum engine, Ethylene-Glycol based) or anti-corrosive solution on the market in accordance with the season and the maker's instructions.

3-C-1. Checking Coolant Leakage

Carefully check the various parts for any leakage of cooling water by using a radiator cap tester. Refill the coolant full in the radiator and between the "FULL" and "LOW" marks on the expansion tank. Run the engine until it reaches normal operating temperature. With the engine running and tester installed, pump up the system to approximately 0.9 kg/cm² (13 lb/in²).

Note: Never allow the pressure to build up to more than 1.1 kg/cm² (14 lb/in²).

If pressure drops rapidly, visually inspect all external parts for leaks. If no external leaks appear and pressure continues to drop, inspect the engine oil to

determine whether or not coolant is leaking into the rotor housing due to a cracked rotor housing or leaking "O" rings.

3-D. RADIATOR

The radiator is of the corrugated fin type with a pressure cap.

3-D-1. Checking Radiator

Carefully check the radiator for water leakage. (Refer to Par. 3-C-1.) A clogged radiator badly influences the cooling effect and should be cleaned with the compressed air.

3-D-2. Repairing Radiator

The radiator used on this model is made of copper. Any minor leakage must be completely eliminated by soldering.

3-D-3. Radiator Pressure Cap

The radiator has a pressure cap. The pressure increases the boiling point of the coolant and prevents over heating and reduces overflow losses.

When the pressure in the radiator exceeds 0.9 kg/cm² (13 lb/in²), the pressure valve opens. A vacuum release valve is employed to prevent undesirable vacuum build-up when the system cools down.

Note:

To remove the radiator pressure cap when the coolant temperature is high or boiling, place a cloth on the pressure cap and turn counter-clockwise one step. Keep it in this position until all pressure is released. Then, turn the cap further until it can be removed. To install the cap, place in position and turn it clockwise as far as it will go.

3-E. FAN DRIVE

As shown in Fig. 3-4, the fan drive is driven with the water pump pulley, and by the work of the silicon oil in the body, prevents the fan from marking more than a certain number of rotations.

As may be seen from this structure, the number of fan rotations will presumably drop if a defect, such as oil leakage, should occur on the fan drive.

If an engine has the tendency to overheat, the number of fan rotations should be checked in the following manner.

3-E-1. Checking Fan Drive

Testers to be used: Photoelectric revolution counter and tachodwell tester.

1. Apply scotch tape to the positions on the fan as shown in Fig. 3-4.
2. Set the tachodwell tester to the engine. Then start the engine and run it at 1,500 rpm.
3. Then turn the photoelectric revolution counter




Fig. 3-4 Fan drive

toward the fan and read the speed of the fan rotation. The fan speed should be within the standards shown in the following table.

Prescribed Revolution	
Engine	Fan
1,500 rpm	1,400 rpm or more
5,000 rpm	2,000 rpm ~ 2,500 rpm

If the reading is below the standard, replace the fan drive assembly.

If the reading is more than the standard—Make a recheck in the following manner.

4. When the reading exceeds the standard, warm up the engine for five minutes at engine speed of more than 3,000 rpm, and then read the speed of the fan rotation at engine speed of 5,000 rpm. If the speed of the fan rotation is within the standard shown in the above table, the operation of the fan drive is satisfactory.

3-F. THERMOSTAT

To regulate the temperature of the cooling water circulating in the engine, a wax type thermostat is adopted. The thermostat is of a bottom by-pass type, which has outstanding cooling efficiency, and is different from the conventional in-line type thermostat in the undermentioned points. Therefore, it should be handled with particular care.

As shown in Fig. 3-5, a by-pass hole is provided at the bottom of the thermostat. The by-pass hole on the bottom by-pass type thermostat is larger than that on the in-line type. The bottom by-pass type thermostat, therefore, has the following advantages: when the thermostat is fully closed, a large amount of cooling water circulates, thus preventing any local rise in the cooling water tem-




Fig. 3-5 Thermostat and by-pass hole



Fig. 3-6 Thermostat

perature, and, when the thermostat is fully opened, the valve of the thermostat closes the by-pass hole and so all of the cooling water flows into the radiator, making effective use of the radiator. But, if the thermostat is removed, a large amount of cooling water flows through the by-pass hole because the hole is large, and so the amount of cooling water flowing into the radiator decreases to half, causing the cooling water temperature to rise.

Therefore, the thermostat should never be removed and no other type of thermostat should be used.

3-F-1. Removing Thermostat

1. Drain the cooling system.
2. Remove the bolts attaching the thermostat cover to the water pump and remove the cover.
3. Lift out the thermostat.

3-F-2. Inspecting Thermostat

To inspect the thermostat, place it in water with a thermometer and gradually heat the water.

Check the temperature when the thermostat starts to open and when it is fully opened, and also, measure the lift height when the thermostat is fully opened. If the reading shows a large difference from the standard specifications, replace the thermostat. The specifications of the thermostat are shown in the following table:

Starts to open	82°C (180°F)
Fully opens	95°C (203°F)
Lift height	8 mm (0.31 in)




Fig. 3-7 Checking thermostat

3-G. WATER PUMP


The water pump employs a centrifugal impeller. In the pump body, the shaft is supported by two bearings. The impeller is fitted to the rear end of the shaft. The seal assembly prevents water leakage.

3-G-1. Inspecting Water Pump

Check the water pump for leaks and excessive end play or looseness of the shaft and bearings. If there is evidence of excessive play when the pulley is manually moved up and down, this indicates that the bearings are rough. If water leaks from the hole located on the body, this is an indication of a defective seal necessitating overhaul of the pump and check of the seal and seat surface. If defective, replace the seal assembly.

Fig. 3-10
Water pump components

1. Pulley boss
2. Dust seal plate
3. Snap ring
4. Bearing
5. Spacer
6. Stop ring
7. Shaft
8. Dust seal
9. Baffle plate
10. Pump body
11. Seal assembly
12. Impeller



3-G-2. Removing Water Pump

1. Drain the cooling system.
2. Remove the air cleaner.
3. Remove the bolts attaching back of the fan drive and remove the fan drive assembly;



Fig. 3-8 Removing fan drive

4. Loosen the bolts attaching the water pump pulley to the water pump boss if it is necessary to disassemble the water pump.
5. Remove the air pump and disengage the air pump




Fig. 3-9 Pump body attaching bolts

drive V-belt.

6. Remove the alternator and disengage the V-belt.
7. Remove the water pump pulley attaching bolts and remove the pulley if necessary.
8. Remove the nuts and bolts attaching the water pump body and remove the pump body. In case the water pump is removed assembly, only four nuts will be removed.

3-G-3. Disassembling Water Pump

1. Using the **pulley boss support** (Part No. 49 0813 145A), press the shaft slowly, and remove the pulley boss and dust seal plate.




Fig. 3-11 Removing pulley boss

2. Remove the snap ring retaining the shaft and bearing assembly in the pump body.
3. Place the front side of the pump body on the **support** (Part No. 49 0813 145A) and apply pressure to the rear end of the shaft to press the shaft and remove the impeller from the shaft. Then press the shaft and bearing assembly out of the pump body.
4. Remove the seal assembly from the pump body.
5. Slide the baffle plate and dust seal plate off the shaft.
6. Remove the bearing stop ring from the shaft.
7. Remove the bearings and spacer from the shaft.



Fig. 3-12 Removing impeller

3-G-4. Assembling Water Pump

1. Fit the bearing stop ring onto the groove of the shaft.
2. Slide the dust seal plate onto the shaft.
3. Slide the baffle plate onto the taper of the shaft.
4. Press fit the bearing onto the shaft with sealed side rearward.




Fig. 3-13 Assembling impeller

5. Press the shaft and bearing into the pump body.
6. Slide the spacer onto the shaft and **fill 1/3 of the space** between the two bearings with grease.
7. Press fit the bearing onto the shaft with the sealed side forward until the snap ring can be installed.
8. Install the snap ring onto the groove of the pump body to retain the shaft and bearing assembly in position.
9. Slide the dust seal plate onto the shaft, and press the pulley boss onto the shaft until it is flush with the front end of the shaft.
10. Apply lubricant onto the seal assembly and install the seal assembly into the pump body.
11. Press the impeller onto the shaft until it is flush with the end of the shaft.




Fig. 3-14 Assembling pulley


SPECIAL TOOL

49 0813 145A

Water pump pulley boss support

FUEL SYSTEM

FUEL SYSTEM	4 : 1
4-A. CARBURETOR	4 : 1
4-A-1. Idle Adjustment	4 : 2
4-A-2. Fast Idle Adjustment	4 : 3
4-A-3. Float Adjustment	4 : 3
4-A-4. Automatic Choke System (Semi-auto)	4 : 4
4-A-5. Automatic Choke System (Full-auto)	4 : 5
4-A-6. Accelerator Pump	4 : 5
4-A-7. Fuel Inlet Fitting	4 : 7
4-A-8. Sub-Zero Starting Assist Device	4 : 7
4-A-9. Safety Throttle Return System	4 : 8
4-A-10. Disassembling Carburetor	4 : 9
4-A-11. Inspecting Carburetor	4 : 11
4-A-12. Carburetor Assembly	4 : 11
4-B. FUEL PUMP	4 : 12
4-C. FUEL FILTER	4 : 12
4-D. FUEL LINES	4 : 12
4-E. FUEL TANK	4 : 12
4-F. AIR CLEANER	4 : 12
4-F-1. Air Cleaner Element	4 : 12
4-F-2. Intake Air Temperature Control System	4 : 13



The fuel system consists of the carburetor, fuel pump, fuel filter, fuel lines, fuel tank, and air cleaner. The carburetor is the device that mixes the fuel and air in the proper proportions for combustion. The fuel pump draws fuel from the tank and sends it to the carburetor. The fuel filter removes any dirt or debris that might clog the fuel lines. The fuel lines carry the fuel from the tank to the carburetor. The fuel tank stores the fuel until it is needed. The air cleaner filters the air that enters the engine, preventing dirt and debris from entering the combustion chamber.

FUEL SYSTEM

The fuel system consists of the carburetor, fuel pump, fuel filter, fuel tank, fuel line, accelerator linkage and air cleaner.

By the suction of the fuel pump, the fuel flows through the fuel line into the fuel filter. The fuel passes through the filter element from the outside to the inside of the element. During this fuel flow, the filter element cleans out all the dirt. The fuel pump is producing a constant controlled pressure, and the fuel volume required for engine operations. The fuel supplied by the fuel pump flows passing through the fuel hose into the carburetor.

The carburetor mixes the air and fuel in varying proportions for different operating conditions. As the air passes through the carburetor before entering the engine, fuel is supplied into the engine through the various circuits of the carburetor.

The air cleaner operates primarily to remove dust and dirt from the air which is drawn into the carburetor and then into the engine.

4-A. CARBURETOR

MAZDA ROTARY PICKUP makes use of a two-stage, four-barrel, down-draft carburetor.

This carburetor comprises two sets each of primary barrels and secondary barrels.

The primary stage includes an idle system, slow system, accelerator pump system, choke system, and main metering system. In addition, an idle switch for exhaust emission control system is attached to primary throttle shaft. The fluid of sub-zero starting assist device and the oil from the metering oil pump are admitted from primary stage barrels to combustion chamber.

The altitude compensator takes the air from primary stage barrels and controls the air supply to the intake manifold at low atmospheric pressure such as high altitudes driving.

The secondary stage includes a secondary operating diaphragm system, step system and main metering system. Choking action is accomplished by means of a semi-automatic choke or full automatic choke.




Fig. 4-1 Carburetor

- | | | |
|-------------------------------------|------------------------------------|--|
| 1. Primary stage | 10. Safety return spring | 19. Air adjust screw (for idle adjustment) |
| 2. Secondary stage | 11. Throttle return spring | 20. To distributor vacuum control diaphragm |
| 3. Primary air vent | 12. Fast idle connecting rod | 21. From metering oil pump |
| 4. Choke valve | 13. Fuel bowl sight glass | 22. From sub-zero starting assist fluid tank |
| 5. Secondary air vent | 14. Throttle lever | 23. Accelerator pump lever |
| 6. Fuel inlet fitting (return side) | 15. Choke lever | 24. Accelerator pump piston |
| 7. Fuel inlet fitting (inlet side) | 16. Throttle adjust screw (locked) | 25. Lead wire of bimetal |
| 8. Bimetal spring housing | 17. To altitude compensator | |
| 9. Vacuum break diaphragm | 18. Idle adjust screw (locked) | |

4-A-1. Idle Adjustment

a. Normal adjustment

1. Fully warm up the engine.
2. Make sure that the return of the secondary throttle valve is proper.
3. Adjust the idling speed so that the engine revolution will be in specifications by manipulating the air adjust screw. **Never meddle with the idle adjust screw and throttle adjust screw.**




Fig. 4-2 Idle adjustment

Note :

To measure the engine revolution, be sure to use a revolution counter intended for general servicing instead of the tachometer equipped on the vehicle.

Specifications – Idling Speed :

Car with Manual Transmission	900 rpm
Car with Automatic Transmission	750 rpm in "D" range

b. Particular adjustment

Idle adjust screw and throttle adjust screw are adjusted by the manufacturer. These screws should not be adjusted. However, if the idle adjust screw and/or throttle adjust screw get out of order for some reason, or after overhauling the carburetor, adjust them in the following procedures.

b-1:

1. Adjust throttle opening to specifications from fully closed position by the throttle adjust screw. Lock the screw lock nut firmly after adjustment.
2. Start the engine and adjust the idling speed to the specified value by the air adjust screw.

Specifications – Idling fuel adjustment :

	Throttle opening angle	Idling fuel flow	Time required to consume 50 cc
Car with Manual Transmission	2 ± 0.5 degrees	2.2 ~ 2.4 liters/h (0.57 ~ 0.62 U.S. gallons/h)	75 sec ~ 82 sec/50 cc
Car with Automatic Transmission	2 ± 0.5 degrees	2.25 ~ 2.45 liters/h (0.59 ~ 0.63 U.S. gallons/h)	73 sec ~ 80 sec/50 cc

3. Set the idle CO, HC gas analyzer.
4. Adjust the idle CO gas reading as close to 0.1% as possible by the idle adjust screw. The idle HC reading must be less than 200 ppm.
5. Recheck or readjust the engine idle speed and CO, HC readings until they meet their respective specifications.

Note:

The gas analyzer should be adopted for checking purpose only, and no adjustment is needed if CO reading is within 0.1% ~ 2.0% and HC reading is less than 200 ppm.

b-2.

It is better for the idle adjustment to use the fuel flow checker (49 2113 015) than to use the gas analyzer. The adjustment by the fuel flow checker should be done as follows.

1. Adjust throttle opening angle to specifications from fully closed position by the throttle adjust screw. Lock the screw lock nut firmly after adjustment.
2. Set the fuel flow checker (49 2113 015) as shown in Fig. 4-3.
3. Start the engine and adjust the idling speed approximately to specifications by the air adjust screw.
4. Adjust the idle fuel flow to specifications by the idle adjust screw.
5. Adjust the idle speed to specifications by the air adjust screw.
6. Recheck the idle fuel flow and the idle speed.




Fig. 4-3 Fuel flow check

4-A-2. Fast Idle Adjustment

1. With the choke knob or choke lever, fully pulled out, measure the primary throttle opening angle (A) or the clearance (B) between the primary throttle valve and the wall of the throttle bore when the carburetor is disassembled.

Note :
To measure the angle (A), install a protractor to the primary throttle shaft centering correctly.
To measure the clearance (B), use a suitable wire gauge or drill.

2. If the clearance isnnot within specifications, adjust the fast idle by bending the connecting rod.




Fig. 4-4 Fast idle




Fig. 4-5 Adjusting fast idle

- 1. Pulled by choke wire
- 2. Link
- 3. Choke shaft lever
- 4. Choke lever
- 5. Fast idle rod (Bend this rod for adjustment)
- 6. Fast idle lever
- 7. Throttle lever

Specifications – Fast Idle Adjustment :

	Throttle valve opening angle (A)	Clearance between throttle valve and bore (B)
Car with Manual Transmission	14.0 ~ 17.0 degrees	1.01 ~ 1.33 mm (0.0398 ~ 0.0524 in)
Car with Automatic Transmission	16.0 ~ 19.0 degrees	1.22 ~ 1.57 mm (0.0480 ~ 0.0618 in)

4-A-3. Float Adjustment

a. Float level adjustment

1. With engine operating, check the fuel levels in the fuel bowl through the sight glasses using a suitable mirror.




Fig. 4-6 Fuel bowl sight glass

2. If the fuel levels are not within the specified mark in the sight glasses, remove the air horn with the floats. Then adjust the float level as follows.

3. Invert the air horn on a stand, lift the float and let it down quietly until the float seat lip just touches the needle valve. By keeping this position, take measurement of clearance (H) between the float and the face of air horn gasket. Standard of this clearance (H) is 11 mm (0.43 in).




Fig. 4-7 Checking float level

4. If the clearance is not within specification, adjust the clearance (H) by bending the float seat lip (A) shown in Fig. 4-9.

5. Install the air horn and recheck the fuel levels through the sight glasses.

b. Float drop adjustment

Allow the float to lower by its own weight, and measure the distance between the bottom of float and the face of air horn gasket. The distance should be 52 ± 0.5 mm (2.05 ± 0.02 in). (Fig. 4-8)




Fig. 4-8 Checking float drop

If the distance is not within specifications, adjust it by bending the float stopper (B) shown in Fig. 4-9.




Fig. 4-9 Adjusting float
A. Float seat lip
B. Float stopper

4-A-4. Automatic Choke System (Semi-auto)

The carburetor for this model is equipped with a semi-automatic choke system.

The semi-automatic choke control is accurately adjusted when originally assembled. Under normal service operations, it is recommended not to change the setting or to disassemble the components for servicing. However, if the setting has been disturbed, adjust it in the following procedures.

The bimetal spring should be adjusted before engine starting. In the case of adjustment that is made after the engine warmed-up, it can not obtain a correct adjustment because the ambient temperature is different from the atmospheric temperature.

a. Vacuum break diaphragm adjustment

Push the diaphragm plunger in until seated and check the stroke of it. This stroke should be in the following specifications.




Fig. 4-10 Adjusting diaphragm stroke




Fig. 4-11 Automatic choke system

Specifications — Diaphragm stroke

Manual transmission	7.0 ~ 7.2 mm (0.276 ~ 0.283 in)
Automatic transmission	5.9 ~ 6.1 mm (0.232 ~ 0.240 in)

b. Bimetal spring adjustment

1. Fully pull out the choke knob or choke lever and keep its position by wire.
2. Push the vacuum break diaphragm plunger in fully and keep its position by wire as shown in Fig. 4-12.




Fig. 4-12 Bimetal spring adjustment

3. Check the choke valve opening angle.
4. If the setting has been out of order, adjust the choke opening angle following Fig. 4-13.




Fig. 4-13 Choke valve opening angle

c. Automatic choke return system

The automatic choke return system is adopted on this model in order to prevent the choke knob from failing to be returned.

This system, as shown in Fig. 4-11, consists of the choke wire attached with an electromagnet and the water temperature detection switch. When the water temperature of engine is low, the choke knob can be held at an optional position because the water temperature switch is 'ON'. On the other hand, when the engine is warmed up, the detection switch becomes 'OFF', and the electromagnet loses its force. Then, the choke knob is returned by the choke return spring.

4-A-5. Automatic Choke System (Full-auto)

In the full automatic choke system, the operation of the choke wire which is essential in the usual semi-automatic system has been eliminated. The system provides a full automatic choke, which controls the opening and closing of the choke valve by the operation of the thermopellet through which the cooling water of the engine runs.

Outline of the Operation

When the engine is cold, the thermopellet is in the contracted condition. By the function of return spring (24), the choke valve is closed. As the temperature of water rises, the thermopellet begins to expand, thus pushing the choke valve in the direction of "open" through the medium of links (5), (6), camshaft (4), link (10), rod (11), and link (12). In the state where the engine is warmed up, the thermopellet remains in the expanded condition, and the choke valve is continuously pushed in the direction of "open". When the temperature of the cooling water begins to drop after the engine is stopped, the thermopellet begins to contract and the choke valve is closed again by the function of return spring (24).

Further, while the engine is cold, the thermopellet is in the contracted condition and by the function of return spring (24), rod (23) is pulled up. Through links (22) and (20), the throttle valve is opened to the degree of "fast idle". Once the engine is started, the choke valve and the throttle valve are compensated to the opening degree suitable for the warm-up. Then, under the negative pressure of the inlet manifold, the diaphragm is pulled. Thus, the throttle valve is compulsorily moved in the direction of "close" through link (20); and the choke valve, in the direction of "open" through rod (17) and link (12). At the same time diaphragm (15) is also drawn, and through bimetal shaft (16), the tensile force of bimetal spring (13) is weakened, which facilitates the opening of the choke valve.

4-A-6. Accelerator Pump

a. Normal checking

1. Remove the air cleaner.
2. Check the pump for discharge by moving the primary throttle valve.
3. Check the pump for nozzle's clogging. When the pump nozzle is clogged, remove the nozzle and clean up the nozzle.

b. Checking amount of accelerator pump discharge

Checking of accelerator pump discharge amount is as follows:

1. Place the vehicle on a level ground.
2. Set the burette at the fuel inlet of the carburetor and fill it with fuel.
3. Fully operate the throttle valve about five times and confirm the fuel discharged from the accelerating pump jet.




Fig. 4-14 Full automatic choke system

4. Set the fuel level in the burette at 300 mm (11.8 in) above the fuel inlet, as shown in Fig. 4-15.




Fig. 4-15 Checking fuel discharge

5. Fully operate the throttle valve ten times according to the cycle as shown in Fig. 4-16 by means of the throttle lever or accelerator pedal and check the amount of discharge by reading the decrease of fuel in the burette.




Fig. 4-16 Test pattern

6. If the discharged amount is not within specifications, check the accelerating pump piston and etc.

Specifications – Standard amount of fuel discharged out of accelerating pump

	Manual transmission	Automatic transmission
Standard	0.8 cc ± 15%/stroke	0.8cc ± 15%/stroke
Measurement	6.8 ~ 9.2 cc/10 strokes	6.8 ~ 9.2 cc/10 strokes

4-A-7. Fuel Inlet Fitting

The carburetor inlet fitting is provided with a fuel return device to prevent percolation. Whenever the key switch is on, a small amount of fuel which is led to the carburetor, returns to the fuel tank through the orifice of fuel return pipe.

Check the orifice for clog. When it is clogged, remove the fuel inlet fitting and clean it by compressed air.




Fig. 4-17 Fuel inlet fitting

4-A-8. Sub-Zero Starting Assist Device

This is the device for increasing the starting ability of the engine in extreme cold. When the ignition key is turned to the position of "start" under the circumstances where the temperature is below -18°C (0°F), a certain amount of starting assist fluid is supplied into the carburetor by a pump installed for supplying the starting assist fluid.

Check whether the device is operating normally or not by the following procedure.




Fig. 4-18 Starting assist fluid tank

1. Make sure that there is sufficient starting assist fluid in the tank. Replenish if necessary.
2. Disconnect the hose on the side of the carburetor.
3. Disconnect the lead line of (S) terminal connected to the starter magnetic switch. This is to prevent the engine from revolving when the ignition key is turned to "start".
4. Disconnect the connector of the lead line of the thermo-unit and connect the body with the earth.
5. Turn the ignition key to the position of "start" and make sure that the starting assist fluid sprouts out from the tip of a hose for about 5 seconds.
6. Make sure that the check valve fitted on the carburetor is in proper working condition by blowing through it with your mouth.
7. Reinstall the rubber hose and wires, which have been removed for the check-up to their proper positions.

Note :

- a. Check the level of the starting assist fluid at suitable intervals and replenish as required so that it will not run short.
- b. The mixture proportion of starting assist fluid should be 90% of anti-freeze solution for Aluminum engine plus 10% of water.




Fig. 4-19 Sub-zero starting assist system

4-A-9. Safety Throttle Return System

The safety throttle return system is adopted in order to prevent any possible danger from occurring when the accelerator return spring should become broken during operation and at that instant the accelerator should get out of control.

Under normal conditions, only spring **A** operates a return spring by pulling throttle lever **4** which is connected to the accelerator wire. Link **3** is fixed by rod **2** (whose upper end is fixed by counter **1**) and does not have any connection with the movement of link **4**. In case spring **A** should become broken, the upper end of rod **2** slips off of counter **1** by spring **B** and throttle lever **4** is pushed by the movement of link **3** instantaneously.

Compression spring **B** works as an accelerator return spring with the same force as when spring **A** is in operation. Consequently even if spring **A** should become broken during operation, no adverse effects will occur in the operation of the accelerator control.

Checking :

1. Check that the throttle valve opens completely with the safety return system in set position.
2. Turn the counter **1** by hand anticlockwise and make sure that the upper end of rod **2** slips off of counter **1** instantaneously.




Fig. 4-20 Safety throttle return system

- A. Throttle return spring
- B. Safety return spring
- 1. Counter
- 2. Safety return spring rod
- 3. Link
- 4. Throttle lever




Fig. 4-21 Safety throttle return system




Fig. 4-22




Fig. 4-23




Fig. 4-24

4-A-10. Disassembling Carburetor

a. Removing bimetal spring housing assembly

1. Disconnect the vacuum sensing tube ① led to the vacuum break diaphragm.
2. Remove the screws ② (don't remove the screw ③ attaching the bimetal spring housing ④ with diaphragm bracket ⑤ to the carburetor and remove the housing assembly ④).

b. Removing throttle return springs

1. Dislocate the safety return spring ⑥ by turning the counter lever ⑦ anticlockwise and remove the spring ⑥ from the spring stopper bracket ⑧.
2. Remove the throttle return spring ⑨ deliberately so as not to get hurt.
3. Remove the spring stopper bracket ⑧ and spring counter lever bracket ⑩ by removing the screws ⑪.

c. Removing air horn

1. Disconnect the fast idle connecting rod ⑫ by removing the cotter pin ⑬.
2. Remove the accelerating pump connecting rod ⑭ by removing the cotter pin ⑮.
3. Remove the bolt ⑯ attaching the inlet fitting ⑰ by box wrench or offset wrench (don't use a spanner – open end wrench), and remove the fitting ⑰ and filter. Remove the connector ⑱ if necessary.
4. Remove the screws ⑲ and the center bolt ⑳ attaching the air horn ㉑ to the body ㉒ and remove the air horn ㉑ being careful not to break the gasket.

d. Removing carburetor body

1. Remove the spring, retainer plate and check ball from the accelerator pump cylinder 23 of the body 22.
2. Remove the idle switch 24 by removing the screws 25 and spring 26.
3. Disconnect the connecting rod 27 of the secondary operating diaphragm 28 by removing the cotter pin 29 and remove the diaphragm 28 by removing the screws 29.
4. Remove the screws attaching the throttle body 30 to the carburetor body 22 and remove the body.




Fig. 4-25




Fig. 4-26

e. Disassembling air horn

1. Remove the float retaining pin 31, float 32 and needle valve 33.
2. Remove the accelerator pump lever 34 by removing the screw 35 and pull out the pump piston 36.
3. Remove the starting assist fluid inlet fitting 37.
4. Remove the slow air bleeds 38.




Fig. 4-27




Fig. 4-28

- 40. Primary venturi
- 41. Primary slow jet
- 42. Primary main air bleed
- 43. Secondary main air bleed
- 44. Secondary venturi
- 45. Secondary slow jet (Step jet) and air bleed
- 46. Plug
- 47. Primary main jet
- 48. Secondary main jet

f. Disassembling carburetor body

1. Remove the accelerator injection nozzle (39) from the body and remove the weight and ball.
2. Write down the numbers and positions of all jets and remove the all jets from the surface of the body.
3. Remove the main jets (47) (48) by removing the plugs (49) from the body.
4. Remove the air adjust screws (50).

g. Throttle chamber

1. Remove the idle adjust screw (51).




Fig. 4-29 Throttle chamber

6. Check the choke valve for proper choking, smooth movement and excessive play of choke shaft.
7. Check all jets and air bleeds for clog, damaged threads, damaged head slots and damaged holes.
8. Check the primary and secondary throttle valves if these close firmly or not, check them for smooth movement and excessive play of the shafts.
9. Check the diaphragm of vacuum control unit for damage. Check the spring for weakness.

4-A-12. Carburetor Assembly

To assemble, follow the disassembly procedures in the reverse order with the following cautions.

1. Discard the old gaskets and use new ones.
2. Confirm that all parts are in good condition and clean.
3. Both the primary and secondary systems have their respective parts which are of a shape. Therefore, when installing, care should be taken so as not to mistake one for the other.
4. When installing the bimetal spring housing to the carburetor, fit the choke shaft lever to the bimetal spring end accurately by means of closing the choke valve and pulling the vacuum break diaphragm shaft.

4-A-11. Inspecting Carburetor

1. Wash all parts in clean gasoline and dry with compressed air. All passages of the carburetor must be blown very carefully.
- Never use** a wire for cleaning the jets.
2. Inspect the air horn, body and body flange for cracks, nicks or burrs on their respective gasket surfaces.
3. Inspect the float for deformation, damaged tab and worn retaining pin bore.
4. Check the float needle valve for wear and for proper seating.
5. Inspect the filter for rust and damage.




Fig. 4-30 Installing bimetal spring housing

4-B. FUEL PUMP

To determine that the fuel pump is in satisfactory operating condition, tests for both fuel pump pressure and fuel pump capacity (volume) should be performed. The tests are performed with the pump installed on the car.

a. Pressure test

1. It is required that measurement should be performed while the engine is in cold condition, and make sure that there is no fire around.
2. Remove the aircleaner assembly. Disconnect the fuel inlet hose at the carburetor. Use care to prevent combustion due to fuel spillage.
3. Connect the pressure gauge to the fuel inlet hose.

Note:

It is recommended to place the pressure gauge outside the engine compartment using a hose of adequate length. In this case, place the gauge almost at the height of carburetor.

4. Turn the ignition switch on and note the pressure reading.

If the reading is not within the specifications mentioned below, the pump is damaged and should be repaired or replaced.

If the pump pressure is within the specifications, perform the test for volume.




Fig. 4-31 Testing fuel pump

b. Volume test

Turn the ignition switch on, open the hose restrictor and expel the fuel into the container, while observing the expelling amount for one minute. Close the restrictor and read the amount.

Specification – Fuel pump

Fuel pressure	0.25 ~ 0.35 kg/cm ² (3.55 ~ 4.98 lb/in ²)
Feeding capacity	More than 1,150 cc/min (1.22 U.S. quart/min)

If the pump volume is below specifications, repeat the test using an auxiliary fuel supply and a new fuel filter. If the pump volume meets specifications while using the auxiliary fuel supply, check for a restriction in the fuel supply from the tank and for the tank not venting properly.

4-C. FUEL FILTER

The fuel filter is of a cartridge type. The element of the filter is sealed cartridge and should be replaced following the maintenance schedule.




Fig. 4-32 fuel filter

4-D. FUEL LINES

Inspect the fuel lines for leaks and tighten the fuel line connections to prevent leakage. It is important that the fuel system should be kept clean and free from water. In an excessive amount of dirt or water is found, drain the fuel from the tank and blow out the fuel lines with compressed air.

4-E. FUEL TANK

Inspect the fuel tank for cracks and corrosion. If any defect is present, repair or replace as necessary.

Note :

Before repairing, clean the fuel tank thoroughly with steam and sufficiently to remove all explosive gas.

4-F. AIR CLEANER

4-F-1. Air Cleaner Element

The air cleaner is of a paper filter type. The element should be serviced following the maintenance schedule. To clean, blow the element with compressed air at low pressure.

4-F-2. Intake Air Temperature Control System

Intake air temperature control system consisting of a control valve and a bimetal is located within the air cleaner and senses the engine room temperature for a stabilized intake air temperature.




Fig. 4-33 Air control valve




Fig. 4-34 Valve opening angle

The intake of fresh air and hot air is automatically controlled over by means of the bimetal and control valve installed in the air cleaner inlet side.

The control valve closes the fresh side air completely below $7.5 \pm 6^\circ\text{C}$ ($45.5 \pm 10.8^\circ\text{F}$) of the ambient temperature and only hot air is led into the engine through the air cleaner element.

The hot air is completely closed above $45.5 \pm 7^\circ\text{C}$ ($113.5 \pm 12.6^\circ\text{F}$) and all the fresh air is sucked into the engine.

a. Removing air control valve

1. Remove the clip and bush from the bimetal side shaft.
2. Pull out the shaft from the air cleaner body.
3. Remove the bimetal by removing the set screw.



Fig. 4-35 Removing air control valve

b. Installing air control valve

To install, follow the removal procedures in the reverse order with following caution.

Assembling the shaft to the bimetal, align the slit of the shaft to the bimetal end.




Fig. 4-36 Installing air control valve

D. Volume test
 Turn the intake valve on over the hose and...
 and expect the fuel from the container will...
 of the expelling stream for one minute. Close the...
 restriction and read the amount.

Specification - Fuel pump

Item	Specification
Fuel pressure	0.35 - 0.53 kg/cm ² (0.50 - 0.75 lb/cm ²)
Fueling capacity	4.00 gpm (15.0 l/min) 11.7 l (3.1 gal/min)

ELECTRICAL SYSTEM (ENGINE)


5-A. BATTERY	5	1
5-A-1. Checking Battery	5	1
5-A-2. Charging Battery	5	1
5-B. IGNITION SYSTEM	5	2
5-C. DISTRIBUTOR	5	3
5-C-1. Adjusting Point Gap	5	3
5-C-2. Adjusting Ignition Timing	5	3
5-C-3. Removing Distributor	5	4
5-C-4. Testing Distributor	5	4
5-C-5. Disassembling Distributor	5	5
5-C-6. Inspecting Distributor	5	5
5-C-7. Assembling Distributor	5	6
5-C-8. Installing Distributor	5	6
5-D. IGNITION COIL	5	7
5-E. SPARK PLUG	5	7
5-E-1. Spark Plug Heat Range	5	7
5-E-2. Removing Spark Plug	5	7
5-E-3. Checking Spark Plug	5	7
5-E-4. Installing Spark Plug	5	7
5-F. ALTERNATOR	5	8
5-F-1. Precautions on Service	5	8
5-F-2. Checking Charging System on Car	5	8
5-F-3. Disassembling Alternator	5	9
5-F-4. Inspecting Alternator	5	9
5-F-5. Assembling Alternator	5	10
5-G. REGULATOR	5	11
5-G-1. Checking Constant Voltage Relay	5	11
5-G-2. Checking Pilot Lamp Relay	5	11
5-G-3. Adjusting Regulator	5	11
5-H. STARTING MOTOR	5	12
5-H-1. Checking Starting Circuit	5	12
5-H-2. Testing Starting Motor	5	12
5-H-3. Disassembling Starting Motor	5	12
5-H-4. Inspecting Starting Motor	5	13
5-H-5. Magnetic Switch Test	5	14
5-H-6. Assembling Starting Motor	5	15
SPECIAL TOOLS	5	15

Check the specific gravity of the electrolyte with a hydrometer as shown in Fig. 7-1. If the reading is 1.28 or more, it indicates that the battery is fully charged. If the reading is below 1.25, the battery requires recharging.

Check the tightness of the terminals to ensure good contact. Clean the terminals and coat them with a thin layer of grease to prevent corrosion.

As the battery has an important influence on starting, it is essential to check the following points before starting the engine.

Check the tightness of the terminals to ensure good contact. Clean the terminals and coat them with a thin layer of grease to prevent corrosion.



5-A. BATTERY

5-A-1. Checking Battery

As the battery has an important influence on startability, ignition and lighting, check the following points periodically and always keep the battery in perfect condition.




Fig. 5-1 Checking specific gravity

1. Check the electrolyte level in each cell of the battery, and add distilled water to maintain the solution 10 ~ 20 mm (0.4 ~ 0.8 in) above the plates. Do not overfill.

2. Check the specific gravity of the electrolyte with a hydrometer, as shown in Fig. 5-1. If the reading is 1.28 or more, it indicates that the battery is fully charged. If the reading is below 1.22, the battery requires recharging.

3. Check the tightness of the terminals to ensure good electrical connections. Clean the terminals and coat the terminals with grease.

4. Inspect for corroded or frayed battery cables.

5-A-2. Charging Battery

a. Constant current charge

1. If the exterior of the battery is dirty with sulphuric acid or dust and dirt, wash these off with clean water and dry thoroughly before charging the battery.

2. Check the electrolyte level and add distilled water if necessary.

Note:

If addition of distilled water is neglected, the plates and separators will become exposed to air, causing a sulphation to occur on the plates.

Do not add dilute sulphuric acid unless the electrolyte has overflowed or led out.

3. Connect the battery to the charger ensuring that the polarities are correct.




Fig. 5-2 Ignition system

4. To charge, apply an electric current of approximately 5A until the specific gravity of the electrolyte reaches 1.27 ~ 1.29.

b. Fast charge

As a fast charge causes both the temperature and the level of the electrolyte to rise suddenly, it does not have a favorable effect on the battery. Therefore, this should not be performed unless in the case of an emergency.

When a fast charge is being applied with the battery mounted on the vehicle, ensure that the cables are removed from the battery terminals before the charge is applied. If this is neglected, it could cause a damage to the diodes on the alternator.

The battery should be kept by the use of cooling water to prevent the temperature of the electrolyte from exceeding 55°C (131°F), otherwise the charging should be discontinued temporarily when the temperature rises above this point.

5-B. IGNITION SYSTEM

In the rotary engine, two spark plugs are provided in

the working chamber, one above the minor axis (called the trailing side) and the other below the minor axis (called leading side) of the epitrochoid surface, so as to enable the engine to obtain the optimum combustion efficiency under any operating condition.

The primary wires from the individual breaker points for trailing and leading plugs are led to the two separate coils and the secondary wires also are separately led via the distributor to the trailing and leading plugs.

In the distributor, the vacuum advance works on the trailing side and the centrifugal advance works on both the trailing and leading sides, and the interval of the initial ignition timing between trailing and leading can be adjusted.

The coil with external resistor is used.

The ignition coil relay is equipped to short-circuit the external resistor in starting (when the starter is running) so as to increase the secondary voltage and improve the startability.

Short-circuiting of resistor by the ignition coil relay is made on the trailing side only and that on the leading side by the ignition switch. The ignition coil relay has another contact point which serves to energize the ignition circuit for the fuel pump, etc.




Fig. 5-3 Distribution of ignition

5-C. DISTRIBUTOR

The distributor for this model had two breaker points, one for leading spark plugs and the other for trailing spark plugs.

The distributor consists of distributing mechanism, contact breaker mechanism, and ignition timing advance control of centrifugal and vacuum.

5-C-1. Adjusting Point Gap

A scope, a dwell meter, or a feeler gauge can be used to check the gap of new breaker points. A scope or a dwell meter should be used to check the gap of used breaker points. Due to the roughness of used points, it is not advisable to use a feeler gauge to check the gap.

To check and adjust the breaker points with a feeler gauge:

1. Check the breaker points alignment. If necessary, bend the stationary point bracket so as to obtain contact in the center of the breaker points.
2. Crank and stop the engine when the rubbing block on the breaker arm just rests on the highest point of the cam.
3. Insert a feeler gauge of 0.45 mm (0.018 in) between the breaker points, loosen the two set screws and move the stationary point until the correct gap is obtained.
4. Tighten the set screws and recheck the point gap.




Fig. 5-4 Adjusting point gap

5-C-2. Adjusting Initial Ignition Timing

To check and adjust the timing with a timing light, proceed as follows:

* STEP-1 *

1. Connect a tachometer to the engine.

Note:

The tacho-dwell tester can be used in the same method as when measuring the dwell angle on a 4 cylinder, 4 cycle reciprocating engine.

2. Disconnect and plug the vacuum tube on the distributor.
3. Connect a timing light to the high tension cord for leading spark plug of the front rotor housing.
4. Start the engine, and run it at specified idle speed. (See page 4 : 2)




Fig. 5-5 Checking ignition timing

5. Aim the timing light at the timing indicator pin on the front cover.




Fig. 5-6 Timing marks

6. If the leading timing is not correctly aligned, stop the engine.
7. Loosen the distributor locking nut slightly and rotate the distributor housing with engine running so that the leading timing may align with the indicator pin on the front cover.
8. Stop the engine and tighten the distributor locking nut. Recheck the timing.
9. Change connection of the timing light to the high tension cord for trailing spark plug of the front housing.
10. Aim the timing light and check the timing. If the timing is in allowance of specification, the both initial timings are satisfactory and checking of timing is finished.

* STEP-2 *

If the trailing timing is not in specification, adjust both the trailing and leading timings as follows:

11. Adjust the trailing timing to specification by rotating the distributor housing.
12. Then, check the leading timing and read the error.
13. Remove the distributor cap and rotor. Turn out breaker base set screws $\frac{1}{2}$ to 2 turns and turn the base as required until correct timing is obtained.

Note:

Refer to graduations on the breaker base to make adjustment easier.




Fig. 5-7 Adjusting procedure

One graduation correspond to eccentric shaft angular displacement of 4 degrees.




Fig. 5-8 Adjusting timing

14. Recheck the timing. If the timing mark is not correctly aligned, repeat this performing until the correct timing is obtained.

Specifications — Initial timing

Leading	-5°	at idle speed
Trailing	$-15^\circ \pm 4^\circ$	at idle speed

5-C-3. Removing Distributor

1. Remove the distributor cap and disconnect the vacuum tube from the vacuum advance unit.
2. Disconnect the coupler of primary wires from the distributor.
3. Remove the distributor attaching nut.
4. Pull the distributor out of the front cover.



Fig. 5-9 Removing distributor

5-C-4. Testing Distributor

a. Dwell angle test

1. Disconnect and plug the distributor vacuum tube and connect the tester following the instructions of the manufacturer. Then start the engine and let it idle.
2. Turn the cylinder selector to the 4 cylinder, 4 cycle position.
3. Read the dwell angle on the dwell meter and compare the reading to specification. ($55 \sim 61^\circ$ in this case)
4. If the dwell angle is below specification, the breaker point gap is too wide. If the dwell angle is above specification, the breaker point gap is too close.




Fig. 5-10 Checking dwell angle

b. Dwell angle adjustment

If the dwell angle is not within specifications, proceed as follows:

1. Remove the coil high tension cords from the distributor and ground them.
2. Remove the distributor cap and place them out of the way.
3. Connect the remote starter switch (49 0242 685A) in the circuit.
4. Loosen the breaker point attaching screws.
5. With the ignition switch on, crank the engine with a remote starter switch and adjust the gap to specification.
6. Release the remote starter switch and tighten the breaker point attaching screws.
7. Since the adjustment may have changed when the attaching screw was tightened, crank the engine again

with the remote starter switch and check the dwell angle. When the dwell is properly adjusted, remove the remote starter switch and tester leads.

c. Advance test

The advance is checked to determine if the ignition timing advances in proper relation to engine speed and load.

Check the dwell angle. If the angle is not within the specifications, adjust the breaker points.

Check the breaker arm spring tension [0.5 ~ 0.65 kg (1.1 ~ 1.4 lb)] and replace the points if the spring tension is not within specifications.

The advance characteristic of the distributor should be within the range as shown in Fig. 5-12.




Fig. 5-11 Advance test




Fig. 5-12 Advance characteristic

Note:

The ignition advance tester can be used in the same method as when measuring the ignition advance on the 4 cylinder, 4 stroke reciprocating engine but the numerical value indicated on the scale is twice as much as the actual advance degree of rotary engine. So the indicated value should be divided into two.

5-C-5. Disassembling Distributor

1. Loosen the cap retaining clips and lift off the cap.
2. Remove the rotor.
3. Remove the screws attaching the vacuum control unit to the distributor housing and remove the clip holding the vacuum diaphragm link. Remove the vacuum control unit.
4. Remove the screws attaching the condensers.
5. Remove the primary wires (rubber block) from the housing.
6. Remove the contact point assemblies from the breaker base by removing the set screws.
7. Remove the screws attaching the breaker base and remove the breaker base.




Fig. 5-13 Removing breaker base

8. Remove the cam set screw and remove the cam.
9. Remove the retaining pin attaching the distributor driven gear. Remove the gear and the washer(s).
10. Remove the shaft in upward direction through the top of the distributor housing.
11. Remove the governors by removing the springs and clips.

5-C-6. Inspecting Distributor

a. Checking cap

Inspect the distributor cap for crack, carbon runners and evidence of arcing. If any of these conditions exists, the cap should be replaced. Clean any corroded high tension terminals.

b. Checking rotor

Inspect the rotor for cracks or evidence of excessive burning at the end of the metal strip. If any of these conditions exists, the rotor should be replaced.

c. Checking contact points

Inspect the points for wear, burning, transferred metal and pitting. If they are slight, the points can be

cleaned with an oil stone. If they are severe, replace with new ones.

d. Checking tension of contact arm spring

For inspection, hook a spring scale on the contact arm and pull in a straight line at a right angle to the contact arm. Take a reading when the contact points start to separate. The reading should be between 0.5 ~ 0.65 kg (1.1 ~ 1.4 lb).

e. Checking condenser

If the condenser is leaky, it will cause a weak spark or burned contact points. Check the capacity of the condenser with a condenser tester. The capacity is 0.27 ± 0.027 microfarads. In the absence of a tester, check by substituting a new condenser.

5-C-7. Assembling Distributor

Assemble the distributor in the reverse order of disassembling.

5-C-8. Installing Distributor

1. Turn the eccentric shaft until the TDC mark on the drive pulley aligns with the indicator pin on the front cover. (See Fig. 5-6)
2. Align the tally mark on the distributor housing and driven gear as shown in Fig. 5-14.
3. Insert the distributor so that the distributor lock



Fig. 5-14 Aligning tally mark

- bolt is located in the center of the slit, and engage the gears.
4. Rotate the distributor clockwise until the leading contact point starts to separate, and tighten the distributor attaching nut.
5. Install the distributor cap and connect the primary wires coupler.
6. Set the timing with a timing light, then tighten the distributor attaching nut. (Refer to Par. 5-C-2)
7. Connect the vacuum tube to the vacuum advance unit.




Fig. 5-15 Distributor components

- | | | | |
|--------------------------|-----------------------------|-----------------------------|-------------------|
| 1. Cap | 6. Governor | 11. Shaft | 16. Cam |
| 2. Rotor | 7. Condenser | 12. Oil seal | 17. Cam set screw |
| 3. Leading breaker point | 8. Lock plate | 13. Breaker base (Leading) | |
| 4. Clamp | 9. Distributor body | 14. Breaker base (Trailing) | |
| 5. Vacuum diaphragm | 10. Distributor driven gear | 15. Trailing breaker point | |

5-D. IGNITION COIL

This model is equipped with two ignition coils of which is the oil cooling type. On this type of ignition coil, oil is sealed within the insulator inside the coil and, therefore, if by any chance an oil leakage should occur, this would cause a drop in the efficiency of the coil, resulting in deteriorating the performance of the engine. Therefore check the ignition coil to ensure that the terminals are clean and that there are no cracks or oil leakages. Also, check the external and primary resistance.

Ignition Coil	Type	External Resistance	Primary Resistance
Leading	HP5-13J	1.4 Ω/20°C	1.35 Ω/20°C
Trailing	HP5-13E	1.6 Ω/20°C	1.46 Ω/20°C

5-E. SPARK PLUG

On this engine, 2 spark plugs are provided in each working chamber so as to enable the engine to obtain the optimum combustion efficiency under any operating condition. These spark plugs for this engine are slightly different from for the reciprocating engines in dimensions and heat values.

As you are aware, heat range of the spark plugs should be selected by owing of various conditions, otherwise durability of the spark plug, startability of the engine and running performance of the car will be down. Therefore, it is recommended that heat range of the spark plugs should be selected in each vehicle running conditions.

All spark plugs must be of the same maker and number or heat range. If spark plugs shown burning white or rapid electrode wear, replace with a **cold range type** spark plugs.

Do not use spark plug which is not specified.

5-E-1. Spark Plug Heat Range

Two types of spark plug, standard spark plug and cold type spark plug, are available and they should be selected according to the weather condition and driving condition.

a. Standard

The standard spark plugs are of the standard specification and suitable for the vehicle which is not frequently driven at a continuous speed over 150 km/h (95 miles/h).

b. Cold type

The cold type spark plugs are of a heat range higher than the standard spark plugs. They should be used in case the standard spark plugs are overheated, or for the vehicles which is frequently driven at a continuous speed of over 150 km/h (95 miles/h).

5-E-2. Removing Spark Plug

1. Disconnect the wire from each spark plug by grasping, twisting and then pulling the moulded cap of the wire only. Do not pull on the wire because the wire connection inside the cap may become separated or the boot may be damaged.
2. After loosening each spark plugs one or two turns, clean the area around each spark plug port with compressed air, then remove the spark plugs.

5-E-3. Checking Spark Plug

1. Inspect each plug individually for badly worn electrodes, glazed, broken or blistered porcelain, and replace the plug as necessary.
2. Clean the spark plugs thoroughly using a sand blast cleaner.
3. Inspect each spark plug for make, and heat range.




Fig. 5-16 Checking gap

Below is the table of recommended spark plugs.

	Standard	Cold type	Initial gap
NGK	B7EM BR7EM B7EMV BR7EMV	B8EM BR8EM B8EMV BR8EMV	0.6 ~ 0.7 mm (0.024 ~ 0.028 in)
NIPPON-DENSO	W22EA W22EAR W22EA-G W22EAR-G	W25EA W25EAR W25EA-G W25EAR-G	
CHAMPION	N-80B RN-80B	N-78B RN-78B	

5-E-4. Installing Spark Plug

1. In order to protect the thread portion of the spark plugs, it is recommended to **apply Moly Paste (0259 77 767 or 0259 77 768)** to the threaded portion of the new spark plugs.
2. Thread the spark plugs into the rotor housing finger tight until the gaskets contact the housing. If the plugs cannot be installed with finger pressure, clean the threads with a suitable greased thread chaser. Torque each plug to specifications.
3. Connect the spark plug wires.

5-F. ALTERNATOR

5-F-1. Precaution on Service

When servicing the charging system, observe the following precaution. If not followed, the result will be in serious damage of the system.

1. Do not short across or ground any of the terminals on the alternator.
2. Never operate the alternator on with an open circuit (with the field terminal connected and the armature terminal disconnected).
3. When installing a battery, always make sure that the negative post of the battery is attached securely to the ground strap.
4. Never reverse battery cables, not even for an instant, as reverse polarity current flow will damage the diodes in the alternator.
5. When charging the battery with a fast charger, disconnect the positive cable at the battery.

5-F-2. Checking Charging System on Car

If the electrical system is not charging properly, check all electrical connections and the fan belt tension prior to performing any test of the charging system, then determine whether the trouble is in the alternator or regulator before removing the alternator.

Check the alternator by using an **alternator tester** (49 0370 290). If the checker is not available, check as follows:

1. Disconnect the wire from "B" terminal of the alternator and connect the negative lead of the ammeter to the wire and the positive lead to the "B" terminal.
2. Disconnect the alternator coupler led to the regulator.
3. Start the engine and hold the alternator speed to 2,000 rpm.
4. Make the short circuit for a moment by connecting "B" terminal and "F" terminal of the alternator with the suitable wire as shown in Fig. 5-18.
5. If the meter reading increases remarkably, the trouble is in the regulator and if there is no change in current, it is in the alternator.




Fig. 5-17 Alternator components

- | | | |
|------------------|---------------------|----------------------|
| 1. Pulley | 6. Front bearing | 11. Terminal bolt |
| 2. Fan | 7. Bearing retainer | 12. Rectifier |
| 3. Spacer | 8. Rotor | 13. Brush and holder |
| 4. Slinger | 9. Rear bearing | 14. Rear housing |
| 5. Front housing | 10. Stator | 15. Condenser |




Fig. 5-18 Checking charging system

5-F-3. Disassembling Alternator

1. Remove the radio noise suppression condenser from the rear of the alternator.
2. Remove the through bolts.
3. Separate the front housing assembly by prying apart with a screwdriver at the slots of the front housing.
4. Hold the front housing and rotor assembly, clamping the rotor.




Fig. 5-19 Loosening pulley nut

5. Loosen the pulley retaining nut and remove the nut, washer, pulley, fan, spacer and front slinger.
6. Remove the front housing with bearing and remove the rear slinger.
7. Remove the nut, washers and insulator from the "B" terminal at the rear of the alternator.
8. Remove the screw attaching the rectifier to the rear housing and remove two screws attaching brush holder and rectifier.
9. Carefully remove the stator, rectifier and brush holder assembly from the rear housing. Use care to keep the brush holder assembly intact during removal from the rear housing.
10. Remove the brush holder assembly.
11. Unsolder the stator leads from the rectifier.
12. If bearing replacement is necessary, remove the rear bearing from the rotor shaft with a puller. To replace the front bearing, remove the bearing retainer attaching screws, and press the bearing from the front housing

5-F-4. Inspecting Alternator

a. Checking stator coil

Check the stator coil for both open and grounded circuits with a tester.

To check for open, connect the prods to each of the two leads, as shown in Fig. 5-20. If there is no flow of current, the coil is open circuit and must be repaired or replaced.




Fig. 5-20 Checking stator coil for open

To check for ground, connect one prod to the core and the other to each lead wire, as shown in Fig. 5-21. If a ground is present the current will flow and the stator coil must be repaired or replaced.




Fig. 5-21 Checking stator coil for ground




Fig. 5-22 Checking rotor for open

b. Checking rotor

To check for open circuit, place both prods of a tester on the slip rings, as shown in Fig. 5-22. If the reading is 4 to 6 ohms, there is no trouble in the rotor. To check for ground, connect one prod to the slip ring and other prod to the core, as shown in Fig. 5-23. If the current flows the rotor must be repaired or replaced.




Fig. 5-23 Checking rotor for ground

c. Checking diodes

Diodes for use in the alternator are available in two different types, the positive diode which allows current to flow from the lead wire to the case but not from the case to the lead wire and the negative diode which has the opposite properties.

To check, read the resistance between the lead wire and case with a tester. Then reverse the tester leads and note the reading. If both readings are very low or high, the diode is defective.

A good diode will give one low reading and one high reading.



Fig. 5-24 Checking diode




Fig. 5-25 Brush holder assembly

d. Checking brushes and springs

The brushes should be replaced when one-third of the original length is worn away. This is indicated by a wear limit line on the side surface of each brush. Check the brush spring tension. The tension should be between 330 and 450 gr (12 and 16 oz). Replace the springs if the tension is less than 330 gr (12 oz) or if excessive corrosion exists.

e. Checking bearings

There is no need of lubricating as the bearing is pre-lubricated. In a long spell of use, when the bearing is worn or damaged, replace it with a new one.

5-F-5. Assembling Alternator

Assemble the alternator in the reverse order of disassembling, noting the following points.

1. When installing the rotor assembly to the rear housing and stator assembly, hold the brushes in position by inserting a piece of stiff wire into the hole of the brush through the rear housing as shown in Fig. 5-26.




Fig. 5-26 Installing rotor assembly

2. The soldering of the diode leads should be performed in **less than twenty seconds** as the excessive heat may damage the diode.

5-G. REGULATOR

The regulator used for this model is composed of two control units, a constant voltage relay and a pilot lamp relay, mounted as an assembly.

5-G-1. Checking Constant Voltage Relay

To check, use an almost fully charged battery and connect a voltmeter between the (A) and (E) terminals of the regulator, as shown in Fig. 5-27.

Then, hold the alternator revolution to 4,000 rpm (engine revolution 1,800 rpm) and take a reading of the voltmeter. If the reading is 14 ± 0.5 volts, it is in proper order. If it is not within the specifications, the voltage relay must be adjusted, as instructed in Par. 5-G-3.




Fig. 5-27 Checking constant voltage relay

5-G-2. Checking Pilot Lamp Relay

Make a circuit, as shown in Fig. 5-28, using a voltmeter and variable resistor, and light up the pilot lamp. Then, slide the knob of the variable resistor so that the voltage gradually increases.

Read the voltage between the (N) and (E) terminal when the lamp goes out. If this voltage is 3.7 to 5.7 volts, it is normal.

Next, slide the knob to gradually reduce the voltage and the lamp will light again. If the reading is less




Fig. 5-28 Checking pilot lamp relay

than 3.5 volts at this time, it is proper.

5-G-3. Adjusting Regulator

First, check the air gap, back gap and point gap with a wire gauge. If they are not within the specifications, adjust by bending the stationary contact bracket. After correct gaps are obtained, adjust the voltage setting. Bend the upper plate down to decrease the voltage setting, up to increase the voltage setting.

In case of the pilot lamp relay, if the voltage when the lamp lights up is adjusted to the specification, the voltage when the lamp goes out may be within the specification.




Fig. 5-29 Adjusting regulator




Fig. 5-30 Gaps of regulator

Specifications

Constant voltage relay

Air gap	0.7 ~ 1.3 mm (0.028 ~ 0.051 in)
Point gap	0.3 ~ 0.45 mm (0.012 ~ 0.018 in)
Back gap	0.7 ~ 1.5 mm (0.028 ~ 0.059 in)

Pilot lamp relay

Air gap	0.9 ~ 1.4 mm (0.035 ~ 0.055 in)
Point gap	0.7 ~ 1.1 mm (0.028 ~ 0.043 in)
Back gap	0.7 ~ 1.5 mm (0.028 ~ 0.059 in)

5-H. STARTING MOTOR (Under the engine type)

5-H-1. Checking Starting Circuit

When the starting motor fails to operate or does not satisfactorily operate, check the following points before removing the starting motor:

1. Weak battery
2. Corroded or loose battery terminal
3. Loose starting motor terminal
4. Broken or loose wires of the starting circuit
5. Faulty ignition switch

5-H-2. Testing Starting Motor

a. Free running test

1. Place the starting motor in a vise equipped with soft jaws and connect a fully-charged 12 volt battery to the starting motor.
2. Connect an ammeter between the (B) terminal of the starting motor and the battery.
3. Operate the starting motor and take a reading. On 1.2 KW starting motor, the current draw should be less than 75 amperes at 4,900 rpm or more. [2.0 KW: less than 100 amperes at 7,800 rpm or more]




Fig. 5-31 Free running test

b. Lock resistance test

1. Install the starting motor on a test bench.
2. Test the lock resistance of the starting motor, following the instructions of the test equipment manufacturer.
3. With applied battery voltage adjusted to 5.0 volts, the current flow should be 780 amperes [1.2 KW: 1,100 amperes] or less and the torque should be 1.1 m-kg (7.95 ft-lb) [1.2 KW: 2.4 m-kg (17.3 ft-lb)] or more.

If the starting motor does not perform to the above test requirements, repair it referring to the following list.

- 1) Starter rotates slowly with a large current at free running.
 - a) Worn, dirty or defective bearings
 - b) Short circuit of armature
 - c) Grounded armature and field coil
- 2) Starter does not rotate with a large current.
 - a) Defective field circuit
 - b) Defective armature circuit
 - c) Burnt commutator
- 3) Low torque and low current flow. Low free running speed.
 - a) Breakage of field circuit

- b) Excessive internal resistance
- 4) Low torque. High free running speed.
 - a) Short circuit of field coil

5-H-3. Disassembling Starting Motor

1. Disconnect the field strap from the terminal on the magnetic switch.
2. Remove the magnetic switch attaching screws and remove the magnetic switch, spring and washers from the driving housing.




Fig. 5-32 Removing magnetic switch

3. Remove the plunger from the driving lever.



Fig. 5-33 Removing plunger

4. Remove the through bolts and brush holder attaching screws. Then, remove the rear cover.




Fig. 5-34 Removing rear cover

5. Remove the insulator and washers from the rear end of the armature shaft.
6. Remove the brush holder.
7. Separate the yoke from the driving housing.



Fig. 5-35 Removing yoke assembly

8. Remove the rubber packing, springs and spring seat.
9. Remove the armature and over-running clutch assembly from the driving housing.




Fig. 5-36 Removing armature assembly

10. Remove the driving lever.
11. Drive the pinion stop collar toward the armature, and remove the stop ring. Then, slide the stop collar



Fig. 5-37 Removing pinion stop collar

- and over-running clutch off the armature shaft.
12. If the field coil removal is necessary, remove the pole shoe retaining screws. Then, remove the pole shoes and field coil from the yoke.

5-H-4. Inspecting Starting Motor

a. Checking armature

Check the armature for both ground and short circuit. To check for ground, touch one prod of an ohmmeter to each segment and the other prod to the core or shaft.

An infinite reading should be obtained for each segment. If the meter reading is not infinite, the armature windings are shorted to the core or shaft and the armature must be replaced.



Fig. 5-38 Checking armature

To check for short circuit, use a growler tester. Place the armature against the core of the tester, and hold a steel strip on the armature. Then, rotate the armature slowly by hand. If the armature coil is shorted, the steel strip will become magnetized and vibrate. Replace the armature if a short is found.

b. Checking commutator

If the commutator is dirty, discolored or worn, clean it with emery paper and wash with clean solvent. After cleaning, undercut the mica between the segments to the depth of 0.5 ~ 0.8 mm (0.020 ~ 0.031 in), as shown in Fig. 5-39.




Fig. 5-39 Undercutting mica




Fig. 5-40 Commutator mica depth

c. Checking field coil

To test the field coil for ground with an ohmmeter, place one prod on the yoke or pole core and the other prod to the field terminal. An infinite meter reading should be obtained. If a reading other than infinite is found, replace the field windings.



Fig. 5-41 Checking field coil for ground

d. Checking brush holder

Check the brush holder for ground. Touch one prod of an ohmmeter to the insulated brush holder and the other prod to the brush holder frame. If the meter reading is other than infinite, the brush holder assembly is shorted and must be replaced. Repeat this test for the other insulated brush holder. Do not use this test on the two grounded brush holders.

e. Checking brushes and brush springs

Check the brushes and replace if they are worn down more than one third of their original length. Otherwise, the brush spring tension will be reduced, leading to an increase in the brush-commutator contact resistance. This will lower the torque and cause the burnt commutator surface.

The spring tension is 1.4 ~ 1.8 kg (49 ~ 63 oz). If the tension is too low, replace the springs.

f. Checking bushes

Check the clearance between the armature shaft and the bush. If it exceeds 0.2 mm (0.08 in), replace the bush.

5-H-5. Magnetic Switch Test

a. Pull-in coil test

Apply the specified voltage (12V) between the (S) terminal and (M) terminal. If the magnetic switch is forcefully attracted, the pull-in coil is in good condition.




Fig. 5-42 Pull-in coil test

b. Holding coil test

Ground the (M) terminal to the magnetic switch body with a lead and impose the specified voltage (12V) upon the (S) terminal to pull in the plunger. If the plunger remains attracted after disconnecting the lead from the (M) terminal, there is no trouble with the holding coil.




Fig. 5-43 Holding coil test




Fig. 5-44 Return test

c. Return test

Push in the plunger by hand and apply the specified voltage (12V) between the (M) terminal and the magnetic switch body. If the plunger is not attracted, there is no trouble.

5-H-6. Assembling Starting Motor

To assemble the starting motor, reverse the procedure of Par. 5-H-3, **noting** the following points.

1. Adjust the armature shaft end play to 0.1 ~ 0.4 mm (0.004 ~ 0.015 in) with a thrust washer on the rear end of the shaft.
2. When the magnetic switch is engaged, the clearance between the pinion and stop collar should be 0.5 ~ 2.0 mm (0.02 ~ 0.08 in). This clearance can be adjusted by inserting the ad-

justing washer between the magnetic switch body and the driving housing.





Fig. 5-45 Checking pinion position

SPECIAL TOOLS

49 0242 685A	Remote starter switch
49 0370 290	Alternator tester



a. Checking field coil
To test the field coil for ground with an ohmmeter, place one lead on the pole or pole core and the other lead to the field terminal. An infinite reading should be obtained. If a reading other than infinite is found, replace the field windings.

b. Checking brush holder
Check the brush holder for ground. Touch one lead of an ohmmeter to the insulated brush holder and the other lead to the brush holder frame. If the meter reading is other than infinite, the brush holder assembly is shorted and must be replaced. Repeat this test for the other insulated brush holder. Do not use this test on the two grounded brush holders.

c. Checking brushes and brush springs
Check the brushes and replace if they are worn down more than one third of their original length. Other than the brush spring tension will be reduced, bearing in mind that an increase in the brush-spring tension will cause the brush to wear the commutator surface. The spring tension is 1.4 ~ 1.7 kg (3.1 ~ 3.7 lb). If the tension is not low, replace the spring.

d. Checking brushes
Check the clearance between the armature shaft and the brush. It should be 0.2 mm (0.008 in). Replace the brush.



Fig. 6-3. Loosening flywheel nut



Fig. 6-4. Checking release bearing

CLUTCH

The clutch is of the single dry disc type. The clutch assembly consists of the clutch disc, pressure plate, cover and pressure plate assembly, and clutch release mechanism. The clutch operating mechanism is of the hydraulic type consisting of a dash mounted master cylinder and a clutch release cylinder mounted in the clutch housing.

6-A. CLUTCH PEDAL ADJUSTMENT

The free travel in the clutch pedal before the push rod contacts with the piston should be 0.8 to 3.0 mm (0.03 to 0.12 in).

6-A. CLUTCH PEDAL ADJUSTMENT..... 6 : 1

6-B. CLUTCH REMOVAL..... 6 : 1

6-C. CLUTCH INSPECTION..... 6 : 1

6-C-1. Checking Release Bearing and Fork..... 6 : 1

6-C-2. Checking Pressure Plate and Cover Assembly..... 6 : 2

6-C-3. Checking Clutch Disc..... 6 : 2

6-C-4. Flywheel Inspection..... 6 : 2

6-C-5. Ring Gear Replacement..... 6 : 3

6-C-6. Checking Pilot Bearing..... 6 : 3

6-C-7. Pilot Bearing Replacement..... 6 : 3

6-C-8. Checking Eccentric Shaft Rear Oil Seal..... 6 : 3

6-D. CLUTCH INSTALLATION..... 6 : 3

6-E. CLUTCH MASTER CYLINDER..... 6 : 4

6-E-1. Removing Clutch Master Cylinder..... 6 : 4

6-E-2. Disassembling Clutch Master Cylinder..... 6 : 4

6-E-3. Checking Clutch Master Cylinder..... 6 : 4

6-E-4. Assembling Clutch Master Cylinder..... 6 : 4

6-E-5. Installing Clutch Master Cylinder..... 6 : 5

6-F. CLUTCH RELEASE CYLINDER..... 6 : 5

6-F-1. Removing Clutch Release Cylinder..... 6 : 5

6-F-2. Disassembling Clutch Release Cylinder..... 6 : 5

6-F-3. Checking Clutch Release Cylinder..... 6 : 5

6-F-4. Assembling Clutch Release Cylinder..... 6 : 5

6-F-5. Installing Clutch Release Cylinder..... 6 : 5

6-G. AIR BLEEDING..... 6 : 5

SPECIAL TOOLS..... 6 : 5

Examine the clutch housing carefully to be certain there are no burrs on the outer surface of the clutch housing.



Fig. 6-4. Checking release bearing

Remove the clutch housing and clutch disc assembly from the flywheel and the clutch disc. With the flywheel, the eccentric shaft and the release bearing removed, the flywheel to the eccentric shaft and remove the flywheel from the eccentric shaft. Using the puller (44-0213-300), remove the flywheel from the eccentric shaft.

Note: After removing the flywheel, inspect for oil leakage through the engine crank oil seal.

Put the release fork forward until the spring tip of the fork release from the ball joint. Remove the fork release bearing from the clutch housing.

CLUTCH

The clutch is of the single dry disc type. The clutch assembly consists of the clutch disc assembly, clutch cover and pressure plate assembly, and clutch release mechanism.

The clutch operating mechanism is of the hydraulic type, consisting of a dash mounted master cylinder and a clutch release cylinder mounted on the clutch housing.

6-A. CLUTCH PEDAL ADJUSTMENT

The free travel of the clutch pedal before the push rod contacts with the piston should be **0.5 to 3.0 mm (0.02 to 0.12 in)**.

To adjust the free travel, loosen the lock nut and turn the push rod until the proper adjustment is made. Tighten the lock nut after adjustment is completed.




Fig. 6-1 Clutch pedal adjustment

- | | |
|--------------------------|-------------|
| 1. Master cylinder | 4. Lock nut |
| 2. Height adjusting bolt | 5. Rod |
| 3. Lock nut | 6. Pedal |

6-B. CLUTCH REMOVAL

To remove the clutch from the vehicle, proceed as follows:

1. Remove the transmission.
2. Install the **ring gear brake** (49 0118 271A).
3. Remove the 4 standard bolts and 2 reamer bolts holding the clutch cover assembly to the flywheel, and remove the clutch cover assembly and the clutch disc.
4. Straighten the tab of the lockwasher. With the **wrench** (49 0820 035), loosen the nut that attaches the flywheel to the eccentric shaft and remove the nut.
5. Using the **puller** (49 0823 300), remove the flywheel from the eccentric shaft.

Note:

After removing the flywheel, inspect for oil leaking through the engine rear oil seal.

6. Pull the release fork outward until the spring clip of the fork releases from the ball pivot. Remove the fork release bearing from the clutch housing.



Fig. 6-2 Loosening flywheel nut



Fig. 6-3 Removing flywheel

6-C. CLUTCH INSPECTION

6-C-1. Checking Release Bearing and Fork

Note: The release bearing is packed with lubricant which is intended to last the whole life time of the bearing. Therefore, the bearing must not be washed in gasoline or any other solvent.

Check the release bearing by pressing and turning the front race slowly by hand. Replace if the bearing feels rough or seems noisy when turning.



Fig. 6-4 Checking release bearing

Examine the clutch housing carefully to be certain there are no burrs on the outer surface of the clutch

housing which pilots the release bearing. Check the release fork for crack or bend. If necessary, replace the fork.

6-C-2. Checking Pressure Plate and Cover Assembly

Check the contact surfaces of the pressure plate with the clutch facing for wear, damage or warpage. If it is slight, correct it by lapping with compound or by turning a lathe. But if severe, replace with a new one.

Check the diaphragm spring and cover and if any wear or damage is found, replace the pressure plate and cover assembly.

6-C-3. Checking Clutch Disc

Inspect the clutch disc for warpage with a dial indicator or a feeler gauge, as shown in Fig. 6-5. If it is more than 1.0 mm (0.039 in), replace with a new one.




Fig. 6-5 Checking clutch disc for warpage

Excessively worn facing will cause slippage or score the pressure plate and flywheel due to the projected heads of rivets.

Check the depth between the facing surface and the rivet using a depth gauge, as shown in Fig. 6-6. If the reading is less than 0.30 mm (0.012 in), replace the clutch disc.



Fig. 6-6 Checking clutch disc for wear

If oil is evident on the facing, clean or replace the facing and eliminate the cause of oil leakage. Make certain that the clutch disc slides easily on the main drive shaft without any excessive play.

6-C-4. Flywheel Inspection

Inspect the contact surface of the flywheel with the clutch facing for burnt surface, scored surface or rivet grooves.

If it is slight, it can be reconditioned by grinding in




Fig. 6-7

Clutch components

1. Clutch disc
2. Clutch cover
3. Reamer bolt
4. Top hole cover
5. Release fork
6. Oil seal
7. Dust cover
8. Bolt
9. Pivot pin
10. Release bearing
11. Clutch housing

a lathe. If the damage is deep, the flywheel should be replaced.

Check the ring gear teeth and replace if the ring gear teeth are broken, cracked or seriously burred.

Check the oil seal contacting surface of the flywheel for roughness. Repair or replace the flywheel if necessary.

Note:

On the vehicle equipped with an automatic transmission, the ring gear and drive plate should be replaced as an assembly.

6-C-5. Ring Gear Replacement

1. Heat the old ring gear and remove it from the flywheel.
2. Heat a new ring gear evenly 250 to 300°C (480 to 570°F).
3. Place the ring gear on the cold flywheel, making sure that the chamfer on the teeth is faced to the transmission.
4. Allow the ring gear to cool slowly to shrink it onto the flywheel.

6-D-6. Checking Pilot Bearing

Check the transmission main drive shaft pilot bearing which is pressed into the rear end of the eccentric shaft.

If the bearing is loose or rough, it should be replaced.

6-D-7. Pilot Bearing Replacement

1. Remove the bearing and seal from the rear end of the eccentric shaft with the remover (49 0823 071A).




Fig. 6-8 Removing pilot bearing




Fig. 6-9 Pilot bearing and seal
1. Seal 2. Pilot bearing

2. Install a new bearing with the installer (49 0823 072A).

3. Install the seal.



Fig. 6-10 Installing pilot bearing

6-C-8. Checking Eccentric Shaft Rear Oil Seal

Check the oil seal fitted into the rear stationary gear for wear or damage.

If traces of oil leakage are found, replace the oil seal.

6-D. CLUTCH INSTALLATION

1. Clean the contact surfaces of the flywheel, pressure plate and disc thoroughly with fine sandpaper or crocus cloth.

Note:

Avoid touching the clutch disc facing, dropping the parts or contaminating them with oil or grease as a clutch chatter may result.

2. Fit the key into the keyway on the eccentric shaft.
3. Install the flywheel onto the rear end of the eccentric shaft, aligning the keyway of the flywheel with the key.
4. Apply sealer on both sides of the lockwasher and place it in position. Install the nut.




Fig. 6-11 Applying sealer to lock washer

5. Install the ring gear brake (49 1881 060) and with the wrench (49 0820 035) tighten the nut to 40 ~ 50 m·kg (289 ~ 362 ft·lb).

6. Bend the tab of the lockwasher to prevent loosening.
7. Hold the clutch disc in its mounting position with the **clutch disc centering tool** (49 0813 310).
If the tool is not available, use a spare main drive shaft.
8. Install the clutch cover and pressure plate assembly, **aligning the "O" marks** of the clutch cover and flywheel and install the 4 standard and 2 reamer bolts finger tight. To avoid pressure plate cover distortion, tighten the bolts a few turns at a time until they are all tight.




Fig. 6-12 Installing clutch cover assembly

9. Torque the bolts to **1.8 ~ 2.7 m-kg (13 ~ 20 ft-lb)**.
10. Remove the disc centering tool and ring gear brake.
11. Apply grease to the pivot pin. Insert the release fork through the dust boot and press it inward so that the spring clip of the fork fits to the ball pivot.
12. Apply a light film of grease to the face of the release bearing and the bearing retainer of the clutch housing. Install the release bearing and the return spring. Operate the release fork to ensure that the bearing slides on the retainer back and forth smoothly.
13. Install the transmission and propeller shaft. Care should be taken in order not to bend the clutch disc by allowing the transmission to hang.




Fig. 6-13
Clutch master cylinder components

1. Cap
2. Fluid baffle
3. Bolt
4. Washer
5. Reservoir
6. Cylinder
7. Spring
8. Primary piston cup
9. Piston and secondary cup assembly
10. Piston stop washer
11. Piston stop wire

6-E. CLUTCH MASTER CYLINDER

6-E-1. Removing Clutch Master Cylinder

If it becomes necessary to remove the master cylinder for repair or overhaul, proceed as follows:

1. Disconnect the fluid pipe at the master cylinder outlet.
2. Remove the nuts that attach the master cylinder to the dash panel.
3. Pull the master cylinder straight out and away from the dash panel.

6-E-2. Disassembling Clutch Master Cylinder

The procedures for disassembling the master cylinder after removing the master cylinder are as follows:

1. Clean the outside of the master cylinder thoroughly and drain the brake fluid.
2. Remove the reservoir from the cylinder.
3. Remove the dust boot from the cylinder.
4. Remove the piston stop wire with a screwdriver and remove the stop washer.
5. Remove the piston assembly, primary cup and return spring from the cylinder.
6. Carefully remove and disassemble the one-way valve.

6-E-3. Checking Clutch Master Cylinder

1. Wash the parts in clean alcohol or brake fluid. **Never use gasoline or kerosene.** Blow the parts dry with compressed air.
2. Check the piston cups and replace if they are damaged, worn, softened, or swelled.
3. Examine the cylinder bore and piston for wear, roughness or scoring.
4. Check the clearance between the cylinder bore and the piston. If it is **more than 0.15 mm (0.006 in)**, replace the cylinder or piston.
5. Ensure that the compensating port on the cylinder is open.
6. Check the one-way valve parts for freedom of operation.

6-E-4. Assembling Clutch Master Cylinder

1. Before assembling, dip the piston and cups in clean brake fluid.

2. Install the reservoir to the cylinder.
3. Insert the return spring into the cylinder.
4. Install the primary cup so that the flat side of the cup goes toward the piston.
5. Fit the secondary cup onto the piston and install them into the cylinder.
6. Install the stop washer and stop wire.
7. Assemble and install the one-way valve.
8. Fill with brake fluid and operate the piston with a screwdriver until the fluid is ejected at the outlet.
9. Install the dust boot to the cylinder.

6-E-5. Installing Clutch Master Cylinder

1. Install the clutch master cylinder assembly onto the dash panel and tighten the nuts.
2. Connect the fluid pipe to the cylinder.
3. Fill with brake fluid.
4. Bleed the clutch hydraulic system, as described in Par 6-G.

6-F. CLUTCH RELEASE CYLINDER

6-F-1. Removing Clutch Release Cylinder

1. Disconnect the fluid pipe at the clutch release cylinder.
2. Remove the nuts attaching the cylinder to the clutch housing. Remove the release cylinder.




Fig. 6-14 Removing clutch release cylinder

6-F-2. Disassembling Clutch Release Cylinder

1. Clean the outside of the cylinder thoroughly.
2. Remove the dust boot from the cylinder.
3. Remove the release rod.
4. Remove the piston and cups from the cylinder. If necessary, blow out with compressed air from the fluid passage.
5. Remove the bleeder screw and valve (steel ball).

6-F-3. Checking Clutch Release Cylinder

Refer to Par. 6-E-3 and inspect the clutch release cylinder.

6-F-4. Assembling Clutch Release Cylinder

1. Install the spring into the cylinder.
2. Fit the piston cup to the piston and install them into the cylinder.
3. Install the release rod into the cylinder.

4. Install the dust boot.
5. Install the valve (steel ball) and bleeder screw into the bleeder hole. Fit the bleeder cap.




Fig. 6-15 Release cylinder cross section

- | | |
|----------------|------------------|
| 1. Spring | 6. Cap |
| 2. Piston cup | 7. Bleeder screw |
| 3. Cylinder | 8. Valve |
| 4. Release rod | 9. Piston |
| 5. Boot | |

6-F-5. Installing Clutch Release Cylinder

1. Install the clutch release cylinder assembly to the clutch housing with two nuts.
2. Connect the fluid pipe.
3. Fill the reservoir of the master cylinder with brake fluid and bleed the system, as described in Par. 6-G.

6-G. AIR BLEEDING

The clutch hydraulic system must be bled whenever a fluid line has been disconnected or air enters the system. To bleed the clutch system, remove the rubber cap from the bleeder screw and attach the bleeder tube and fixture of the bleeder screw.

Place the end of the tube in the glass jar and submerge in brake fluid. Open the bleeder valve. Depress the clutch pedal and allow it to return slowly. Continue this pumping action and watch the flow of fluid in the jar. When air bubbles cease to appear, close the bleeder valve. During bleeding the reservoir of the master cylinder must be kept at least 3/4 full of the brake fluid. After the bleeding operation, remove the tube, fit the cap to the bleeder screw, fill the reservoir and fit the filler cap.

SPECIAL TOOLS

49 1881 060	Ring gear brake
49 0820 035	Wrench for flywheel nut
49 0823 300	Flywheel puller
49 0823 071A	Pilot bearing remover
49 0823 072A	Pilot bearing installer
49 0813 310	Clutch disk centering tool

TRANSMISSION

- 7-A. TRANSMISSION REMOVAL..... 7 : 1
- 7-B. TRANSMISSION DISASSEMBLY..... 7 : 1
- 7-C. TRANSMISSION INSPECTION..... 7 : 3
 - 7-C-1. Checking Transmission Case and Clutch Housing..... 7 : 3
 - 7-C-2. Checking Bearings..... 7 : 3
 - 7-C-3. Checking Gears..... 7 : 3
 - 7-C-4. Checking Main Shaft and Main Drive Shaft..... 7 : 3
 - 7-C-5. Checking Counter Shaft..... 7 : 3
 - 7-C-6. Checking Control Lever and Shift Fork Shaft..... 7 : 3
 - 7-C-7. Checking Shift Fork..... 7 : 3
 - 7-C-8. Checking Clutch Sleeve..... 7 : 4
 - 7-C-9. Checking Synchronizer Ring..... 7 : 4
 - 7-C-10. Checking Synchronizer Key and Spring..... 7 : 5
 - 7-C-11. Checking Clutch Hub..... 7 : 5
 - 7-C-12. Checking Extension Housing..... 7 : 5
 - 7-C-13. Checking Speedometer Gears..... 7 : 5
- 7-D. TRANSMISSION ASSEMBLY..... 7 : 5
- 7-E. TRANSMISSION INSTALLATION..... 7 : 11
- SPECIAL TOOLS..... 7 : 11

7-B TRANSMISSION DISASSEMBLY

The procedure for disassembly of the transmission follows:

1. Place the transmission on a work stand.

Remove the drain plug and drain the transmission oil from the metal filter as shown. Clean the drain plug if necessary. If the drain plug after draining lubricant, it has the release lock solenoid in the lock system. The spring release itself from the ball stud. Remove the lock and lock cover from the clutch housing. Using the clutch housing and gear.

7-C TRANSMISSION INSPECTION

When removing the transmission, the following procedure is followed:

1. Remove the clutch fork.

2. Remove the shift fork.

3. Remove the shift fork shaft.

4. Remove the shift fork shaft.

5. Remove the shift fork shaft.

6. Remove the shift fork shaft.

7. Remove the shift fork shaft.

8. Remove the shift fork shaft.

9. Remove the shift fork shaft.

10. Remove the shift fork shaft.

11. Remove the shift fork shaft.

12. Remove the shift fork shaft.

13. Remove the shift fork shaft.

14. Remove the shift fork shaft.

15. Remove the shift fork shaft.

16. Remove the shift fork shaft.

17. Remove the shift fork shaft.

18. Remove the shift fork shaft.

19. Remove the shift fork shaft.

20. Remove the shift fork shaft.

7-D TRANSMISSION ASSEMBLY

Remove the drain plug and drain the transmission oil from the metal filter as shown. Clean the drain plug if necessary. If the drain plug after draining lubricant, it has the release lock solenoid in the lock system. The spring release itself from the ball stud. Remove the lock and lock cover from the clutch housing. Using the clutch housing and gear.

7-E TRANSMISSION INSTALLATION

Remove the drain plug and drain the transmission oil from the metal filter as shown. Clean the drain plug if necessary. If the drain plug after draining lubricant, it has the release lock solenoid in the lock system. The spring release itself from the ball stud. Remove the lock and lock cover from the clutch housing. Using the clutch housing and gear.

SPECIAL TOOLS

Remove the drain plug and drain the transmission oil from the metal filter as shown. Clean the drain plug if necessary. If the drain plug after draining lubricant, it has the release lock solenoid in the lock system. The spring release itself from the ball stud. Remove the lock and lock cover from the clutch housing. Using the clutch housing and gear.

Remove the drain plug and drain the transmission oil from the metal filter as shown. Clean the drain plug if necessary. If the drain plug after draining lubricant, it has the release lock solenoid in the lock system. The spring release itself from the ball stud. Remove the lock and lock cover from the clutch housing. Using the clutch housing and gear.



Fig. 7-3 Inspecting control lever and...

TRANSMISSION

Remove the drain plug and drain the transmission oil from the metal filter as shown. Clean the drain plug if necessary. If the drain plug after draining lubricant, it has the release lock solenoid in the lock system. The spring release itself from the ball stud. Remove the lock and lock cover from the clutch housing. Using the clutch housing and gear.

Remove the drain plug and drain the transmission oil from the metal filter as shown. Clean the drain plug if necessary. If the drain plug after draining lubricant, it has the release lock solenoid in the lock system. The spring release itself from the ball stud. Remove the lock and lock cover from the clutch housing. Using the clutch housing and gear.

Remove the drain plug and drain the transmission oil from the metal filter as shown. Clean the drain plug if necessary. If the drain plug after draining lubricant, it has the release lock solenoid in the lock system. The spring release itself from the ball stud. Remove the lock and lock cover from the clutch housing. Using the clutch housing and gear.

Remove the drain plug and drain the transmission oil from the metal filter as shown. Clean the drain plug if necessary. If the drain plug after draining lubricant, it has the release lock solenoid in the lock system. The spring release itself from the ball stud. Remove the lock and lock cover from the clutch housing. Using the clutch housing and gear.

Remove the drain plug and drain the transmission oil from the metal filter as shown. Clean the drain plug if necessary. If the drain plug after draining lubricant, it has the release lock solenoid in the lock system. The spring release itself from the ball stud. Remove the lock and lock cover from the clutch housing. Using the clutch housing and gear.

Remove the drain plug and drain the transmission oil from the metal filter as shown. Clean the drain plug if necessary. If the drain plug after draining lubricant, it has the release lock solenoid in the lock system. The spring release itself from the ball stud. Remove the lock and lock cover from the clutch housing. Using the clutch housing and gear.

Remove the drain plug and drain the transmission oil from the metal filter as shown. Clean the drain plug if necessary. If the drain plug after draining lubricant, it has the release lock solenoid in the lock system. The spring release itself from the ball stud. Remove the lock and lock cover from the clutch housing. Using the clutch housing and gear.

Remove the drain plug and drain the transmission oil from the metal filter as shown. Clean the drain plug if necessary. If the drain plug after draining lubricant, it has the release lock solenoid in the lock system. The spring release itself from the ball stud. Remove the lock and lock cover from the clutch housing. Using the clutch housing and gear.

TRANSMISSION

MAZDA Rotary pickup is equipped with a four speed manual transmission which is of the fully synchronized type with all gears except the reverse gear being in constant mesh.

The gearshift mechanism is a direct control with a floor-shift type.

The transmission gear ratio is as follows:

	Gear ratio
First	3.683
Second	2.263
Third	1.397
Top	1.000
Reverse	3.692

7-A. TRANSMISSION REMOVAL

When removing the transmission from the vehicle, proceed as follows:

1. Remove the gearshift lever knob.
2. Remove the boot for the gearshift lever.
3. Remove the bolts attaching the retainer cover to the gearshift lever retainer.
4. Pull the gearshift lever, shim and bush straight up and away from the gearshift lever retainer.
5. Disconnect the earth wire of the battery.
6. Remove the bolt attaching the power brake vacuum pipe clip to the clutch housing.
7. Remove the earth wire from the transmission case.
8. Remove the nuts attaching the clutch release cylinder and remove the clutch release cylinder.
9. Remove the one upper bolt securing the starting motor, then remove the three upper bolts and nuts securing the transmission to the engine rear end.
10. Raise the vehicle and support with stands.
11. Disconnect the wires of the starting motor and the reverse lamp switch.
12. Disconnect the speedometer cable from the extension housing.
13. Remove the bolts attaching the heat insulator to the exhaust front pipe, and remove the heat insulator.
14. Disconnect the exhaust front pipe from the exhaust pipe brackets by removing the bolts and nuts. Disconnect the exhaust front pipe flange from the exhaust manifold by removing the nuts. Remove the bolts and nuts attaching the front pipe flange to the main silencer, and remove the exhaust front pipe.
15. Remove the propeller shaft, as described in Par. 8-A-1, and insert the **transmission oil plug** (49 0259 440) into the extension housing.
16. Remove the lower bolt securing the starting motor to the clutch housing and remove the starting motor.
17. Place a jack under the front side of the engine and support the engine with the jack.
18. Remove the bolts securing the transmission support to the body.
19. Remove the two lower bolts securing the transmission to the engine rear end.
20. Slide the transmission rearward until the main drive shaft clears the clutch disc and carefully with-

draw it downward from the vehicle.

7-B. TRANSMISSION DISASSEMBLY

The procedures for disassembling the transmission after removing the transmission from the vehicle are as follows:

1. Place the transmission on a work stand.
2. Remove the drain plug, and drain the lubricant from the transmission. Clean the metal fillings adhered on the magnet of the drain plug if necessary. Refit the drain plug after draining lubricant.
3. Pull the release fork outward until the fork retaining spring release itself from the ball stud. Remove the fork and boot from the clutch housing.
4. Remove the nuts attaching the clutch housing, and remove the clutch housing and gasket.




Fig. 7-1 Removing clutch housing

5. Remove the adjusting shim from the bearing bore of the clutch housing.
6. Remove the bolts attaching the gearshift lever retainer to the extension housing and remove the retainer and gasket.
7. Remove the nuts attaching the extension housing to the transmission case. With the control lever end in neutral, press the end to the left as far as it will go, and slide the extension housing off the transmission.
8. Remove the spring cap bolt and remove the spring and friction piece from the extension housing.
9. Remove the neutral switch from the extension housing.
10. Remove the bolt that attach the gearshift control lever end to the gearshift control lever, and remove the control lever end, key and control lever.



Fig. 7-2 Removing control lever end

11. Remove the speedometer sleeve lock plate, and remove the sleeve and driven gear assembly from the extension housing.
12. Remove the back-up lamp switch from the extension housing.
13. Remove the snap ring that secures the speedometer drive gear to the main shaft. Slide the drive gear off the main shaft, and remove the lock ball.
14. Evenly loosen the bolts securing the case cover to the transmission case and remove the cover and gasket.
15. Remove the three spring cap bolts and remove the detent springs and detent balls (locking balls) from the transmission case.




Fig. 7-3 Spring cap bolts

- | | |
|-------------------------|--------------------|
| 1. Spring cap bolt | 6. Detent ball |
| 2. Washer | 7. Detent spring |
| 3. Detent spring | 8. Washer |
| 4. Detent ball | 9. Spring cap bolt |
| 5. Shift inter-lock pin | |

16. Remove the nuts attaching the two blind covers to the transmission case and remove the blind covers and gaskets.
17. Remove the bolt attaching the reverse shift lever to the transmission case. Slide the reverse shift fork shaft with the reverse shift lever and reverse idle gear out the rear of the transmission case. Remove the attaching bolt from the reverse shift fork and remove the shift fork.
18. Remove the attaching bolt from the third-and-fourth shift fork. Slide the third-and-fourth shift fork shaft out the rear of the transmission case.
19. Remove the attaching bolt from the first-and-second shift fork. Slide the first-and-second shift fork shaft out the rear of the transmission case.
20. Straighten the tab of the lock washer, hold the rear end of the main shaft with the **holder** (Part No. 49 0259 440) as shown in Fig. 7-4 and loosen the main shaft lock nut. Slide the reverse gear off the rear of the main shaft, and remove the key.
21. Remove the snap ring from the rear end of the counter shaft and remove the counter reverse gear.
22. Remove the bolts attaching the bearing cover to the transmission case and remove the bearing cover.
23. Remove the reverse idler gear shaft from the transmission case.
24. Install the **synchronizer ring holder** between the




Fig. 7-4 Removing lock nut

fourth synchronizer ring and the synchromesh gear on the main drive shaft.

25. Remove the snap ring that secures the counter shaft front bearing to the front end of the counter shaft. Using the **bearing puller** (Part No. 49 0839 425B) shown in Fig. 7-5, remove the counter shaft front bearing.



Fig. 7-5 Removing counter shaft front bearing

26. Remove the adjusting shim from the counter shaft front bearing bore of the transmission case.
27. Remove the counter shaft rear bearing from the counter shaft with the **puller** (Part No. 49 0839 425B).
28. Using the **puller** (Part No. 49 0839 425B) shown in Fig. 7-6, remove the main shaft bearing.
29. Remove the adjusting shim from the main shaft bearing bore of the transmission case.
30. Remove the snap ring that secures the main drive shaft bearing to the main drive shaft. Remove the main drive shaft bearing with the **puller** (Part




Fig. 7-6 Removing main drive shaft bearing

No. 49 0839 425B).

31. Take out the counter shaft and gear from the transmission case.

32. Separate the main shaft from the main drive shaft and remove the main shaft from the case as shown in Fig. 7-7. Remove the fourth synchronizer ring and needle bearing from the main drive shaft and gears assembly.

33. Take out the main drive shaft and gears assembly from the case.




Fig. 7-7 Removing main shaft and gears assembly

34. Remove the first-and-second shift fork and third-and-fourth shift fork from the case.

35. Remove the two shift inter-lock pins from the case.

36. Remove the snap ring that secures the third-and-fourth clutch hub and sleeve assembly. Slide the third-and-fourth clutch hub and sleeve assembly, third synchronizer ring, third gear out the front of the main shaft. **Do not** mix the synchronizer rings.

37. Slide the first gear, first synchronizer ring and first gear sleeve out the rear of the main shaft.

38. Remove the second gear, second synchronizer ring, first-and-second clutch hub and sleeve assembly from the main shaft.

7-C. TRANSMISSION INSPECTION

Thoroughly clean all the parts. Inspect the parts for wear, damage and other defects. The parts found defective must be repaired or replaced.

7-C-1. Checking Transmission Case and Clutch Housing

Inspect the case for cracks or any damage. Check the clutch housing for cracks or any damage. Replace the oil seal in the clutch housing if necessary.

7-C-2. Checking Bearings

Inspect each bearing for roughness or noise by holding the outer race, and rotating the inner race while applying pressure with hand. Replace the bearings if necessary. Replace the needle bearings that are broken, worn or rough.

7-C-3. Checking Gears

Inspect the teeth of each gear. If excessively worn, broken or chipped, replace with new gear. Excessive

wear of the gears causes increase of backlash, which results in producing noises or may cause the gear to work off while running.

7-C-4. Checking Main Shaft and Main Drive Shaft

Check the main shaft run-out with a dial indicator. If the run-out exceeds **0.03 mm (0.0012 in)**, correct with a press or replace with a new one.




Fig. 7-8 Checking main shaft run-out

Replace the main shaft if there is any evidence of wear or if any of the splines is damaged.

Replace the main drive shaft if the splines are damaged. If the needle bearing surface in the bore of the bearing is worn or rough, or if the cone surface is damaged, replace with a new shaft.

7-C-5. Checking Counter Shaft

Check the teeth of the counter shaft gear for wear or damage. Replace the counter shaft if it is bent, scored or worn.

7-C-6. Checking Control Lever and Shift Fork Shaft

Check the contact surface of the shift fork shaft with the detent ball for wear or damage.

Check the contact surface of the shift fork shaft with the control lever for wear. The clearance between the shift fork shaft and the control lever should be **more than 0.8 mm (0.031 in)**.




Fig. 7-9 Checking clearance

7-C-7. Checking Shift Fork

Check the contact surface of the shift forks with the clutch sleeve for wear or damage. The clearance

between the shift fork and the clutch sleeve should be more than 0.5 mm (0.020 in).




Fig. 7-10 Checking clearance

7-C-8. Checking Clutch Sleeve

Check the clutch sleeves for free movement on their hubs.

Check the splines of the clutch sleeve for wear or damage.

Check the contact surface of the clutch sleeve with the shift fork for wear or damage.

7-C-9. Checking Synchronizer Ring

1. Check the synchromesh gear on the synchronizer ring for wear or damage.

2. Check the tapered portion for uneven wear or




Fig. 7-11 Checking clearance




Fig. 7-12

Shafts and gears

1. Adjusting shim
2. Snap ring
3. Main drive shaft bearing
4. Main drive shaft
5. Synchronizer ring
6. Needle bearing
7. Synchronizer key spring
8. Third-and-fourth clutch hub
9. Synchronizer key
10. Clutch hub sleeve
11. Third gear
12. Main shaft
13. Second gear
14. First-and-second clutch hub
15. Clutch hub sleeve
16. Gear sleeve
17. First gear
18. Thrust washer
19. Adjust shim
20. Ball bearing and clip
21. Bearing stopper
22. Bolt
23. Key
24. Reverse gear
25. Lock washer
26. Lock nut
27. Steel ball
28. Speedometer drive gear
29. Snap ring
30. Ball bearing and clip
31. Adjust shim
32. Counter shaft
33. Needle bearing
34. Counter reverse gear
35. Reverse idler gear
36. Reverse idler gear shaft

damage. Also place the ring on the gear cone, and check the clearance between the gear and the ring. If the clearance is less than 0.8 mm (0.031 in), replace the synchronizer ring.

3. If the contact between the ring and the gear cone is incorrect, or if a new synchronizer ring is used, lap the synchronizer ring with the gear cone using a lapping compound. Apply a light pressure for lapping. After lapping, clean the ring and the gear cone with a suitable solvent, then check the clearance and contact between the ring and the gear cone.

7-C-10. Checking Synchronizer Key and Spring

1. Check the synchronizer key for wear or damage.
2. Check the synchronizer key spring for wear or weakness.

7-C-11. Checking Clutch Hub

Check the splines for wear or damage. Check the contact surface of the clutch hub with the synchronizer ring for wear or damage. Check the contact surface of the clutch hub with the thrust surface of the gears for wear or damage.

7-C-12. Checking Extension Housing

Inspect the extension housing for cracks and the machined mating surface for burrs, nicks or any damage. Inspect the oil seal in the extension housing. Replace them if they are worn or damaged.

7-C-13. Checking Speedometer Gears

Check the drive gear and driven gear and the driven gear shaft for wear or damage. Check the "O" ring for weakness or damage.

7-D. TRANSMISSION ASSEMBLY

1. Assemble the first-and-second synchromesh mechanism by installing the clutch hub to the sleeve, placing the three synchronizer keys into the clutch hub key slots and installing the key springs to the clutch hub.




Fig. 7-13 Synchromesh mechanism

- | | |
|------------------|---------------------|
| 1. Clutch sleeve | 3. Synchronizer key |
| 2. Clutch hub | 4. Key spring |




Fig. 7-14 Installing synchronizer key spring

Note :

When installing the key springs, the open ends of the springs should be kept 120° apart as shown in Fig. 7-15, so that the spring tension on each key




Fig. 7-15 Installing key spring

will be uniform.

2. Assemble the third-and-fourth synchromesh mechanism in the same manner as first-and-second synchromesh mechanism.

3. Place the synchronizer ring on the second gear and slide the second gear to the main shaft with the synchronizer ring toward the rear of the shaft.

4. Slide the first-and-second clutch hub and sleeve assembly to the main shaft with the oil grooves of the clutch hub toward the front of the main shaft. Make sure that the three synchronizer keys in the synchromesh mechanism engage the notches in the second synchronizer ring.




Fig. 7-16 Installing clutch hub and sleeve assembly

5. Slide the first gear sleeve to the main shaft.
6. Place the synchronizer ring on the first gear and slide the first gear to the main shaft with the synchronizer ring toward the front of the shaft. Rotate the first gear as necessary to engage the three notches in the synchronizer ring with the synchronizer keys in the first-and-second.
7. Install the original thrust washer to the main shaft.



Fig. 7-17 Installing first gear

8. Place the synchronizer ring on the third gear and slide the third gear to the front of the main shaft with the synchronizer ring toward the front.
9. Slide the third-and-fourth clutch hub and sleeve assembly to the front of the main shaft making sure




Fig. 7-18 Installing clutch hub and sleeve assembly




Fig. 7-19 Direction of clutch hub assembly

that the three synchronizer keys in the synchromesh mechanism engage the notches in the synchronizer ring.

Note :

The direction of the third-and-fourth clutch hub and sleeve assembly should be as shown in Fig. 7-19.

10. Install the snap ring to the front of the main shaft.
11. Position the main shaft and gears assembly in the case.




Fig. 7-20 Installing main shaft and gears assembly

12. Place the needle bearing to the front end of the main shaft.
13. Place the synchronizer ring on the third-and-fourth clutch hub making sure that the three synchronizer keys in the third-and-fourth synchromesh mechanism engage the notches in the synchronizer ring.
14. Install the main shaft and gears assembly into the transmission case. Then, engage the main shaft and gears assembly with the main drive shaft.
15. Position the first-and-second shift fork and third-and-fourth shift fork in the groove of the clutch hub and sleeve assembly, as shown in Fig. 7-21.




Fig. 7-21 Installing shift forks

16. Position the counter shaft gear in the case, making sure that the counter shaft gear engage each gear of the main shaft assembly.
17. Check the main shaft bearing end play, proceed as follows: Measure the depth of the main shaft bearing bore in the clutch housing by using a depth gauge. Then, measure the main shaft bearing height shown in Fig. 7-23. The difference between the two




Fig. 7-22 Installing counter shaft gear

measurements indicates the required thickness of the adjusting shim. The standard end play is 0 ~ 0.1 mm (0 ~ 0.0039 in). The adjusting shims are available in the following thickness :

0.1 mm (0.0039 in)	0.3 mm (0.0118 in)
--------------------	--------------------




Fig. 7-23 Checking end play

18. Install the **synchronizer ring holder** (Part No. 49 0839 445) between the fourth synchronizer ring and the synchronesh gear on the main drive shaft.
19. Position the main drive shaft bearing and the




Fig. 7-24 Checking end play

main shaft bearing in their respective bearing bore, and press them in by using a press.

20. Install the snap ring to secure the main drive shaft bearing.

21. Check the counter shaft bearing end play in the same manner for the main shaft bearing end play. The standard clearance is 0 ~ 0.1 mm (0 ~ 0.0039 in). The adjusting shims are available in the following thickness :

0.1 mm (0.0039 in)	0.3 mm (0.0118 in)
--------------------	--------------------

22. Install the **synchronizer ring holder** (Part No. 49 0839 445) between the fourth synchronizer ring and the synchronesh gear on the main drive shaft.

23. Position the counter shaft front bearing and the rear bearing in their respective bearing bore, and press them in by using a press.

24. Install the snap ring to secure the front bearing.

25. Remove the synchronizer ring holder.

26. Install the counter reverse gear to the rear end of the counter shaft and secure it with the snap ring.

27. Install the reverse idler gear shaft to the transmission case.

28. Install the bearing cover to the transmission case and tighten the attaching bolts.
29. Install the reverse gear with the key to the main shaft. Tighten the main shaft lock nut to 21.0 ~ 25.0 m·kg (151.0 ~ 180.0 ft·lb), by using the holder (Part No. 49 0259 440).




Fig. 7-25 Tightening lock nut

30. Slide the first-and-second shift fork shaft into the case from the rear of the case. Secure the first-and-second shift fork to the fork shaft with the lock bolt.

31. Place the shift fork shaft in neutral position.




Fig. 7-26 Shift inter-lock pin installer




Fig. 7-27 Inserting shift inter-lock pin

Using the **shift inter-lock pin installer** (Part No. 49 0862 350) shown in Fig. 7-27, insert the shift inter-lock pin into the case.

32. Slide the third-and-fourth shift fork shaft into the case from the rear of the case. Secure the third-and-fourth shift fork to the fork shaft with the lock bolt.




Fig. 7-28 Securing shift fork

33. Insert the shift inter-lock pin into the case by using the **installer** (Part No. 49 0862 350).




Fig. 7-29 Inserting shift inter-lock pin

34. Install the reverse shift fork to the reverse shift fork shaft and secure the shift fork with the lock bolt.




Fig. 7-30 Spring cap bolts

- | | |
|-------------------------|--------------------|
| 1. Spring cap bolt | 6. Detent ball |
| 2. Washer | 7. Detent spring |
| 3. Detent spring | 8. Washer |
| 4. Detent ball | 9. Spring cap bolt |
| 5. Shift inter-lock pin | |

35. Slide the reverse shift fork shaft with the reverse shift lever and reverse idler gear into the case from the rear of the case. Secure the reverse shift lever to the case with the bolt.




Fig. 7-31 Installing reverse idle gear

36. Position the three detent balls and three springs into the case and install the spring cap bolts.

37. Place the third-and-fourth clutch sleeve in the third gear.

38. Check the clearance between the synchronizer key and the exposed edge of the synchronizer ring with a feeler gauge. This measurement should be




Fig. 7-32 Checking clearance

0.66 ~ 2.0 mm (0.026 ~ 0.079 in). If the measurement is greater than 2.0 mm (0.079 in), the synchronizer key could pop out of position. If the measurement exceeds 2.0 mm (0.079 in), exchange the thrust washer (selective fit). The thrust washers are available as in the following table.

2.5 mm (0.098 in)	3.5 mm (0.138 in)
3.0 mm (0.118 in)	

If the measurement corrects, bend the tab of the lock washer.

39. Install the two blind covers and gaskets to the case and tighten the attaching nuts.

40. Install the transmission case cover to the case and tighten the attaching bolts.

41. Install the lock ball, speedometer drive gear and snap ring to the main shaft from the rear of the main shaft.




Fig. 7-33 Installing drive gear

42. Insert the gearshift control lever through the holes from the front of the extension housing. Position the woodruff key in place and slide the gearshift control lever end to the gearshift control lever. Secure the lever end to the control lever with the bolt.

43. Install the neutral switch to the extension housing.




Fig. 7-34 Gear shift mechanism

1. Third-and-fourth shift fork
2. Third-and-fourth shift rod
3. First-and-second shift rod
4. First-and-second shift fork
5. Reverse shift rod
6. Reverse shift fork
7. Steel ball
8. Cap spring
9. Cap spring gasket
10. Cap spring plug
11. Shift lever
12. Change lever knob
13. Change lever
14. Interlock pin
15. Dust boot
16. Cover plate
17. Cover plate gasket
18. Wave washer
19. Bush
20. Shim
21. Cap spring plug
22. Cap spring gasket
23. Cap spring
24. Steel ball
25. Change control case
26. Change control case gasket
27. Select lock spindle spring
28. Select lock spindle
29. Spring seat
30. Control end
31. Control lever
32. Control lever key
33. Reverse lamp switch
34. Friction piece
35. Cap spring
36. Cap plug gasket
37. Cap spring plug



Fig. 7-35 Installing control lever end

and tighten the switch.

44. Position the spring and friction piece in the extension housing and tighten the spring cap bolt to the extension housing.

45. Install the back-up lamp switch to the extension housing and tighten the switch.

46. Insert the speedometer driven gear assembly to the extension housing and secure it with the bolt and lock plate.




Fig. 7-36 Friction piece

47. Place the gasket on the rear of the transmission case and position the extension housing on the transmission case with the gearshift control lever end laid down to the left as far as it will go. Tighten the attaching nuts.




Fig. 7-37 Installing extension housing

48. Check to ensure that the gearshift control lever operates properly.

49. Insert the select lock spindle and spring from the inside of the gearshift lever retainer. Position the lock ball and spring in alignment with the select lock spindle and tighten the spring cap bolt.




Fig. 7-38 Gearshift lever retainer

- | | |
|-----------------|------------------------|
| 1. Retainer | 4. Spring cap bolt |
| 2. Locking ball | 5. Spring |
| 3. Spring | 6. Select lock spindle |

50. Position the gasket and gearshift lever retainer to the extension housing, and tighten the attaching bolts.

51. Check the bearing end play as follows: Measure the depth of the main drive shaft bearing bore in the clutch housing using a depth gauge. Then, measure the bearing height shown in Fig. 7-39. The difference between two measurements indicates the




Fig. 7-39 Measuring bearing height




Fig. 7-40 Measuring bearing bore depth

required thickness of the adjusting shim. The standard clearance is 0 ~ 0.1 mm (0 ~ 0.0039 in). If necessary, select and use the properly sized shim. The shims are available in the following thickness:

0.1 mm (0.0039 in)	0.3 mm (0.0118 in)
--------------------	--------------------

- 52. Apply lubricant to the lip of the oil seal in the clutch housing.
- 53. Place the gasket on the front side of the case and install the clutch housing to the case. Tighten the attaching nuts.
- 54. Install the release bearing, release fork and release fork boot to the clutch housing.

7-E. TRANSMISSION INSTALLATION

Follow the removal procedures in the reverse order.

Note:

- (a) Apply a thin coat of grease to the splines of the main drive shaft.
- (b) Use the **clutch disc arbor** (Part No. 49 0813 310) to align the splines of the main drive shaft and clutch disc.
- (c) Fill the transmission case with lubricant until the lubricant overflows from the level hole.

SPECIAL TOOLS

49 0839 425B	Bearing puller seat
49 0259 440	Main shaft holder
49 0839 445	Synchronizer ring holder
49 0862 350	Shift inter-lock pin installer
49 0813 310	Clutch disc arbor
49 0259 440	Transmission oil plug




Fig. 3-28 Measuring bearing length



Fig. 3-29 Measuring bearing length



Fig. 3-30 Clutch disc

10. Place the gasket on the top of the transmission case and position the synchronizer housing on the case. Tighten the screws with the bearing puller seat and turn down to the set as it will be. Tighten the bearing nut.





Fig. 3-31 Installing synchronizer housing

11. Check to ensure that the synchronizer housing is properly installed. Tighten the screws with the bearing puller seat and turn down to the set as it will be. Tighten the bearing nut.

AUTOMATIC TRANSMISSION

<p>7B-A. TROUBLE DIAGNOSIS AND ADJUSTMENT 7B : 2</p> <p>7B-B. ITEMS TO CHECK AND ADJUST 7B : 2</p> <p style="padding-left: 20px;">7B-B-1. Torque Converter Oil 7B : 2</p> <p style="padding-left: 40px;">a. Oil level check 7B : 2</p> <p style="padding-left: 40px;">b. Oil leakage check 7B : 2</p> <p style="padding-left: 40px;">c. Oil condition check 7B : 2</p> <p style="padding-left: 20px;">7B-B-2. Engine Idling Speed 7B : 2</p> <p style="padding-left: 20px;">7B-B-3. Kick-Down Switch and Down Shift Solenoid 7B : 2</p> <p style="padding-left: 20px;">7B-B-4. Manual Linkage 7B : 3</p> <p style="padding-left: 20px;">7B-B-5. Inhibitor Switch 7B : 3</p> <p>7B-C. DIAGNOSTIC TEST ITEMS 7B : 4</p> <p style="padding-left: 20px;">7B-C-1. Stall Test 7B : 4</p> <p style="padding-left: 40px;">a. Stall test procedure 7B : 4</p> <p style="padding-left: 40px;">b. Judgement 7B : 4</p> <p style="padding-left: 20px;">7B-C-2. Road Test 7B : 5</p> <p style="padding-left: 40px;">a. Shift point check 7B : 5</p> <p style="padding-left: 40px;">b. Shift point check procedure 7B : 5</p> <p style="padding-left: 40px;">c. Other checks in driving 7B : 5</p> <p style="padding-left: 20px;">7B-C-3. Oil Pressure Test 7B : 6</p> <p style="padding-left: 40px;">a. Line pressure test 7B : 6</p> <p style="padding-left: 40px;">b. Line pressure test procedures 7B : 6</p> <p style="padding-left: 40px;">c. Diagnosis from measurements 7B : 6</p> <p style="padding-left: 40px;">d. Governor pressure test 7B : 6</p> <p>7B-D. TROUBLE DIAGNOSIS CHART 7B : 7</p> <p style="padding-left: 20px;">7B-D-1. Items to Check 7B : 7</p> <p style="padding-left: 20px;">7B-D-2. Trouble Diagnosis Chart 7B : 7</p> <p>7B-E. REMOVAL OF TRANSMISSION 7B : 9</p>	<p>7B-F. DISASSEMBLY OF TRANSMISSION COMPLETE 7B : 10</p> <p style="padding-left: 20px;">7B-F-1. Disassemble Procedure 7B : 10</p> <p>7B-G. OVERHAUL OF MAIN COMPONENTS 7B : 11</p> <p style="padding-left: 20px;">7B-G-1. Torque Converter 7B : 11</p> <p style="padding-left: 20px;">7B-G-2. Front Clutch Assembly 7B : 11</p> <p style="padding-left: 20px;">7B-G-3. Rear Clutch Assembly 7B : 12</p> <p style="padding-left: 20px;">7B-G-4. Low and Reverse Brake Assembly 7B : 13</p> <p style="padding-left: 20px;">7B-G-5. Band Servo 7B : 14</p> <p style="padding-left: 20px;">7B-G-6. Governor Valve Assembly .. 7B : 15</p> <p style="padding-left: 20px;">7B-G-7. Oil Pump Assembly 7B : 16</p> <p style="padding-left: 20px;">7B-G-8. Control Valve Assembly 7B : 17</p> <p style="padding-left: 20px;">7B-G-9. Bearing and Bearing Race... 7B : 18</p> <p style="padding-left: 20px;">7B-G-10. Other Component Parts 7B : 18</p> <p style="padding-left: 40px;">a. Front planet carrier assembly rear planet carrier assembly, input shaft and output shaft 7B : 18</p> <p style="padding-left: 40px;">b. Shell and sun gear assembly 7B : 19</p> <p style="padding-left: 40px;">c. Internal drive flange assembly 7B : 19</p> <p style="padding-left: 40px;">d. Connecting drum assembly 7B : 19</p> <p style="padding-left: 40px;">e. Manual control system and parking lock system 7B : 19</p> <p>7B-H. REASSEMBLY OF TRANSMISSION ... 7B : 19</p> <p>7B-I. INSTALLATION AND ADJUSTMENT OF TRANSMISSION 7B : 22</p> <p>SERVICE SPECIAL TOOLS 7B : 23</p>
---	--



AUTOMATIC TRANSMISSION MODEL R3A (JATCO)

7B-A. TROUBLE DIAGNOSIS AND ADJUSTMENT

In trouble-shooting an automatic transmission it is necessary first of all to correctly define a faulty phenomenon, and then make efficient and orderly check to determine possible causes so that a proper remedy can be effected.

To grasp a faulty phenomenon, check whether the automatic transmission functions normally in all aspects under all conditions including starting, running and stopping. Find out a corresponding trouble from among the troubles in the TROUBLE DIAGNOSIS CHART, and check "Items to Check" in the sequence as indicated.

In diagnosing according to the TROUBLE DIAGNOSIS CHART, make sure to first check and adjust the following items (described in 7B-B):

1. Oil level
2. Idling speed
3. Down-shift solenoid and kickdown switch
4. Manual linkage
5. Inhibitor switch

It is meaningless to proceed to check other items without checking the above items carefully.

In the case of the automatic transmission particularly, there are a great number of troubles which can be solved by inspecting and regulating the above items with the transmission mounted on the vehicle.

So do not remove or disassemble the transmission without checking such items first. Also there are some troubles which require further detailed diagnostic tests including stall test, road test and hydraulic pressure test before removing the transmission from the vehicle. Such tests are described in 7B-C.

If a trouble should prove not correctable by inspection, adjustments and repairs made according to TROUBLE DIAGNOSIS CHART with the transmission installed, that is, if removal and overhauling are indicated by diagnosis, only then, the transmission should be removed and overhauled in the procedure mentioned later.

7B-B. ITEMS TO CHECK AND ADJUST**7B-B-1. Torque Converter Oil****a. Oil level check**

Put the vehicle on a level surface and run the engine approximately two minutes at 1,200 rpm. Then move the manual lever through all driving ranges applying brake with the engine idling condition. Place the manual lever in "P". Insert the dipstick fully and take it out quickly before splashing oil adheres to the gauge, and then observe the level on the dipstick. The oil level must be somewhere between L and F marks and never be outside the limits.

Note :

1. The recommended oil is Genuine Automatic Transmission Fluid M2C33F (Type F) or Automatic Transmission Fluid M2C33F (Type F) of any make. Do

not mix with other type of automatic transmission fluid than mentioned above.

2. Periodic oil change is not necessary, but the oil level must be checked at least every 6,000 km (4,000 miles).

3. The total amount of oil is 6.2 liters (13.1 U.S. pints, 10.9 Imp. pints, 6.6 U.S. quarts) and the difference between the amounts shown by L and F marks on the dipstick is about 0.45 liter (1.0 U.S. pints, 0.8 Imp. pints, 0.5 U.S. quart).

b. Oil leakage check

When the oil level is lower than specified, add it and at the same time check carefully for possible leaks and repair any if found.

Note :

1. Torque converter oil is of a red-wine color and is distinguishable from engine oil.

2. In checking for possible leak from the transmission breather pipe, jack up one of the rear wheels and run the engine to simulate the running condition. When the oil level is over the "F" limit, the oil never fails to spurt out from the breather pipe. When water is contained in it, the oil sometimes spurts out even when the oil level is within the specified range.

c. Oil condition check

In checking the condition of oil by the oil sticking on the dipstick, note that, if the oil appears like varnish, it might cause control values to stick, and if it is black, it shows that linings of clutch or brake band have been scorched. In case such oil deterioration is found severe, it sometimes indicates that overhaul should be made without conducting tests listed in TROUBLE DIAGNOSIS CHART. If it is difficult to readily determine whether or not to make such tests, oil should be drained for confirmation.

7B-B-2. Engine Idling Speed

The engine idling speed should be properly adjusted to the specified revolution by using a tachometer for servicing rather than the one installed on the vehicle. If the engine idling speed is too low, the engine cannot revolve smoothly and when it is too high, shifts from "N" or "P" to other ranges will be harsh with increased shock or creep. Adjust the engine idling speed to 750 rpm in "D" range.

7B-B-3. Kick-down Switch and Downshift Solenoid

Position the ignition switch at the first stage after making sure that the accelerator pedal goes through the entire stroke properly. Depress the accelerator pedal as far as it goes. As the throttle nears the wide-open position, the contact point of the kick-down switch is closed with a light click from the solenoid.

The kick-down switch must begin to operate in between 7/8-15/16 of the entire pedal travel or full




Fig. 7B-2 Kick-down switch and down shift solenoid

throttle. If not, adjust the kick-down switch. If the solenoid should not make any clicking sound it indicates some abnormality, so check with a tester must be made.

Note :

When the solenoid is removed for replacing, some one liter of fluid leaks out. So a receptacle should be made ready to catch it.

7B-B-4. Manual Linkage

The adjustment of linkage is equally important as "Inspection of oil level" for the automatic transmission. Therefore, great care should be exercised because defective adjustment will result in the breakdown of the transmission.

Pull the manual lever toward you and turn it so far as "P" to "1" range, where clicks will be felt by hand. This is the detent of manual valve in the body, and indicates the correct position of the lever. Inspect whether the pointer of selector dial corresponds to this point, and also whether the lever comes in alignment with the stepping of position plate when it is released.

When the position of the manual lever is found incorrect, disconnect the T joint on the lower rod, and place in "N" the range select lever on the transmission (where the slot of the manual shaft is positioned vertically).




Fig. 7B-3 Manual linkage

Adjust the position of the manual lever by turning the T joint so as to position the manual lever in "N". Finally make sure that the lever travels to "P" and "1" ranges correctly. Check at the same time to see that the linkage has no looseness.

7B-B-5. Inhibitor Switch

The inhibitor switch permits the reverse lamp to light up only when "R" range is selected and the starter motor to revolve only when the lever is in "N" or "P" position, so that when "D", "2" or "1" is selected, the reverse lamp does not light up and the starter motor cannot revolve.

If any abnormality is found in any range, check and adjust the manual linkage; if the manual linkage is found normal, then check the inhibitor switch.

Engage the manual lever in each range and check the connection of the inhibitor switch with a tester. Check also the extent through which the electrical connection is made for "R", "N" and "P". If anything wrong is revealed as a result of the conductivity check of the inhibitor switch, make adjustments in the following procedures.

1. Adjust the select lever so that the clearance between pin and guide plate will be 0 ~ 0.3 mm when the lever is in "N" position by using the adjusting nut "B" of the rod.
2. Adjust the inhibitor switch so that the pin hole of the switch body will be aligned with the pin hole of the sliding plate when the select lever is in "N" position.
3. The starter switch should turn on only when "N" and "P" range are selected.




Fig. 7B-4 Inhibitor wiring

Color	Function
GL	Warning lamp "P" ~ Inhibitor switch
GB	Warning lamp "N" ~ Inhibitor switch
GR	Warning lamp "D" ~ Inhibitor switch
GW	Warning lamp "2" ~ Inhibitor switch
G	Warning lamp "1" ~ Inhibitor switch
BY	Starter switch ~ Inhibitor switch
RY	Reverse lamp ~ Inhibitor switch
GY	Fuse box Ig. ~ Inhibitor switch
BY	Key switch St. ~ Inhibitor switch




Fig. 7B-5 Inhibitor switch




Fig. 7B-6 Inhibitor switch

7B-C. DIAGNOSTIC TEST ITEMS

Make sure that all the inspection items described in 7B-B are normal before starting the diagnostic tests—stall test, road test and oil pressure test.

7B-C-1. Stall Test

The purpose of this test is to check the transmission and engine for trouble by measuring the maximum numbers of the engine revolutions while the vehicle is held in a stalled condition and the carburetor is in full throttle operation with the manual lever in ranges "D", "2", "1" and "R" respectively and by comparing the measured results with the standard values.

The specified stall revolution is in the following table.

Stall revolution (rpm)	
In breaking in	After breaking in
2,400 ~ 2,650	2,450 ~ 2,700

a. Stall test procedure

1. Check the levels of engine coolant, engine oil and torque converter oil. Warm up the engine at about 1,200 rpm for several minutes with the manual lever

in "P" in order to heat the torque converter oil to a suitable temperature of 60° ~ 100°C (140° ~ 212°F).
2. Mount the engine tachometer at a location that allows good visibility from the driver's seat and put a mark on specified revolutions on the meter.

3. Secure the front and rear wheels completely with chocks and apply the hand brake. Be sure to depress the brake pedal firmly with the left foot before depressing down the accelerator pedal.

4. Place the manual lever in "D" range.

5. Gradually step on the accelerator pedal to the wide-open position. As soon as the engine speed becomes constant, read the engine speed and release the accelerator pedal.

6. Place the manual lever in "N" or "P" and run the engine at about 1,200 rpm for more than one minute to cool down the torque converter oil and coolant.

7. Proceed to do the stall test for "2", "1" and "R" in the same manner as for "D".

Note :

The stall test operation as specified in the item (5) should be made within five seconds. If it takes too long, the oil deteriorates and the clutches, brake and band are adversely affected. Sufficient cooling time should be given between each test for the four ranges "D", "2", "1" and "R".

b. Judgement

By comparing the measured stall speed and the specified one, troubles can be surmised as follows :

1. Standard stall revolution

Both transmission control elements and engine performance are normal, and the one-way clutch of the torque converter is not slipping though whether or not there is sticking is unknown.

* In the road test, if the maximum speed cannot be attained and the torque converter oil is found to be at unusually high temperature, the one-way clutch of the torque converter is diagnosed to be sticking.

2. High stall revolution more than standard revolution.

If the engine revolution in stall condition is higher than the standard values, it indicates that one or more clutches in the transmission are slipping and, therefore, no further test is required. For the following abnormalities, the respective causes are presumed.

High rpm in all ranges

Line pressure is low or all clutches, brake and band are slipping.

High rpm in "D", "2" and "1" (normal in "R")

The rear clutch is slipping.

High rpm in "D" (normal in "2", "1" and "R")

The one-way clutch is slipping.

High rpm in "R" (normal in "D", "2" and "1")

The front clutch or the low and reverse brake is slipping.

* In the road test, if there is no engine braking in "1" range, the low and reverse brake is slipping, and if there is engine braking in "1" range, the front clutch is slipping.

High rpm in "2" (normal in "D", "1" and "R")

The band is slipping.

3. Low stall revolution less than standard

The one-way clutch of the torque converter is slipping, or the engine performance is poor.

* In the road test, if poor acceleration is noted at various speeds, indicates poor engine performance or incorrect engine adjustment. In case the starting acceleration is poor while acceleration at high speeds is normal, the one-way clutch of the torque converter is slipping.

7B-C-2. Road Test

An accurate knowledge of the automatic transmission is prerequisite to its exact diagnosis by a road test.

The purpose of road test is to make a comprehensive check of the transmission under varying running conditions to detect and analyze troubles and to clear up the cause of troubles.

a. Shift Point Check

Check to see that the up-shift and down-shift occur within the range specified in the shift point table below, following the checking procedures.

b. Shift point check procedure

1. Make sure that the tire air pressure is in the standard range and preheat the converter oil to appropriate temperature about 60 ~ 100°C (140 ~ 212°F) in engine idling condition.

2. Place the manual lever in "D" range and accelerate in wide open throttle (kick-down switch energized), and read the car speed at the instant of D₁ → D₂ and D₂ → D₃ up-shifts with speedometer which is installed on this car.

3. Drive the car with the manual lever in "D". When it is running at a constant speed in D₃, depress the accelerator pedal to the full (the kickdown switch energized) and make sure that D₃ → D₂ shift occurs. Continue this check at higher speeds until a critical speed from which that down-shift does not occur any more is reached. Proceed to check the critical speed for D₂ → D₁ kick-down by using the same method. Shift-down can be noted by a shift shock or change in engine sound.

4. When the car is running in D₃ at a speed about 60 km/h (45 mile/h), release the accelerator pedal completely and read the car speed just when D₃ → D₁ down shift occurs at the fully closes throttle condition.

5. When the car is running in D₃ at a speed more than 60 km/h (45 mile/h), place the manual lever from "D" into "1", and read the car speed just when I₂ → I₁ downshift occurs.

Note :

Care must be taken not to shift from "D" to "1" (from "2" to "1") in exceeding the speed in "2" range ("1" range) shown below to avoid the engine overrun.

Engine Max. speed (rpm)	"1" Range	"2" Range
	Mile/h	Mile/h
6,500	40	70

6. Connect a vacuum gauge into the socket in the intake manifold and set it so that it is visible while driving. Place the manual lever in "D" and accelerate with accelerator pressure controlled so that the vacuum gauge will show 200 mm-kg, and read car speed at the instant of D₁ → D₂ and D₂ → D₃ upshifts.

Note :

1. In reading car speeds at shifting, acceleration and deceleration around shift points must be made gently except for (2) above.

2. Checks of (2), (3) and (4) above should indicate general condition of shift point except in very rare instances. Item (6) should be carried out only when the condition in partial throttle must be known.

Car Speed at Gear Shift

Throttle Condition	Gear Shift	Model and Shift Speeds Mile/h
Kick-down (0 ~ 100 mm-Hg) (0 ~ 3.94 in-Hg)	D ₁ → D ₂	30 ~ 44
	D ₂ → D ₃	55 ~ 74
	D ₃ → D ₂	48 ~ 62
	D ₂ → D ₁	21 ~ 31
Half throttle (190 ~ 210 mm-Hg) (7.48 ~ 8.27 in-Hg)	D ₁ → D ₂	7 ~ 17
	D ₂ → D ₃	17 ~ 37
Fully closes throttle	D ₃ → D ₁	6 ~ 11
Manual 1	I ₂ → I ₁	25 ~ 32

Note :

The shift speeds in the above table include the permissible allowance of a speedometer on the car. Therefore check the shift speed with the speedometer on the car.

c. Other checks in driving

1. Check each range for faulty performance or shifting. Check to see, for instance, that :

(1) Firm locking is effected when "P" is selected.

(2) Reversing is effected when "R" is selected.

(3) Completely neutral condition is attained by selecting "N".

(4) D₁ ↔ D₂ ↔ D₃ shifts take place in "D" range.

(5) Kick-down takes place.

(6) When "1" is selected from "D", there occur D₃ → I₂ → I₁ or D₃ → I₁ shifts with engine braking effected in I₂ and I₁.

(7) The transmission does not shift up in "I" range.

(8) In "2" range, the transmission is fixed to 2nd speed.

2. Check to see that shifting is smooth without conspicuous shock and there is no marked creep. (Slight creep in each range is normal.)

3. Check to see that shifts are effected promptly without drag.

4. Check for abnormal gear noise, clutch, band squeal, poor acceleration or oil leak.

7B-C-3. Oil Pressure Test

When there is slippage in the gear train or when shifts do not feel proper, line pressure and governor pressure must be checked.

The following chart shows standard line pressures (before cut back).

Manual Range	Line Pressure kg/cm ² (lb/in ²)	
	Engine Idling	Stall
"R"	4.0 ~ 7.0 (57 ~ 100)	15.5 ~ 19.0 (220 ~ 270)
"D"	3.0 ~ 4.0 (43 ~ 57)	9.5 ~ 11.0 (135 ~ 156)
"2"	8.0 ~ 12.0 (114 ~ 170)	10.0 ~ 12.0 (142 ~ 170)
"1"	3.0 ~ 4.0 (43 ~ 57)	9.5 ~ 11.0 (135 ~ 156)

a. Line pressure test

Place the transmission in "D", "2", "1" and "R", and check respective line pressure at engine idling and stall conditions. Compare the results with specified pressures to trace the cause of trouble.

b. Line pressure test procedures

1. Warm up the engine to bring the converter oil to operating temperature 60°~ 100°C (140 ~ 212°F).
2. Line pressure for "R" range is taken out at an inspection hole at the right front of the transmission case, and for "D", "2" and "1" ranges the inspection hole is at the right rear. Connect a pressure gauge to the inspection hole and put it where it is visible from the driver's seat.
3. Firmly check the front and rear wheels and apply the hand brake as in the stall test.
4. With the manual lever put in the range to be checked, run the engine at engine idling condition and read the pressure gauge.
5. With the brake pedal depressed fully, press the accelerator pedal gradually to the wide open position. While checking whether the pressure rises smoothly, read the pressure gauge at the stall condition. The test time from starting accelerator depression to its release must not exceed 5 seconds.
6. Measure line pressure for each of other ranges in the same manner. Be sure to interpose more than one minute cooling time at 1,200 rpm with the manual lever placed in "P" or "N".
7. After above, check whether the cut-back function to release the shock at gear shifting is operative properly. The cut-back function can be judged normal if the line pressure drops suddenly when the car is accelerated gradually and reaches to the certain running speed.

c. Diagnosis from measurements

1. When line pressure at idling is low in all of "R", "D", "2" and "1", possible causes include a fault in the pressure supply system, e.g. increased side clearance in the oil pump, reduced pump output because




Fig. 7B-7 Oil pressure test

- A. For line pressure in "R" range
- B. For line pressure in forward ranges
- C. For governor pressure

of bolts left untightened, oil leak from pump, valve body or transmission case, and sticking of regulator valve or vacuum throttle valve.

2. In case line pressure at idling is low in one range only, there probably are pressure leaks in some devices or oil passages for the relevant range.
3. In case line pressure at idling is high in all ranges, possible cause is throttle pressure rise due to leak from vacuum tube or vacuum diaphragm, or regulator valve sticking.
4. When pressure does not rise at stall condition, the vacuum rod possibly may not be installed.
5. When pressure rise is not smooth or pressure at stall condition does not come within the specified range, possible cause is sticking of vacuum throttle valve, pressure regulator valve or pressure regulator plug.

D. Governor pressure test

Governor pressure has only to be measured when shift point is different from the specified.

Connect a pressure gauge in the inspection hole on the left rear of transmission case, and put it where it is visible during driving. Read governor pressure when the car is going at required speeds for each model. If the result is out of the specified range shown in the following table, disassemble and check the governor valve.

Governor Pressure (1)

Driving speed	Output shaft speed rpm	Standard governor pressure	
		kg/cm ²	lb/in ²
20 mile/h	1,150 ~ 1,240	0.9 ~ 1.4	13 ~ 20
35 mile/h	2,030 ~ 2,150	1.7 ~ 2.4	24 ~ 34
55 mile/h	3,190 ~ 3,350	3.5 ~ 4.5	50 ~ 64

Governor Pressure (2)

Break point	at		
	1,000 rpm	2,000 rpm	3,000 rpm
400~600rpm	0.9~1.3 kg/cm ² (13 ~ 18 lb/in ²)	1.6~2.2 kg/cm ² (23 ~ 28 lb/in ²)	3.0~3.8 kg/cm ² (43 ~ 54 lb/in ²)

7B-D. TROUBLE DIAGNOSIS CHART

7B-D-1. Items to Check

- (1) Inspection with automatic transmission on the car.
 - A. Oil level
 - B. Range select linkage
 - C. Inhibitor switch and wiring
 - D. Vacuum diaphragm and piping
 - E. Downshift solenoid, kick-down switch and wiring
 - F. Engine idling speed
 - G. Oil pressure
 - H. Engine stall speed
 - I. Rear lubrication
 - J. Manual control valve
 - K. Governor valve
 - L. Band servo
 - M. Transmission air check
 - N. Oil drain check
 - O. Ignition switch and starter motor
 - P. Engine adjustment and brake inspection

- (2) Inspection after inspecting automatic transmission on the car.
 - a. Rear clutch
 - b. Front clutch
 - c. Band brake
 - d. Low & reverse brake
 - e. Oil pump
 - f. Leak from hydraulic passages
 - g. One-way clutch in torque converter
 - h. One-way clutch in power train
 - i. Front clutch check ball
 - j. Parking linkage
 - k. Planetary gear

7B-D-2. Trouble Diagnosis Chart

The numerals show the sequence of inspection for detecting trouble.

Trouble	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P	a	b	c	d	e	f	g	h	i	j	k
Engine won't start in "N" and "P" ranges	.	2	3	1
Engine starts in other ranges than "N" and "P" ranges	.	1	2
Excessive shock on "N" → "D" range shift	.	.	.	2	.	1	3	.	.	4	5
Car won't move in "D" range (but moves in "2", "1" and "R" ranges)	.	1	2	.	.	3	4	.	.	.
No drive, excessive slip or very poor acceleration in "D", "2" or "1" range (Driver in "R" range)	1	2	4	.	.	5	.	.	6	3	.	7	8	10	.	.	9	.	.	.
No drive, excessive slip or very poor acceleration in "R" range (but Drives in "D", "2" and "1" ranges)	1	2	3	.	.	5	.	.	6	4	.	.	9	8	.	7	.	10	.	11	.
Car won't move in any range	1	2	3	.	.	5	.	.	6	4	7	8	.	.	9	.
Tendency to slip when starting	1	2	.	6	.	.	3	.	.	5	.	.	7	4	8	9
Car moves in "N" range	.	1	3	.	.	2	4
Maximum speed too low and poor acceleration	1	2	4	5	.	7	.	6	.	3	.	8	.	11	12	9	10	13
Car braked when "R" range is selected	3	2	1	.	.	.	4	.	5	6	.
Excessive creep	1
No creep at all	1	2	.	.	.	3	.	.	.	5	.	.	.	4	.	.	8	9	.	.	6	7
No D1 → D2 change	.	1	.	2	3	5	6	8	7	4	9	.	.	10
No D2 → D3 change	.	1	.	2	3	5	6	8	7	4	9	.	.	10	.	.	11	.	.
D1 → D2 and D2 → D3 shift-points too high	.	.	.	1	2	.	3	.	.	5	6	.	.	4	7
D1 → D3 change without through D2	2	4	.	3	1	5	6	.	.	.
Excessive shock on D1 → D2 change	.	.	.	1	4	.	5	.	3	6

Trouble	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P	a	b	c	d	e	f	g	h	i	j	k
Excessive shock on D2 → D3 change	.	.	.	1	.	.	2	.	.	3	.	5	4	.	.	.	⑥
Practically no shift shock or excessive slip on D1 → D2 change	1	2	.	3	.	.	4	.	.	6	.	8	7	5	.	.	⑨	.	.	⑩
Practically no shock; or excessive slip; or engine runaway on D2 → D3 change	1	2	.	3	.	.	4	.	.	6	.	8	7	5	.	.	⑨	.	.	⑩	.	.	.	⑪	.	.	.
Car braked on D1 → D2 change	2	.	.	1	.	.	.	④	.	③	.	.	.	⑤
Car braked on D2 → D3 change	3	.	2	1	.	.	.	④
No D3 → D2 change	.	.	.	1	3	4	6	5	2	.	.	⑦	⑧	.	.	⑨
No D2 → D1 or D3 → D1 change	.	.	.	1	3	4	6	5	2	.	.	⑦	⑧
Shift shock felt when accelerator is released and deceleration occurs	.	1	.	2	3	.	4	.	.	5	6	⑦
D3 → D2 and D2 → D1 shift-points too high	.	1	.	2	3	.	4	.	.	5	6	⑦
No kick-down on accelerator depression in D3 (within kick-down speed limits)	.	.	.	2	1	4	5	.	3	.	.	.	⑥	.	.	.	⑦
Abnormal rise of engine speed on accelerator depression in D3 (above kick-down upper limit)	.	1	.	2	.	.	3	.	.	5	6	.	7	4	.	.	⑧	.	.	.	⑨
Engine runaway or slip on D3 → D2 change	.	.	.	1	.	.	2	.	.	4	.	6	5	3	.	.	⑦	⑧	.	.	⑨	.	.	⑩	.	.	.
No D3 → 2 change on "D" → "2" range shift	.	1	2	.	.	4	.	5	.	3	.	.	⑥	.	.	.	⑦
2 → 1, 2 → D, or 2 → D3 change in "2" range	.	1	2	.	.	3
No shift shock or engine run-away on "1" → "2" range shift	1	2	.	3	.	4	.	1	.	6	.	.	7	5	⑨	.	⑩
No D3 → 1 change on "D" → "1" range shift	.	1	2	.	.	4	5	7	6	3	.	.	⑧	⑨	.	.	⑩
No engine braking in "1" range	.	1	2	.	.	4	.	.	5	3	⑥	.	⑦
1 → 2 or D2 change, or 2 or D2 → D3 change in "1" range	.	1	2	③
No 12 → 11 change on "D" → "1" range shift	1	2	4	5	6	7	3	⑧	.	⑨
Excessive shift shock on 12 → 11 change in "1" range	.	.	.	1	.	.	.	2	.	4	.	.	3	⑤
Car moves in "P" range, and parking gear not removed when "P" range is disengaged.	.	1	②	.	.
Transmission overheats	1	3	4	2	6	.	8	7	5	.	.	⑨	⑩	⑪	⑫	⑬	⑭	.	.	.	⑮	.
Oil spurting up or white exhaust during running	1	.	.	3	.	.	5	6	2	7	.	.	8	4	.	.	⑨	⑩	⑪	⑫	⑬	⑭	.	.	.	⑮	.
Offensive smell from oil charging pipe	1	2	.	.	.	③	④	⑤	⑥	⑦	⑧	⑨	.	.	.	⑩
Transmission noisy in "P" and "N" ranges	1	2	③
Transmission noisy in "D", "2", "1" and "R" ranges	1	2	③	.	.	④	.	⑤	.	.	.	⑥	.

7B-E. REMOVAL OF TRANSMISSION

When dismantling the automatic transmission from a vehicle, pay attention to the following point.

Before dismantling the transmission, rigidly inspect it by aid of the "Trouble Diagnosis Chart", and dismount it only when considered to be necessary. The transmission should be removed in the following sequence :

1. Remove the battery earth.
2. Remove the power brake vacuum pipe clip from the converter housing. (Left hand drive vehicles only)
3. Remove the service hole cover. To lock the drive plate, apply the wrench to the drive pulley lock bolt. Loosen and remove four bolts that attach the torque converter to the drive plate by using the **special wrench** (49 0877 435). At the same time, make aligning mark across torque converter and drive plate.
4. Jack up the vehicle and support it with safety stands.
5. Remove the screws attaching the heat insulator to the exhaust pipe and remove the heat insulator.
6. Remove the bolt and nut attaching the exhaust front pipe to the exhaust pipe bracket. Disconnect the exhaust front pipe flange from the exhaust manifold by removing nuts. Remove the bolts and nuts attaching the exhaust front pipe flange to the main silencer, and remove the exhaust front pipe.
7. Remove the bolts attaching the heat insulator to the underbody and remove the heat insulator.
8. Remove the four propeller shaft attaching bolts and remove the center bearing attaching bolts. Then pull it out from the extension housing. Apply a plug to prevent oil leak.




Fig. 7B-8 Removing propellar shaft

9. Disconnect the speedometer cable from the extension housing.
10. Disconnect the control rod by removing snap ring.
11. Disconnect the wirings from the starting motor. Loosen the upper and lower bolt attaching the starting motor to the converter housing and remove the starting motor.
12. Remove the undercover (or service cover) on the converter housing.
13. With the transmission supported with the transmission holder, remove the tightening nuts of the




Fig. 7B-9 Removing speedometer cable

transmission member and take out the member. Then lower the transmission holder, widen the clearance between the transmission and the floor.

14. Remove the vacuum union bolt from the inlet manifold. Remove the vacuum pipe clips from the converter housing, transmission case and extension housing. Disconnect the vacuum hose from the vacuum diaphragm and remove the vacuum pipe.
15. Disconnect the wire connections of down-shift solenoid and remove the wires from the clip.
16. Disconnect the feed pipe and return pipe for cooling on the left side of the transmission. Remove the feed pipe and return pipe clips from the converter housing and transmission case.




Fig. 7B-10 Removing pipes

17. Loosen and remove the bolts that connect the engine and the torque converter housing to disconnect the transmission and engine.




Fig. 7B-11 Bolts on engine & converter housing

18. Return the transmission to the level position. While slowly plying a screw driver or something between the converter and the drive plate, pull out the transmission rearward with the converter attached to it. Then lower the holder and dismount the transmission.

7B-F. DISASSEMBLY OF TRANSMISSION COMPLETE

Attention must be paid to the following matter in disassembling the transmission :

- (1) Clean the outside of the transmission thoroughly before overhauling. In case of that, see that the steam does not enter the transmission and the gasoline is not used in using rubber parts.
- (2) Disassembly should be made in a clean workshop, preferably in a dust-proof workshop.

7B-F-1. Disassembly Procedure

1. Remove the torque converter from the housing taking care not to have the converter oil spill. Then tilt the transmission housing and drain the oil in the oil pan through the end of the extension housing into a vessel.
2. Loosen the bolt for the oil gauge tube and remove it together with the "O" ring.
3. Remove the connecting rod attached to the range select lever.
4. Loosen and remove the bolts that attach the converter housing and the transmission case, and remove the converter housing.




Fig. 7B-12 Bolts on converter housing




Fig. 7B-13 Removing extension housing

5. Loosen and remove the bolts that attach the extension housing and the transmission case, and pull out the extension housing rearward taking care so that the washer does not fall down. Then remove the parking pawl, spring and washer. Remove the gasket from the transmission case.

6. Loosen and remove out the oil pan bolts and take out the oil pan and the gasket.

7. Turn the downshift solenoid and the vacuum diaphragm unit by hand and remove them together with "O" rings. Take care not to forget taking out the vacuum diaphragm rod.




Fig. 7B-14 Removing downshift solenoid

8. Remove the control valve assembly by loosening out nine attaching bolts.




Fig. 7B-15 Control valve body ass'y setting bolts

9. Remove the nut attaching the range select lever to the manual shaft and remove the select lever.

10. Disconnect the parking rod from the parking lever by removing snap ring.

Loosen the nut attaching the manual plate to the manual shaft and remove the manual shaft from the transmission case tapping the manual shaft with the plastic hammer. Then, take out the manual plate, washer, nut and parking rod.

11. Pull out the input shaft.

12. Remove the bolts that attach the band servo cover to the servo retainer and remove the servo cover.

13. Loosen lock nut on piston stem. Then tighten piston stem in order to prevent to fall front clutch drum down when oil pump is withdrawn.

14. Pull out the oil pump with the **oil pump remover** (49 0378 390) and remove the gasket.




Fig. 7B-16 Removing oil pump

15. Loosen the piston stem and take out the band strut.

16. Loosen and remove the anchor bolt from the transmission case.

17. Remove the following as one set: band, front clutch assembly, rear clutch assembly, front planet carrier assembly with sun gear.




Fig. 7B-17 Removing clutch ass'y

18. Take out the rear planet carrier by removing the snap ring which fastens the rear planet carrier to the connecting drum.

19. Take out the output shaft snap ring and the internal drive flange.




Fig. 7B-18 Removing snap ring

20. Turn left the connecting drum as far as it goes and make sure it is firmly locked. Then turn it right and remove together with the one-way clutch.

21. Remove the snap ring that secures the speedometer drive gear to the output shaft. Slide the drive gear off the output shaft, and remove the lock ball.

22. Pull out the output shaft rearward. Then remove the oil distributor together with governor and take out the needle bearing remaining on the transmission case side.

The above operations complete the disassembly of the principal transmission parts excepting the low-reverse brake which still remain on the transmission case. The low-reverse brake can of course be removed from the transmission case but the disassembling operations of it are described in the next section dealing with overhaul of principal components.

7B-G. OVERHAUL OF MAIN COMPONENTS

The principal components each include a large number of similar parts finished to high precision. So all related parts of each component should be placed apart from others to avoid confusion. Overhaul should be made in the following sequence. (Bearings and bearing races must be checked with respect to parts to which they are mounted.)

7B-G-1. Torque Converter

1. The torque converter is welded all along the circumference and so cannot be disassembled.

To Inspect

1. Check for external damages, oil leak, distortions, dents, etc., and replace if necessary.

Note :

If the converter oil is found markedly degenerated or fouled, thoroughly rinse the inside of the converter with approximately 0.5 liter (1.0 U.S. pints, 0.5 U.S. quart, 0.9 Imp. pint) of cleaning solvent (none-lead gasoline or kerosene) and make it drain for half an hour with the rear side of the converter facing down. Then fill it with converter oil and stir it well and drain it again in the same procedure.

7B-G-2. Front Clutch Assembly

To Remove

1. Remove the snap ring with a screw driver or something, then take out the retaining plate, inner plates, outer plates and dished plate.

2. Remove the coil spring retainer snap ring by using the **clutch spring compressor** (49 0378 375).

3. Remove the coil spring retainer and 10 coil springs.

4. Remove the piston by blowing compressed air into the oil hole as shown in Fig. 7B-21.

To Inspect

1. Check the inner and outer plates for worn or damaged facings.

2. Check to see that the coil spring retainer is not deformed.

3. Check to see that the coil spring has not lost tension.




Fig. 7B-19 Front clutch ass'y

- | | |
|----------------------|--------------------|
| 1. Piston | 6. Inner plate |
| 2. Front clutch drum | 7. Snap ring |
| 3. Outer plate | 8. Spring retainer |
| 4. Snap ring | 9. Coil spring |
| 5. Retaining plate | 10. Dished plate |



Fig. 7B-20 Removing snap ring



Fig. 7B-21 Blowing out piston

4. Check to see that the seal around the piston and the "O" ring inside the clutch drum are not damaged.
5. If defective parts are found, replace them with new ones.

To Reassemble

1. All parts are smeared with converter oil and re-assembled in the reverse sequence of the disassembly.

2. Measure the clearance between the snap ring and retaining plate with a thickness gauge after reassembly and selectively use a retaining plate to provide the standard clearance 1.6 ~ 1.8 mm (0.062 ~ 0.071 in).



Fig. 7B-22 Measuring clearance

Note :

To adjust above clearance, the retaining plate comes in the following six thicknesses.

- | | |
|--------------------|-------------------|
| 7.2 mm (0.283 in), | 7.4 mm (0.291 in) |
| 7.6 mm (0.299 in), | 7.8 mm (0.307 in) |
| 8.0 mm (0.315 in), | 8.2 mm (0.323 in) |

3. Install the front clutch assembly to the oil pump. Blow compressed air into the oil hole as shown in Fig. 7B-23 and check the clutch operation.




Fig. 7B-23 Testing front clutch

7B-G-3. Rear Clutch Assembly

To Remove

1. Remove the snap ring, retaining plate, outer plates, inner plates and dished plate in the same procedure as for the front clutch assembly.
2. Remove the coil spring retainer snap ring by the use of the clutch spring compressor (49 0378 375). Then remove the coil spring retainer and 10 coil springs.
3. Remove the piston by blowing compressed air into the oil hole.

To Inspect

1. Make the same inspection as for the front clutch



Fig. 7B-24 Blowing out piston

assembly and replace any defective parts with new ones.

To Reassemble

1. All parts are reassembled with converter oil smeared in the reverse sequence of the disassembly, as in the case of the front clutch.
2. After reassembly, check to see that the clearance between the snap ring and retaining plate is within the standard range of 0.8 ~ 1.5 mm (0.032 ~ 0.059 in).




Fig. 7B-25 Measuring clearance

3. Install the rear clutch assembly to the oil pump and check the clutch operation by blowing compressed air into the oil hole as shown in Fig. 7B-26.




Fig. 7B-26 Testing rear clutch




Fig. 7B-27 Rear clutch ass'y

- | | |
|---------------------|--------------------|
| 1. Piston | 6. Inner plate |
| 2. Rear clutch drum | 7. Snap ring |
| 3. Outer plate | 8. Spring retainer |
| 4. Snap ring | 9. Coil spring |
| 5. Retaining plate | 10. Dished plate |

7B-G-4. Low and Reverse Brake Assembly




Fig. 7B-28 Low & reverse brake

- | | |
|--------------------|-------------------------|
| 1. Snap ring | 7. Bolt |
| 2. Retaining plate | 8. Snap ring |
| 3. Friction plate | 9. Piston return spring |
| 4. Steel plate | 10. Spring ring |
| 5. Dished plate | 11. Piston |
| 6. Inner race | |

To Remove

1. Remove the snap ring of the low and reverse brake. Remove the retaining plate, friction plates, steel plates and dished plate.
2. The inner race of the one-way clutch is tightened with 8 bolts from the rear of the case. Loosen and remove all the bolts using the hex-head extension (49 8000 040), then remove the inner race, snap ring, piston return spring and ring.
3. Remove the piston by blowing compressed air into the low and reverse brake oil hole located at the rear of the transmission case.

To Inspect

1. Check the friction and steel plates for worn or damaged facing.



Fig. 7B-29 Blowing out piston

2. Check to see that the piston return spring has not lost tension.
3. Check to see that there is no deformation on the snap ring (stopper) for piston return spring, attached on the one-way clutch inner race.
4. Check to see that the seal rubber on the inside and outside of the piston are not damaged.
5. If any defective part is found, replace with new one.

To Reassemble

1. Lubricate the piston with converter oil and install it into the transmission case.
2. Install the return spring support ring, return spring, snap ring and one-way clutch inner race on the piston in this order. Then tighten the inner race, from rear of the case, with eight bolts by using the hex-head extension (49 8000 040) to a specified torque of 1.3 ~ 1.8 m-kg (10 ~ 13 ft-lb).




Fig. 7B-30 Tightening inner race

3. Reassemble the dished plate, steel plates, friction plates and retaining plate in the reverse order, smearing each with converter oil. Then fit the snap ring.
4. After reassembly, measure the clearance between the snap ring and retaining plate and select the retaining plate to provide a standard clearance of 0.8 ~ 1.05 mm (0.032 ~ 0.042 in).

Note :

To adjust above clearance the retaining plate is available in the following six thicknesses.

- 11.8 mm (0.466 in), 12.0 mm (0.472 in),
- 12.2 mm (0.480 in), 12.4 mm (0.488 in),
- 12.6 mm (0.496 in), 12.8 mm (0.504 in)




Fig. 7B-31 Measuring clearance

5. Check the operation of the low and reverse brake by blowing air into the oil hole as shown in Fig. 7B-29.

7B-G-5. Band Servo




Fig. 7B-32 Cross-sectional of servo

- | | |
|----------------------|---------------|
| 1. Release pressure | 6. Retainer |
| 2. Return spring | 7. Cover |
| 3. Piston stem | 8. Washer |
| 4. Apply pressure | 9. Adjust nut |
| 5. Transmission case | 10. Piston |

To Remove

1. Loosen and remove three bolts that attach the band servo retainer to the transmission case, and remove the band servo retainer together with the servo piston. Take out the return spring. If the servo retainer is difficult to disconnect from the case, it can be readily removed by blowing air into the oil hole on the piston release side.
2. Blow compressed air into the oil hole on the apply side of the servo piston to remove the piston from the retainer.




Fig. 7B-33 Band servo

- | | |
|------------------|----------------|
| 1. Retainer | 4. Adjust nut |
| 2. Piston | 5. Washer |
| 3. Return spring | 6. Piston stem |



Fig. 7B-34 Blowing out piston

To Inspect

1. Check to see that two "O" rings on the servo retainer and the seal rubber on the servo piston are not damaged.
2. Check to see that there are no damages on the servo retainer, piston, piston stem and the portion of transmission case where those parts are fitted.
3. Check the return spring for decline or deformation.
4. Check the brake band lining for wear or damages.




Fig. 7B-35 Checking band servo (1)

To Reassemble

1. Apply converter oil on all parts and reinstall them in the reverse order of disassembly.
2. Blow compressed air into the oil hole on the servo piston apply side to make sure that the piston operates properly, as in Fig. 7B-35.
3. Back off the three attaching bolts slightly and uniformly, and apply compressed air into the oil hole on the servo piston release side, as in Fig. 7B-36. If the retainer rises by the extent of bolt backing off, the piston operation on release is normal. Tightening torque of the servo retainer is 1.0 ~ 1.5 m·kg (7.3 ~ 10.8 ft·lb).




Fig. 7B-36 Checking band servo (2)

7B-G-6. Governor Valve Assembly




Fig. 7B-37 Cross-sectional view of governor

- | | |
|--------------------|------------------------|
| 1. Primary valve | 4. Governor valve body |
| 2. Oil distributor | 5. Secondary valve |
| 3. Output shaft | |

To Remove

1. Loosen and remove four bolts that attach the governor. Remove the governor from the oil distributor.
2. Remove the secondary governor retainer plate. Then remove the spring and secondary governor valve from the body.
3. Remove the primary governor valve in the same procedure as for the secondary, if primary governor is to be disassembled for any purpose.




Fig. 7B-38 Governor valve

- | | |
|--------------------|-------------------|
| 1. Oil distributor | 5. Primary valve |
| 2. Secondary valve | 6. Spring |
| 3. Spring | 7. Retainer plate |
| 4. Valve body | |

To Inspect

1. Check the valve and the body to see that there is nothing that may cause valve sticking or catching.
2. Check to see that the spring has not lost tension and the retainer plates are not deformed.
3. Check the side clearance between the sealing and groove as shown in Fig. 7B-39. The standard clearance is $0.04 \sim 0.16$ mm ($0.002 \sim 0.006$ in). When disassembling the seal ring, squeeze it up so that its joint will rise above the groove, and disconnect the joint.




Fig. 7B-39 Clearance of oil seal ring

To Reassemble

1. Lubricate all parts with converter oil and reinstall them in the reverse order of disassembly so as not to confuse primary with secondary. After reassembly, make sure that the governor spring is straight and there is no catch in the governor valve movement.
2. Tighten the governor to the oil distributor with four bolts to a standard torque of $0.50 \sim 0.70$ m·kg ($3.6 \sim 5.1$ ft·lb).
3. To determine if secondary governor is in good condition, blow air under light pressure into line pressure hole in Fig. 7B-37 to listen for noise like a model plane.

7B-G-7. Oil Pump Assembly

To Remove

1. Disconnect the pump cover from the pump housing by loosening five bolts that attach them.
2. Take out the inner gear and the outer gear from the pump housing. At the same time, put a sign indicating the installing side with quick-dry ink or something and not with a punch, to avoid erroneous assembly.

To Inspect

1. Check to see that tooth faces of the inner and outer gears are not damaged or worn.
2. Check the side play of the inner (or outer) gear by using a straight edge and thickness gauge as in Fig. 7B-40. The standard value is $0.02 \sim 0.04$ mm ($0.001 \sim 0.002$ in). If the clearance exceeds 0.08 mm (0.003 in), replace the gears with those selected from the three kinds. Make sure that the inner and outer gears are replaced as a set.



Fig. 7B-40 Measuring clearance (1)

3. Check the clearance between the outer gear teeth and crescent. The standard value is $0.14 \sim 0.21$ mm ($0.006 \sim 0.008$ in). If the clearance exceeds 0.25 mm (0.010 in), replace the gears.



Fig. 7B-41 Measuring clearance (2)

4. Check the clearance between the outer gear and the housing. The standard value is $0.05 \sim 0.20$ mm ($0.002 \sim 0.008$ in). If the clearance exceeds 0.25 mm (0.010 in), replace the gears as a set.



Fig. 7B-42 Measuring clearance (3)

5. Check to see that the seal rubber attached on the pump housing periphery is not damaged.
6. Check to see that the oil seal lip is not damaged and the spring has not lost tension.
7. Check to see that the seal rings of oil feed grooves for the front and rear clutches are not damaged or lost tension. Measure the side clearance of the seal ring. The standard valve is $0.04 \sim 0.16 \text{ mm}$ ($0.002 \sim 0.006 \text{ in}$). When replacing seal ring refer to part 7B-G-6.
8. Check to see that the pump housing and the cover are not damaged.
9. If any defective part is found, replace with new one.

To Reassemble

1. Fix the pump housing to the oil pump assembling guide (49 0378 405) and fit the inner gear and outer gear in the pump housing as were installed in original. Then fit the pump cover as shown in Fig. 7B-43 and tighten it temporarily with five bolts.



Fig. 7B-43 Assembling oil pump

2. After removing the pump assembly from the oil pump assembling guide, tighten the bolts finally with specified torque $0.6 \sim 0.8 \text{ m}\cdot\text{kg}$ ($4.3 \sim 5.8 \text{ ft}\cdot\text{lb}$).

7B-G-8. Control Valve Assembly

The control valves are composed of the most accurate of the automatic transmission parts and so particular care must be paid in disassembly and reassembly. Also, since a number of similar parts are used, they

must be arranged in the order of disassembly to facilitate reassembly.

To Remove

1. Loosen and remove the bolts and nut, that attach the oil strainer, and remove the oil strainer. In loosening the 8 mm bolt, a box wrench should be used as much as possible although a screw driver can be used.
2. Disconnect the lower valve body, separate plate and upper valve body by removing the attaching bolts. When taking out the separate plate, be careful not to lose the orifice check valves and springs in the lower valve body.




Fig. 7B-44 Removing separate plate

3. Take out the manual valve.
4. Remove the side plate "A", then take out the 1-2 shift valve with spring, the 2-3 shift valve with spring, the 2-3 shift plug and the pressure modifier valve with spring.
5. Remove the side plate "B", then take out the solenoid downshift valve with spring, the throttle back-up valve with spring, the vacuum throttle valve and the 2-3 timing valve with spring.
6. Remove the side plate "D", then take out the pressure regulator plug sleeve, pressure regulator plug, spring seat, spring, pressure regulator valve and second lock valve with spring.

To Inspect

1. Check each valve for anything that might cause sticking.
2. Check to see that valve springs and check valve springs have not lost tension.
3. Check to see that the oil strainer is not damaged.
4. Check for possible abnormal oil passage developing on the separate plate.
5. Check for possible damages or other abnormalities in the oil passages of valve body.
6. If any defective part is found, replace with new one.

To Reassemble

1. Reassemble in the reverse order to disassembly paying special attention to the following points:
 - a. Install small valves and springs by referring to the components parts of control valve Fig. 7B-45.
 - b. Lubricate all valves and springs with converter oil before installing.




Fig. 7B-45 Component parts of control valve

- | | | |
|-----------------------------|----------------------------|----------------------|
| 1. Side plate "D" | 7. 2-3 timing valve | 13. 2-3 shift plug |
| 2. Plug sleeve | 8. Vacuum throttle valve | 14. 2-3 shift valve |
| 3. Regulator pressure plug | 9. Side plate "B" | 15. Side plate "A" |
| 4. Spring seat | 10. Throttle back-up valve | 16. Upper valve body |
| 5. Regulator pressure valve | 11. Down-shift valve | 17. Manual valve |
| 6. Second lock valve | 12. Modifier valve | 18. 1-2 shift valve |

c. If there is any valve that is difficult to insert, do not force it in but give it a light, straight push.

d. Make sure that the followings are strictly tightened to 0.25 ~ 0.35 m·kg (1.8 ~ 2.5 ft·lb).

Side plate to valve body

Lower valve body to upper valve body

Oil strainer to lower valve body

7B-G-9. Bearing and Bearing Race

Check each bearing and bearing race after cleaning carefully. Also check to see that the mating parts of each bearing and bearing race are not damaged. If any defective part is found, replace it.

7B-G-10. Other Component Parts

Check to see by sight that the following parts are not damaged. Disassembly, if indicated, should be made in the procedure below.

a. Front planet carrier assembly, rear planet carrier assembly, input shaft and output shaft

The planetary carrier cannot be divided into its individual components.

If any part or component is defective, replace the

carrier as a unit.

Check the clearance between pinion washer and planetary carrier with a feeler.

The standard clearance is 0.20 ~ 0.70 mm (0.008 ~ 0.027 in).




Fig. 7B-46 Clearance of planetary gear

If the clearance exceeds 0.80 mm (0.032 in), replace with new one.

b. Shell and sun gear assembly

Remove the snap rings and draw out the sun gear from the connecting shell.

c. Internal drive flange assembly

Remove the snap ring and disconnect the flange from the internal gear.

d. Connecting drum assembly

The operation of the one-way clutch can be checked by assuring that the connecting drum assembly (or outer race) turns clockwise and not counter-clockwise, before removing the connecting drum assembly from the case. See 7B-F "DISASSEMBLY OF TRANSMISSION COMPLETE"—20.

Draw out the one-way clutch by removing the snap ring from each end. Remove the outer race snap ring and draw out the outer race rearward from the drum.

After disassembly, check to see that the one-way clutch is not damaged. Check at the same time whether there is any damage on the contacting surface of the outer race or inner race.




Fig. 7B-47 One-way clutch

When installing the one-way clutch, make sure that it is fitted with the arrow mark "→" on the front of vehicle.



Fig. 7B-48 Mark on the one-way clutch

e. Manual control system and parking lock system

Removal and disassembly of these parts are omitted.

7B-H. REASSEMBLY OF TRANSMISSION

Reassembling the major component parts on the transmission case are described below.

Install them in the procedure reverse to that of 7B-F "DISASSEMBLY OF TRANSMISSION" and make sure to lubricate each with converter oil before installation. All gaskets must be replaced with new ones. As to various component parts, refer to 7B-G "OVERHAUL OF MAIN COMPONENT".

1. Install the low and reverse brake assembly on the transmission case. (7B-G-4)
2. Turn clockwise and push in the connecting drum assembly, engaging it with the friction plates.
3. Mount the needle bearing for the front face of the oil distributor assembly on the transmission case side and the bearing race on the front face of the oil distributor assembly. Then install the oil distributor assembly with governor to the case, taking care not to damage the seal rings.
4. Install the output shaft.
5. Install the lock ball, speedometer drive gear and snap ring to the output shaft from the rear end of the output shaft.
6. Mount the needle bearings on the front and rear faces of the internal drive flange, fit the flange on the output shaft and lock it with the snap ring.
7. Mount the bearing race on the rear face of the rear planet carrier and the needle bearing on its front face. Fit the rear planet carrier into the internal drive flange, and lock the carrier by placing the snap ring on the connecting drum.
8. Install the band servo on the case. (7B-G-5)
9. Mount the needle bearing on the rear face of the rear clutch hub and the bearing race on the front face of the front planet carrier. Assemble the rear clutch hub and the planet carrier, and install its assembly on the sun gear and connecting shell.
10. Put the above assembly with the rear clutch hub side facing upward. Mount the needle bearing on the front face of the rear clutch hub and the bearing race on the rear face of the rear clutch assembly, and install the rear clutch assembly downward on the rear clutch hub. In doing so, turn it a little so that the teeth of the clutch plates may come into engagement with the clutch hub spline.
11. Install the front clutch assembly into the rear one as in the case of the rear clutch assembly.
12. Install the assembly including the connecting shell, front clutch, rear clutch and front planet carrier into the transmission case.
13. Install the brake band on the front clutch drum.
14. Install the anchor blot to the transmission case and tighten it to $5.6 \sim 8.2 \text{ m-kg}$ ($41 \sim 59 \text{ ft-lb}$).
15. Install the band strut between the piston stem and the brake band.
16. Set the front clutch thrust washer, which adjusts the end play of the front clutch drum, on the rear face of the oil pump cover assembly, and also set the bearing race, which adjusts the total end play, on the rear end of the oil pump cover. Apply some amount of vaseline to prevent bearing race falling. Install the oil pump assembly with gasket to the



Fig. 7B-49 Assembling clutches

transmission case. Then install and tighten the converter housing onto the transmission case with six bolts to 4.5 ~ 5.5 m-kg (33 ~ 39 ft-lb). Insert the input shaft.

Note : Above two end plays should be checked after the oil pump is properly installed and adjusted following 17 and 18.

17. Push the front clutch drum back and forth and insert a thickness gauge in the clearance between the front clutch drum and connecting shell in order to measure the end play between the rear face of the oil pump cover and the front face of the front clutch drum. Select a thrust washer from the following seven washers to adjust the clearance to specified 0.5 ~ 0.8 mm (0.020 ~ 0.032 in).

- | | |
|---------------------|---------------------|
| 1.50 mm (0.059 in), | 1.70 mm (0.067 in), |
| 1.90 mm (0.075 in), | 2.10 mm (0.083 in), |
| 2.30 mm (0.091 in), | 2.50 mm (0.098 in), |
| 2.70 mm (0.106 in) | |




Fig. 7B-50 Checking end play

18. In measuring the total end play, apply the dial gauge on the tip of the input shaft and move the connecting shell fore and aft, and read the needle vibration. The standard clearance is 0.25 ~ 0.50 mm (0.010 ~ 0.020 in). Adjust end play by selecting a proper race in the followings.

- | | |
|---------------------|---------------------|
| 1.20 mm (0.047 in), | 1.40 mm (0.055 in), |
| 1.60 mm (0.063 in), | 1.80 mm (0.071 in), |
| 2.00 mm (0.079 in), | 2.20 mm (0.087 in) |




Fig. 7B-51 Checking end play




Fig. 7B-52 End plays

19. Tighten the stem of the servo piston to a torque of 1.2 ~ 1.5 m-kg (8.6 ~ 11.0 ft-lb). Then loosen it by two turns and lock with the lock nut to a tightening torque of 1.5 ~ 4.0 m-kg (11 ~ 29 ft-lb). Install and tighten the band servo cover to the retainer.




Fig. 7B-53 Tightening stem

20. Push in the manual shaft into the case with manual plate, washer and nut and tighten the nut. Then mount the parking lever and parking rod.
21. Install the range select lever to the manual shaft with the washer and nut then tighten the nut.

22. Install the control valve assembly onto the transmission case with nine bolts to a specified tightening torque of **0.55 ~ 0.75 m·kg (4.0 ~ 5.4 ft·lb)**.

23. Install the downshift solenoid with "O" ring. Install the vacuum diaphragm unit with vacuum diaphragm rod and "O" ring. Then tighten the downshift solenoid and vacuum diaphragm unit by hand. If the valve body, transmission case or rod were replaced, measure the distance "L" in the condition of the valve fully compressed and select adequate diaphragm rod according to the table below.




Fig. 7B-54 Vacuum throttle valve

a tightening torque of **0.50 ~ 0.70 m·kg (3.6 ~ 5.0 ft·lb)**.

25. Install the spacer, return spring and parking pawl on the shaft. Fit the rear end of the parking rod between the two steel balls in the supporter, then install the extension housing onto the case. Tighten the bolts to a specified torque of **2.0 ~ 2.5 m·kg (15 ~ 18 ft·lb)**.

Measurement "L"	Diaphragm rod
Under 27.2 mm (1.071 in)	29.0 mm (1.140 in)
27.3 ~ 27.7 mm (1.075 ~ 1.091 in)	29.5 mm (1.160 in)
27.8 ~ 28.2 mm (1.095 ~ 1.110 in)	30.0 mm (1.180 in)
28.3 ~ 28.7 mm (1.114 ~ 1.130 in)	30.5 mm (1.200 in)
Over 28.8 mm (1.134 in)	31.0 mm (1.220 in)

24. Install the oil pan together with the gasket to




Fig. 7B-55 Main components of transmission

- | | | | |
|----------------------|-------------------------------|-------------------------------|---|
| 1. Torque converter | 6. Front clutch ass'y | 11. Rear planet carrier ass'y | 16. Servo piston ass'y |
| 2. Converter housing | 7. Rear clutch ass'y | 12. Drive flange ass'y | 17. Oil pan |
| 3. Case | 8. Rear clutch hub ass'y | 13. Low & reverse brake ass'y | 18. Control valve ass'y |
| 4. Extension housing | 9. Front planet carrier ass'y | 14. Input shaft | 19. Governor valve ass'y and output shaft |
| 5. Oil pump ass'y | 10. Shell & sun gear ass'y | 15. Brake band | |




Fig. 7B-56 Installing extension housing

7B-I. INSTALLATION AND ADJUSTMENT OF TRANSMISSION

1. Before installing the transmission, measure the runout of the torque converter drive plate with a dial gauge. The runout must be within **0.3 mm (0.012 in)**. In case the runout exceeds **0.5 mm (0.020 in)**, replace the drive plate.

2. When combining the converter with oil pump, check whether they are rightly combined with each other by measuring the distance shown in Fig. 7B-57. The distance is approximately **19.5 mm (0.78 in)**. If there is great difference in the measurement, the converter should be rightly combined again.




Fig. 7B-57 Checking torque converter fit

3. Installation procedure for the transmission is reverse to the removing procedure, referring to "REMOVAL OF TRANSMISSION" in 7B-E. In tightening the torque converter and the drive plate, temporarily tighten four bolts first, then lock the drive plate by applying the wrench to the drive pulley lock bolt. And tighten the four bolts to a specified torque of **3.7 ~ 5.5 m·kg (27 ~ 40 ft·lb)**. In case of confirming the tightening torque accurately, it is recommendable to proceed as follows:

Install a torque wrench to the hole in the center of the **special wrench (49 0877 435)**, and tighten the bolt until the reading on the torque wrench comes to the value to be obtained by the undermentioned formula.

"L" indicates the effective length of the torque wrench. In the case of the torque wrench expressed in the m·kg unit, measure the "L" in terms of cm, and substitute the value (for example, 30 in case of 30 cm) into formula (1). In the case of the ft·lb torque wrench, on the other hand, measure the "L" in the inch unit, and substitute the value into formula (2). The prescribed tightening torque will thus be obtained.

$$\frac{5L}{10 + L} \text{ . m·kg(1)}$$

$$\frac{35L}{4 + L} \text{ . ft·lb (2)}$$




Fig. 7B-58 "L" length of torque wrench



Fig. 7B-59 Tightening torque converter

4. When the installation is finished, rotate the torque converter and check to see that there is no interference in the transmission. Then make the following check:

- (1) Fill converter oil. The converter, when empty, can hold **6.2 liters (13.1 U.S. pints, 10.9 Imp. pints, 6.6 U.S. quarts)**. (7B-B-1)
 - (2) Check and regulate the manual linkage. (7B-B-4)
 - (3) Check and regulate the inhibitor switch. (7B-B-5)
 - (4) Check and regulate the engine idling. (7B-B-2)
- Apply the hand brake. With the engine idling, place the manual lever in "N", "D", "2", "1" and "R", and check to see that there is a slight shock of the transmission.
- (5) Confirm the operation of the kick-down switch and downshaft solenoid. (7B-B-3)
 - (6) Check the oil level again.

5. When checking and regulating are over, conduct stall test, road test and hydraulic test referring to diagnostic test items (7B-C) in order to make sure that the transmission works normally.

SERVICE SPECIAL TOOLS





Fig. 7B-60 Automatic transmission service tools set

It is essential that the service special tools in this manual must be absolutely utilized in performing the various operations of trouble shooting, disassembling and assembling of the R3A type automatic transmission.

1. Oil pressure gauge set	49 0378 400	Use for checking hydraulic pressure
a. Oil pressure gauge	49 8000 001	This is included in the oil pressure gauge set (49 8000 000)
b. Rubber hose	49 0378 401	- do -
c. Joint pipe	49 0378 402	- do -
d. Hose adaptor	49 0378 403	- do -
e. Hose adaptor	49 0378 404	- do -
2. Transmission case stand	49 0378 320	Use for setting transmission
3. Puller oil pump	49 0378 390	Use for removing oil pump
4. Snap ring remover	49 8000 015	Use for removing or installing snap ring
5. Snap ring remover	49 8000 025	Use for removing or installing snap ring
6. Torque driver	49 8000 021	Use for tightening in accurate torque Max. torque 1.04 m·kg (90 lb-in)
7. Clutch spring compressor	49 0378 375	Use for assembling or disassembling front and rear clutch
8. Hexagon wrench	49 8000 031	Use for disassembling and assembling control valve
9. Spinner handle	49 8000 035	Use for disassembling and assembling control valve
10. Hex-head extension	49 0378 346	Use for removing and installing one-way clutch inner race with torque wrench. Drive angle 1/2" square and 5 mm (across flat width)
11. Special wrench	49 0877 435	A tool used for removing the bolt that attaches the drive-plate to the torque converter
12. Oil pump assembling gauge	49 0378 405	Use for centering oil pump

Insert the bolts (Fig. 12) into the universal bearing to prevent lubricant from running out of the bearing.



PROPELLER SHAFT

8-A. REMOVING PROPELLER SHAFT	8 : 1
8-B. CHECKING PROPELLER SHAFT	8 : 2
8-C. DISASSEMBLING UNIVERSAL JOINT	8 : 2
8-D. CHECKING UNIVERSAL JOINT	8 : 2
8-E. ASSEMBLING UNIVERSAL JOINT	8 : 2
8-F. INSTALLING PROPELLER SHAFT	8 : 3
SPECIAL TOOLS	8 : 3

Note: Do not remove the oil seal and bearing from the propeller shaft.

Fig. 8-3
Propeller shaft components

- 1. Sliding yoke
- 2. Snap ring
- 3. Universal joint
- 4. Front shaft
- 5. Cross shaft
- 6. Protection
- 7. Seal and washer
- 8. Center bearing support
- 9. Bearing
- 10. Snap ring
- 11. Yoke (rear)
- 12. Bolt
- 13. Nut
- 14. Prop. shaft
- 15. Bolt
- 16. Yoke (front)



PROPELLER SHAFT
The propeller shaft assembly consists of the front propeller shaft and propeller shaft center support bearing universal joints and yokes.
The rear end of the propeller shaft is attached to the companion flange of the rear axle through the universal joint and the front end is attached to the main shaft of the transmission by means of the pinned sliding yokes which permit fore and aft movement of the propeller shaft.
The center of the propeller shaft is supported by the bearing attached to the underbody.
The universal joints are lubricated in the factory and require no further lubrication.
8-A. REMOVING PROPELLER SHAFT
1. To remove the propeller shaft, disconnect the front of the companion flange from the rear axle flange so that they may be removed.
2. Remove the bolts that attach the propeller shaft to the companion flange in the rear axle.
3. Remove the center support bearing bracket from the underbody.
4. Pull the propeller shaft assembly rearward and remove from the transmission.

PROPELLER SHAFT

The propeller shaft assembly consists of the front propeller shaft, rear propeller shaft, center support bearing, universal joints and yokes.

The rear end of the propeller shaft is attached to the companion flange of the rear axle through the universal joint and the front end is attached to the main shaft of the transmission by means of the splined sliding yokes, which permits fore and aft movement of the propeller shaft when the rear axle moves up and down.

The center of the propeller shaft is supported by the bearing attached to the underbody.

The universal joints are lubricated for life, so do not require lubricating.

8-A. REMOVING PROPELLER SHAFT

1. To maintain drive line balance, mark the mating parts of the companion flange, yokes and propeller shafts so that they may be installed in their original positions.
2. Remove the bolts that attach the propeller shaft to the companion flange of the rear axle.
3. Remove the center support bearing bracket from the underbody.
4. Pull the propeller shaft assembly rearward and remove from the transmission.

5. Install the holder (49 0259 440) into the extension housing to prevent lubricant from running out of the housing.



Fig. 8-1 Holder installed into extension housing

6. Remove the universal joints, as described in Par. 8-C.
7. Remove the nut attaching the yoke and bearing to the front propeller shaft. Remove the yoke and bearing support.

Note: Do not remove the oil seals and bearing from




Fig. 8-2
Propeller shaft components

1. Sliding yoke
2. Snap ring
3. Universal joint
4. Front shaft
5. Grease seal
6. Protector
7. Nut and washer
8. Center bearing support
9. Bearing
10. Snap ring
11. Yoke (Center)
12. Washer
13. Nut
14. Rear shaft
15. Bolt
16. Yoke (Rear)

the support unless they are defective.

8-B. CHECKING PROPELLER SHAFT

1. Check the run-out of the propeller shaft by supporting both ends of the propeller shaft on the "V" blocks and applying a dial indicator. The permissible run-out is under 0.4 mm (0.016 in).




Fig. 8-3 Checking propeller shaft for run-out

2. Check the propeller shaft for dynamic unbalance. The maximum permissible unbalance is shown in the following table. If the unbalance is more than the specifications, correct or replace the propeller shaft assembly.

	Max. permissible unbalance at 4,000 rpm
At front	15 cm-gr (0.21 in-oz)
At center	30 cm-gr (0.42 in-oz)
At rear	30 cm-gr (0.42 in-oz)

Note :

As the looseness on the front universal joint may cause the increase of the unbalance, resulting the seizure of the extension housing bush, the front universal joint and propeller shaft should be replaced as an assembly. But, if the unbalance of the propeller shaft assembly can be checked and corrected within the specifications, the universal joint only may be replaced.

3. Check the center bearing for wear, looseness or any damage.

8-C. DISASSEMBLING UNIVERSAL JOINT

1. Place the propeller shaft in a vise being careful not to damage it.
2. Remove the snap rings retaining the bearings in the yoke and in the propeller shaft.
3. Position the **universal joint replacer** (49 0259 460A) on the yoke and screw in the center bolt until the bearing comes out of the yoke.
4. Remove the replacer and remove the bearing.
5. Reposition the replacer to press on the yoke to remove the bearing from the opposite side of the yoke.
6. Remove the opposite side bearing in the same manner.
7. Remove the yoke and spider assembly from the propeller shaft.
8. Using the same replacer, remove the remaining two



Fig. 8-4 Removing universal joint

bearings in the same manner.

9. Remove the spider from the yoke.

8-D. CHECKING UNIVERSAL JOINT

1. Examine the bearing surfaces of the spider. They should be smooth and free from pits.
2. Measure the diameter of the spider. If it is **under 16.549 mm (0.6515 in)**, replace with a new universal joint assembly.




Fig. 8-5 Measuring spider diameter

3. Check the needle rollers for wear or any damage. The rollers should have a uniformly good appearance and roll freely inside the bearing cup.

8-E. ASSEMBLING UNIVERSAL JOINT

1. Place the bearing into the yoke at the end of the propeller shaft.
2. Position the spider in the yoke.
3. Position the replacer and press the bearing, while guiding the spider into the bearing, until the snap ring can be installed.
4. Remove the replacer and install the snap ring.
5. Place the bearing into the opposite side of the yoke.
6. Install the replacer and press on the bearing until




Fig. 8-6 Universal joint components

- 1. Bearing
- 2. Spider
- 3. Grease seal
- 4. Yoke
- 5. Propeller shaft
- 6. Snap ring

the snap ring can be installed.
7. Remove the replacer and install the snap ring.

Note:

Select the snap rings so as to place the spider in the center of the yoke and to give a suitable slight drag fit (not binding).

Be sure to use same sized snap rings to both sides of the yoke.

Snap rings are available in seven thicknesses as shown in the following table.

1.45 mm (0.0570 in)	1.57 mm (0.0618 in)
1.48 mm (0.0582 in)	1.60 mm (0.0629 in)
1.51 mm (0.0594 in)	1.63 mm (0.0641 in)
1.54 mm (0.0606 in)	

8. Position the yoke on the spider and install two

bearings and snap rings in the same manner as instructed above.



Fig. 8-7 Installing universal joint

8-F. INSTALLING PROPELLER SHAFT

Install the propeller shaft in the reverse order of removing, noting the following points.

1. Be sure to observe location marks on the companion flange, yokes and propeller shafts for correct assembly.
2. Torque the nut attaching the yoke and center bearing to the front shaft to 16.0 ~ 18.0 m·kg (116 ~ 130 ft·lb).
3. The tightening torque of the nuts attaching the center bearing support is 2.0 ~ 2.9 m·kg (14 ~ 21 ft·lb).
4. The tightening torque of the nuts attaching the yoke to companion flange is 5.5 ~ 6.5 m·kg (40 ~ 47 ft·lb).

SPECIAL TOOLS

49 0259 440	Main shaft holder
49 0259 460A	Universal joint replacer

Mount a dial indicator in the location shown in the illustration. The dial should be set to zero (0) before the axle is rotated.




REAR AXLE

- 9-A. REAR AXLE SHAFT 9 : 1
 - 9-A-1. Removing Rear Axle Shaft 9 : 1
 - 9-A-2. Disassembling Rear Axle Shaft 9 : 1
 - 9-A-3. Assembling Rear Axle Shaft 9 : 1
 - 9-A-4. Installing Rear Axle Shaft 9 : 1
- 9-B. REAR AXLE REMOVAL 9 : 2
- 9-C. REAR AXLE DISASSEMBLY 9 : 2
 - 9-C-1. Removing Differential 9 : 2
 - 9-C-2. Disassembling Differential 9 : 2
 - 9-C-3. Removing Drive Pinion 9 : 3
- 9-D. REAR AXLE INSPECTION 9 : 3
 - 9-D-1. Checking Drive Pinion and Ring Gear 9 : 3
 - 9-D-2. Checking Differential Gears 9 : 3
 - 9-D-3. Checking Bearings 9 : 3
 - 9-D-4. Replacing Pinion Bearing
 - Outer Race 9 : 3
 - 9-D-5. Checking Collapsible Spacer 9 : 3
 - 9-D-6. Checking Oil Seal 9 : 3
 - 9-D-7. Checking Companion Flange 9 : 3
- 9-E. REAR AXLE ASSEMBLY 9 : 3
 - 9-E-1. Adjusting Drive Pinion 9 : 3
 - 9-E-2. Adjusting Pinion Bearing Preload 9 : 4
 - 9-E-3. Assembling Differential 9 : 5
 - 9-E-4. Installing Differential 9 : 7
 - 9-E-5. Adjusting Backlash 9 : 7
- 9-F. REAR AXLE INSTALLATION 9 : 7
- SPECIAL TOOLS 9 : 8

It has been removed, the dial indicator should be set to zero (0) before the axle is rotated. When installing the axle, the dial indicator should be checked when the first shaft is rotated after both shafts are removed. The second shaft should be rotated about 90 degrees. The dial indicator should be set to zero (0) before the axle is rotated. When installing the axle, the dial indicator should be checked when the first shaft is rotated after both shafts are removed.

- Fig. 9-5
Rear axle shaft
components:
- 1. Drive shaft
 - 2. Bearing housing
 - 3. Oil seal (O-ring)
 - 4. Carrier
 - 5. Ring gear
 - 6. Pinion
 - 7. Axle shaft
 - 8. Oil seal (O-ring)
 - 9. Lock nut
 - 10. Lock washer
 - 11. Bearing
 - 12. Pinion
 - 13. Drive shaft



REAR AXLE

Rotary pickup is equipped with a semi-floating type rear axle with a hypoid ring gear and pinion set. The final reduction ratio is 4.625.

9-A. REAR AXLE SHAFT

9-A-1. Removing Rear Axle Shaft

1. Raise the rear end of the vehicle and support the rear axle housing with stands.
2. Remove the wheel, and remove the center cap adaptor from the rear axle shaft flange.
3. Remove the rear wheel and brake drum.
4. Remove the brake shoe assembly, as detailed in Par 11-C..
5. Remove the parking brake cable retainer.
6. Disconnect the brake fluid pipes at the wheel cylinders.
7. Remove the nuts holding the backing plate and bearing housing to the axle housing.
8. Pull the axle shaft, backing plate, bearing housing assembly and shims off the axle housing.

9-A-2. Disassembling Rear Axle Shaft

1. Straighten the tabs of the lock washer.
2. With the **spanner** (49 0603 621A), loosen the lock nut and remove the lock nut and lock washer.
3. Using a suitable puller, remove the bearing and housing assembly from the rear axle shaft.
4. Remove the backing plate.
5. Remove the bearing and oil seal from the bearing housing, if necessary.

9-A-3. Assembling Rear Axle Shaft

Assemble the rear axle shaft in the reverse order of disassembling.

9-A-4. Installing Rear Axle Shaft

1. Install the rear axle shaft, backing plate and bearing housing assembly to the rear axle housing.
2. Using two bolts and nuts, temporarily assemble the bearing housing and backing plate to the axle

housing flange.

3. Mount a dial indicator to the backing plate to check end play (Fig. 9-1).



Fig. 9-1 Checking end play

If only one axle shaft has been removed, the end play should be 0.05 ~ 0.15 mm (0.002 ~ 0.006 in). A very special procedure is required if both axle shafts have been removed. When installing the shafts, the end play should be checked when the first shaft is installed (don't wait until after both shafts are installed).

The end play for the first shaft should be 0.65 ~ 0.85 mm (0.026 ~ 0.033 in). The second shaft should then be 0.05 ~ 0.15 mm (0.002 ~ 0.006 in). Use the adjusting shims to arrive at these results.

4. After adjusting the end play, install all bolts and nuts and torque to specifications.
5. Install the brake shoe assembly and drum, as described in Par. 11-E.
6. Connect the brake fluid pipes to the wheel cylinder.
7. Bleed the brake system.
8. Install the wheel.
9. Lower the vehicle.




Fig. 9-2
Rear axle shaft components

1. Shims
2. Bearing housing
3. Oil seal (Outer)
4. Gasket
5. Rivet
6. Baffle
7. Axle shaft
8. Oil seal (Inner)
9. Lock nut
10. Lock washer
11. Bearing
12. Spacer
13. Hub bolt and nut

9-B. REAR AXLE REMOVAL

1. Jack up the vehicle until the rear wheels are clear of the ground.
2. Drain the oil by removing the drain plug. Reinstall the drain plug after all oil is out. (As the plug is magnetic, it should be cleaned.)
3. Remove the rear axle shafts, referring to Par. 9-A-1.
4. Mark the companion flange and propeller shaft for correct reassembly; then disconnect the propeller shaft.
5. Remove the nuts supporting the rear axle to the rear axle housing and remove the rear axle.

9-C. REAR AXLE DISASSEMBLY

9-C-1. Removing Differential

1. Mount the rear axle on the stand (49 0164 550D and 49 0164 562B).




Fig. 9-3 Stand for rear axle

2. Apply identification punch marks on the carrier, differential bearing cap, and adjuster for reassembly purpose.




Fig. 9-4 Applying identification marks

3. Remove the adjuster lock plates.
4. Loosen the bearing cap attaching nuts and back off the adjuster slightly with the **spanner** (49 0259 720) to relieve differential bearing preload.

5. Remove the nuts, bearing caps, and adjusters.
6. Remove the differential assembly together with the bearing outer races. Make certain that each bearing outer race remains with its respective bearing.




Fig. 9-5 Removing differential assembly

9-C-2. Disassembling Differential

1. If the bearing replacement is necessary, remove the bearings from the differential gear case with a suitable puller.
2. Remove the bolts and washers that attach the ring gear to the gear case. Remove the ring gear.




Fig. 9-6 Removing ring gear

3. From the back side of the gear case flange, drive the pinion shaft lock pin out of the gear case with a suitable drift, as shown in Fig. 9-7.



Fig. 9-7 Removing pinion shaft lock pin

4. Remove the pinion shaft and thrust block.

5. Rotate the differential pinion gears 90 degrees and remove each pinion gear.
6. Remove the differential side gears and thrust washers.

9-C-3. Removing Drive Pinion

1. Hold the companion flange with the holder (49 0259 710A) and remove the drive pinion nut.



Fig. 9-8 Loosening pinion nut

2. Remove the companion flange.
3. Remove the drive pinion and rear bearing from the carrier. If necessary, tap the pinion out with a plastic hammer, while being careful to guide the pinion with hand to avoid damage.
4. Remove the oil seal and the front bearing.

9-D. REAR AXLE INSPECTION

9-D-1. Checking Drive Pinion and Ring Gear

Check the drive pinion for damaged or excessively worn teeth, damaged bearing journals and splines. Inspect the ring gear for worn or chipped teeth. If any of above conditions is found, replace both drive pinion and ring gear as they are available only in set.

9-D-2. Checking Differential Gears

Inspect the differential side gears and pinion gears for cracks, chipped teeth or any damage. Replace the side gears, pinion gears or thrust washers if necessary. Check the clearance between the pinion gear and shaft. If excessive clearance is found due to wear, replace with new parts.

Check the spline fit of the side gear and rear axle shaft. If excessive clearance is found, replace the side gear or rear axle shaft.

9-D-3. Checking Bearings

Inspect the differential bearings and pinion bearings for wear, flaking or any damage. If inspection reveals that either bearing cones or outer race are unfit for further service, replace the bearing.

9-D-4. Replacing Pinion Bearing Outer Race

If it becomes necessary to replace the pinion bearing

- outer race(s), proceed as follows:
1. Remove the old outer race from the carrier by using a drift in slots provided for this purpose.




Fig. 9-9 Removing pinion bearing outer race

2. Install a new outer race into the carrier.

9-D-5. Checking Collapsible Spacer

Measure the length of the collapsible spacer with a micrometer. The standard length is 47 ± 0.15 mm (1.8504 ± 0.0059 in).



Fig. 9-10 Collapsible spacer

2. Apply identification punch marks on the carrier.
3. Apply identification punch marks on the carrier.
4. Apply identification punch marks on the carrier.
5. Apply identification punch marks on the carrier.
6. Apply identification punch marks on the carrier.
7. Apply identification punch marks on the carrier.
8. Apply identification punch marks on the carrier.
9. Apply identification punch marks on the carrier.
10. Apply identification punch marks on the carrier.
11. Apply identification punch marks on the carrier.
12. Apply identification punch marks on the carrier.
13. Apply identification punch marks on the carrier.
14. Apply identification punch marks on the carrier.
15. Apply identification punch marks on the carrier.
16. Apply identification punch marks on the carrier.
17. Apply identification punch marks on the carrier.
18. Apply identification punch marks on the carrier.
19. Apply identification punch marks on the carrier.
20. Apply identification punch marks on the carrier.
21. Apply identification punch marks on the carrier.
22. Apply identification punch marks on the carrier.
23. Apply identification punch marks on the carrier.
24. Apply identification punch marks on the carrier.
25. Apply identification punch marks on the carrier.
26. Apply identification punch marks on the carrier.
27. Apply identification punch marks on the carrier.
28. Apply identification punch marks on the carrier.
29. Apply identification punch marks on the carrier.
30. Apply identification punch marks on the carrier.
31. Apply identification punch marks on the carrier.
32. Apply identification punch marks on the carrier.
33. Apply identification punch marks on the carrier.
34. Apply identification punch marks on the carrier.
35. Apply identification punch marks on the carrier.
36. Apply identification punch marks on the carrier.
37. Apply identification punch marks on the carrier.
38. Apply identification punch marks on the carrier.
39. Apply identification punch marks on the carrier.
40. Apply identification punch marks on the carrier.
41. Apply identification punch marks on the carrier.
42. Apply identification punch marks on the carrier.
43. Apply identification punch marks on the carrier.
44. Apply identification punch marks on the carrier.
45. Apply identification punch marks on the carrier.
46. Apply identification punch marks on the carrier.
47. Apply identification punch marks on the carrier.
48. Apply identification punch marks on the carrier.
49. Apply identification punch marks on the carrier.
50. Apply identification punch marks on the carrier.
51. Apply identification punch marks on the carrier.
52. Apply identification punch marks on the carrier.
53. Apply identification punch marks on the carrier.
54. Apply identification punch marks on the carrier.
55. Apply identification punch marks on the carrier.
56. Apply identification punch marks on the carrier.
57. Apply identification punch marks on the carrier.
58. Apply identification punch marks on the carrier.
59. Apply identification punch marks on the carrier.
60. Apply identification punch marks on the carrier.
61. Apply identification punch marks on the carrier.
62. Apply identification punch marks on the carrier.
63. Apply identification punch marks on the carrier.
64. Apply identification punch marks on the carrier.
65. Apply identification punch marks on the carrier.
66. Apply identification punch marks on the carrier.
67. Apply identification punch marks on the carrier.
68. Apply identification punch marks on the carrier.
69. Apply identification punch marks on the carrier.
70. Apply identification punch marks on the carrier.
71. Apply identification punch marks on the carrier.
72. Apply identification punch marks on the carrier.
73. Apply identification punch marks on the carrier.
74. Apply identification punch marks on the carrier.
75. Apply identification punch marks on the carrier.
76. Apply identification punch marks on the carrier.
77. Apply identification punch marks on the carrier.
78. Apply identification punch marks on the carrier.
79. Apply identification punch marks on the carrier.
80. Apply identification punch marks on the carrier.
81. Apply identification punch marks on the carrier.
82. Apply identification punch marks on the carrier.
83. Apply identification punch marks on the carrier.
84. Apply identification punch marks on the carrier.
85. Apply identification punch marks on the carrier.
86. Apply identification punch marks on the carrier.
87. Apply identification punch marks on the carrier.
88. Apply identification punch marks on the carrier.
89. Apply identification punch marks on the carrier.
90. Apply identification punch marks on the carrier.
91. Apply identification punch marks on the carrier.
92. Apply identification punch marks on the carrier.
93. Apply identification punch marks on the carrier.
94. Apply identification punch marks on the carrier.
95. Apply identification punch marks on the carrier.
96. Apply identification punch marks on the carrier.
97. Apply identification punch marks on the carrier.
98. Apply identification punch marks on the carrier.
99. Apply identification punch marks on the carrier.
100. Apply identification punch marks on the carrier.

1. Check the oil seal for wear or damage. If there is any possibility of oil leakage, replace the oil seal.

9-D-7. Checking Companion Flange

Check the companion flange for cracks, worn splines, or rough oil seal contacting surface. Repair or replace the companion flange if necessary.

9-E. REAR AXLE ASSEMBLY

9-E-1. Adjusting Drive Pinion

The drive pinion should be correctly positioned in relation to the ring gear by the use of spacer which is placed between the drive pinion and the pinion rear bearing.

To adjust the drive pinion position, use the special gauge (49 0727 570 and 49 0603 555A) and proceed as follows:

1. Install the dial indicator to the gauge body. Place the gauge body on the surface plate as shown in Fig. 9-11 and lock the dial indicator by the screw so



Fig. 9-11 ZERO setting

that the needle is pointing toward 1 to 3 mm. Then, set the reading to "Zero" by turning the outer ring of the indicator.

2. Make certain that the differential bearing support bores are free of dirt and burrs.

3. Install the pinion and bearing model (49 0603 555A) together with a spacer into the carrier.




Fig. 9-12 Installing pinion and bearing model

4. Place the gauge block on the pinion and carefully place the gauge body adjusted in Step 1 on the gauge block so that the feeler of the indicator comes in contact with the lowest portion of the differential bearing support bore.




Fig. 9-13 Measuring pinion height

5. Record the number of hundredths dial indicator

moves in a "+" (plus) or "-" (minus) direction from zero. Remove the gauge body and dial indicator from the carrier and check zero setting on the surface plate to make sure this setting was not disturbed by handling.

6. In order to compensate for all of the machining variables, the pinion has a plus or minus reading recorded in hundredth millimeters on the rear face of the pinion.

(a) If the pinion is marked "+" (plus), subtract the amount specified on the pinion.

(b) If the pinion is marked "-" (minus), add the amount specified on the pinion.

7. Place the bearing model and the rear pinion bearing on the surface plate and compare their heights as shown in Fig. 9-14.

(a) If the bearing is higher than the model, subtract the amount equivalent to the difference.

(b) If the bearing is lower than the model, add the amount equivalent to the difference.



Fig. 9-14 Measuring bearing height

8. Finally select the correct pinion spacer to be used during pinion assembly by adding or subtracting the amount determined in Step 5, 6 and 7 from the thickness of the spacer used in Step 3.

The spacers are available in the following thickness:

Identification mark	Thickness
08	3.08 mm (0.1213 in)
11	3.11 mm (0.1224 in)
14	3.14 mm (0.1236 in)
17	3.17 mm (0.1248 in)
20	3.20 mm (0.1260 in)
23	3.23 mm (0.1271 in)
26	3.26 mm (0.1283 in)
29	3.29 mm (0.1295 in)
32	3.32 mm (0.1307 in)
35	3.35 mm (0.1319 in)
38	3.38 mm (0.1331 in)
41	3.41 mm (0.1343 in)
44	3.44 mm (0.1354 in)
47	3.47 mm (0.1366 in)

9. Position the correct spacer on the pinion and install the rear pinion bearing.*

9-E-2. Adjusting Pinion Bearing Preload

1. Position the pinion assembly in the carrier and




Fig. 9-15 Installing pinion and collapsible spacer

1. Install the collapsible spacer as shown in Fig. 9-15.
2. Place the front pinion bearing in position on the pinion. Hold the pinion fully forward and drive the pinion bearing over the pinion until seated.
3. Apply gear lubricant to the lip of the pinion oil seal and install the pinion oil seal into the carrier.
4. Install the companion flange on the pinion by tapping with a soft hammer.
5. Install the pinion washer and nut. Before tightening the nut (When the pinion preload is Zero), check the drag by the oil seal by using a torque wrench.
6. Tighten the pinion nut to **20 m-kg (145 ft-lb)** and check the preload as shown in Fig. 9-16.




Fig. 9-16 Checking pinion bearing preload

Note: After preload has been checked, final tightening should be done very cautiously.

The pinion nut should be further tightened only a little at a time and preload should be checked after each slight amount of tightening. Exceeding preload specifications will compress the collapsible spacer too far and requires its replacement. The maximum tightening torque of the nut is 35 m-kg (253 ft-lb).

7. While observing the proceeding caution, carefully set the preload drag at **13 to 18 cm-kg (11.3 to 15.6 in-lb)** plus the oil seal drag determined in Step 5.

Note: If the preload is measured by using a spring scale at the bolt hole of the companion flange, the reading should be 3.3 ~ 4.6 kg (7.3 ~ 10.1 lb).

9-E-3. Assembling Differential

1. Install the thrust washer on each differential side gear and install these in the gear case.




Fig. 9-17 Installing side gear and thrust washer

2. Through the openings of the gear case, insert each of two pinion gears exactly 180 degrees opposite each other.



Fig. 9-18 Installing differential gears

3. Rotate the gears 90 degrees so that the pinion shaft holes of the case come into alignment with the holes in the pinion gears.
4. Insert the pinion shaft through the case and pinion gears.
5. Check the backlash of the side gear and pinion gear. The backlash should be 0 to 0.1 mm (0 to 0.004 in).



Fig. 9-19 Checking backlash of pinion and side gear




Fig. 9-21
Rear axle components

1. Companion flange
2. Oil seal
3. Front bearing
4. Collapsible spacer
5. Carrier
6. Bearing cap
7. Rear bearing
8. Spacer
9. Drive pinion
10. Adjusting screw
11. Differential bearing
12. Ring gear
13. Thrust washer
14. Side gear
15. Pinion gear
16. Pinion shaft
17. Gear case
18. Thrust block

If it is more than 0.2 mm (0.008 in), adjustment can be made with the side gear thrust washers. The following thrust washers are available:

Identification mark	Thickness
0	2.0 mm (0.0789)
1	2.1 mm (0.0827)
2	2.2 mm (0.0866)

6. After adjustment, remove the pinion shaft and



Fig. 9-20 Installing thrust block and pinion shaft

install the thrust block so that the hole is centered between the side gears. Reinstall the pinion into the case until the lock pin hole in the pinion shaft is exact alignment with the hole in the case.

7. Install the lock pin to secure the pinion shaft. Stake the lock pin into position with a punch to prevent it from working out.

8. Install the ring gear to the case and torque the bolts to 9.0 ~ 11.0 m-kg (65 ~ 80 ft-lb);




Fig. 9-22 Tightening ring gear bolts

9. Install each differential bearing to the gear case.
10. Install the differential bearing outer races to their respective bearings.

9-E-4. Installing Differential

1. Place the differential gear assembly in the carrier, making ensure that the marks for backlash adjustment on the face of the pinion and ring gear teeth are aligned each other.



Fig. 9-23 Installing of differential assembly

2. Note the identification marks on the adjusters and install each to its respective side.
3. Install the differential bearing caps making sure that the identification marks on the caps correspond with those on the carrier and install the attaching nuts.
4. Turn the adjusters with the **spanner** (49 0259 720) until the bearings are properly positioned in their respective outer races and the end play is eliminated with some backlash existing between the ring gear and drive pinion.
5. Slightly tighten one of the bearing cap nuts on each side and adjust the backlash, as instructed in the following paragraph.

9-E-5. Adjusting Backlash

1. Secure a dial indicator to the carrier flange so that the feeler comes in contact at right angles with one of the ring gear teeth.
2. Check the backlash between the ring gear and drive pinion. With the **spanner** (49 0259 720), turn both bearing adjusters equally until the backlash becomes 0.19 to 0.21 mm (0.0075 to 0.0083 in).




Fig. 9-24 Adjusting backlash

3. The preload on the differential bearings is obtained by tightening the adjusters. Tighten the adjusters until the distance between both pilot sections on the bearing caps becomes 204.428 ~ 204.5 mm (8.0485 ~ 8.0513 in), as shown in Fig. 9-25.




Fig. 9-25 Adjusting bearing preload (case spread)

Note: When adjusting the preload, care must be taken not to affect the backlash of the drive pinion and ring gear.

4. Tighten the bearing cap nuts to a torque of 6.5 ~ 7.7 m·kg (47 ~ 56 ft·lb).
5. Install the adjuster lock plates on the bearing caps to prevent the adjusters from loosening.
6. Check the tooth contact of the ring gear and pinion by applying a thin coat of red lead on both sides of about six or eight of ring gear teeth and rotating the ring gear several times to and fro. If the pinion position and backlash have been correctly set, the contact pattern should be as shown in Fig. 9-26.




Fig. 9-26 Correct tooth contact

9-F. REAR AXLE INSTALLATION

1. Clean the sealing surface of the carrier and the housing. No gasket is required.
2. Apply oil resistant sealer to the surfaces.
3. Position the carrier to the housing.
4. Tighten the nuts.
5. Connect the propeller shaft following the markings closely to prevent any out of balance condition. Torque the bolts to 5.5 ~ 6.5 m·kg (40 ~ 47 ft·lb).

-
6. Install the axle shafts, drums and wheels. of lubricant.
7. Fill the axle with the correct grade and quantity 8. Lower the vehicle.

SPECIAL TOOLS

49 0603 621A	Spanner for axle shaft bearing lock nut
49 0164 550D	Rear axle stand
49 0164 562B	Attachment for rear axle stand
49 0259 720	Backlash adjusting spanner
49 0259 710A	Companion flange holding tool
49 0727 570	Pinion adjusting gauge
49 0603 555A	Gauge block and bearing model

STEERING

STEERING	10	: 1
10-A. STEERING WHEEL.....	10	: 1
10-A-1. Checking Steering Wheel Play.....	10	: 1
10-A-2. Steering Wheel Removal.....	10	: 1
10-A-3. Steering Wheel Inspection.....	10	: 2
10-A-4. Steering Wheel Installation.....	10	: 2
10-B. STEERING GEAR.....	10	: 2
10-B-1. Steering Gear Removal.....	10	: 2
10-B-2. Steering Gear Disassembly.....	10	: 3
10-B-3. Steering Gear Inspection.....	10	: 3
10-B-4. Steering Gear Assembly.....	10	: 4
10-B-5. Steering Gear Installation.....	10	: 5
10-C. STEERING LINKAGE	10	: 5
10-C-1. Checking Ball Joint.....	10	: 5
10-C-2. Idler Arm.....	10	: 5
a. Removing idler arm.....	10	: 5
b. Disassembling idler arm.....	10	: 6
c. Checking idler arm.....	10	: 6
d. Assembling idler arm.....	10	: 6
e. Installing idler arm.....	10	: 6
10-C-3. Replacing Pitman Arm.....	10	: 6
10-C-4. Replacing Tie-rod	10	: 6
10-C-5. Replacing Center Link.....	10	: 7
10-D. FRONT WHEEL ALIGNMENT.....	10	: 7
10-D-1. Toe-in.....	10	: 8
a. Checking toe-in.....	10	: 8
b. Adjusting toe-in.....	10	: 8
10-D-2. Camber.....	10	: 8
10-D-3. Caster.....	10	: 8
10-D-4. Adjusting Turning Angle.....	10	: 9
SPECIAL TOOLS.....	10	: 9

1. Front wheel
2. Steering gear housing
3. Steering gear housing
4. Steering gear housing
5. Steering gear housing
6. Steering gear housing
7. Steering gear housing
8. Steering gear housing
9. Steering gear housing
10. Steering gear housing

STEERING

The steering system consists of the steering gear, steering column, steering wheel and steering linkage. The steering gear is of a recirculating ball nut type and the steering gear ratio 20.2. Therefore, this steering gear provides easy steering.

10-A. STEERING WHEEL

10-A-1. Checking Steering Wheel Play

The steering wheel play should be 15 ~ 25 mm (0.60 ~ 1.00 in). With the front wheels on the ground and in the straight ahead position, move the steering wheel in both directions without moving the front wheels.

If excessive play is found, the following points should be carefully checked.

1. Fit of the ball joints of the steering linkage
2. Looseness of the wheel bearings

3. Backlash between the sector gear and ball nut.

10-A-2. Steering Wheel Removal

1. Pull the steering wheel pad toward the top of the wheel.
2. Punch the mating marks on the steering wheel hub and the column shaft.
3. Remove the steering wheel attaching nut and then remove the steering wheel assembly.

Note :

Do not use any hammer for removal and never pound on the column shaft.

4. Disconnect the wiring harness at the connector under the instrument panel.

5. Remove the retaining ring that secures the combination switch assembly and lift the switch assembly over the column shaft.




Fig. 10-1 Steering assembly

- | | | |
|-----------------------|-----------------|--------------------------|
| 1. Steering wheel | 4. Shaft jacket | 7. Bolt |
| 2. Stop ring | 5. Bracket | 8. Steering gear housing |
| 3. Shaft support bush | 6. Shaft ass'y | 9. Idler arm |

10-A-3. Steering Wheel Inspection

1. Cracks and damage of the steering wheel
2. Damage of the horn button contact plate, seat, washer, cushion and the spring
3. Cracks and damage of the horn button
4. Function of the combination switch assembly

10-A-4. Steering Wheel Installation

Follow the removal procedures in the reverse order.

10-B. STEERING GEAR

10-B-1. Steering Gear Removal

1. Raise the front end of the vehicle and support with stands.
2. Loosen the bolt securing the worm shaft to the steering joint.



Fig. 10-3 Loosening securing bolt

3. Remove the cotter pin and castellated nut attaching the center link to the pitman arm.
4. Disconnect the center link from the pitman arm with the ball joint puller (Part No. 49 0727 575).



Fig. 10-4 Disconnecting center link

5. Remove the screws attaching the insulator to the pitman arm and remove the insulator.
6. Remove the bolts and nuts retaining the steering




Fig. 10-2 Steering wheel components

1. Steering wheel
2. Horn button
3. Earth plate
4. Spring
5. Insulator
6. Cap set
7. Screw
8. Spring cap
9. Horn cap
10. Emblem
11. Tapping screw
12. Terminal
13. Wheel core cover
14. Set plate
15. Screw
16. Steering wheel nut

gear housing to the body. At this point, check for the possible presence of aligning shim between the gear housing and the body.

7. Remove the steering gear from the vehicle.

10-B-2. Steering Gear Disassembly

1. Drain lubricant from the gear housing by removing the plug.

2. Remove the nut attaching the pitman arm and remove the pitman arm with the **pitman arm puller** (Part No. 49 0223 695C), as shown in Fig. 10-5.




Fig. 10-5 Removing pitman arm

3. Remove the bolts that attach the side cover to the gear housing and loosen the sector shaft adjusting screw lock nut, then remove the sector shaft side cover screwing in the sector shaft adjusting screw.

4. Remove the sector shaft adjusting screw and shim from the slot at the end of the sector shaft.

5. Remove the sector shaft from the gear housing.



Fig. 10-6 Removing sector shaft

6. Remove the bolts that attach the end cover to the gear housing and remove the end cover and shims.

7. Remove the worm shaft and ball nut assembly from the gear housing.

8. Remove the oil seal from the gear housing, if necessary.

10-B-3. Steering Gear Inspection

1. Check the steering wheel for cracks or damage.

2. Check the operation of the ball nut assembly on the worm shaft. If the ball nut does not travel smoothly and freely on the worm shaft, the ball nut and worm shaft assembly should be replaced.




Fig. 10-7 Steering gear cross section

1. Plug
2. Lock nut
3. Adjusting screw
4. Side cover
5. Gasket
6. Oil seal
7. Sector shaft
8. Steering gear housing
9. Worm shaft and ball nut assembly
10. Oil seal
11. End cover
12. Adjusting shim

Note :

The worm shaft and ball nut are serviced as an assembly only.




Fig. 10-8 Worm shaft and ball nut assembly

3. Check the sector shaft for wear or damage at the gear surface.
4. Check the oil seal for wear, flaw, or any damage. If there is any possibility of oil leakage, replace the oil seal.

10-B-4. Steering Gear Assembly

1. Install the oil seal to the gear housing.
2. Insert the worm shaft and ball nut assembly into the gear housing.
3. Install the end cover and the bearing preload adjusting shims to the gear housing and tighten the end cover attaching bolts to 1.6 ~ 2.3 m·kg (12.0 ~ 17.0 ft·lb).



Fig. 10-9 Installing end cover and adjusting shim

4. Adjust the bearing preload. To check the preload, attach the **preload checking tool** (Part No. 49 0180 510A) onto the worm shaft and connect a pull scale to the preload checking tool. Pull the scale gradually, and read the scale keeping the worm shaft rotating. If the reading is less than 0.1 kg (0.22 lb), reduce the shim, and add the shim if the preload is more than 0.4 kg (0.88 lb). The following shims are available.

0.050 mm (0.002 in)	0.100 mm (0.004 in)
0.075 mm (0.003 in)	0.200 mm (0.008 in)




Fig. 10-10 Checking bearing preload

5. Insert the sector shaft into the gear housing, being careful not to damage the oil seal; and ensuring that the center of the sector gear is in alignment




Fig. 10-11 Position of sector gear and worm gear

with the center of the worm gear as shown in Fig. 10-11.

6. Install the sector shaft adjusting screw into the slot at the end of the sector shaft. Check the end clearance between the sector shaft and adjusting screw with a feeler gauge and adjust this clearance to 0 ~ 0.1 mm (0 ~ 0.004 in) by inserting appropriate thrust washer.

The thrust washers are available in the following four thicknesses :

1.95 mm (0.077 in)	2.05 mm (0.081 in)
2.00 mm (0.079 in)	2.10 mm (0.083 in)




Fig. 10-12 Checking end clearance

7. Place the side cover and the gasket onto the sector shaft adjusting screw and turn the adjusting screw until the side cover is screwed into proper position. Install the side cover attaching bolts and tighten the bolts.




Fig. 10-13 Installing side cover

8. Install the pitman arm onto the sector shaft, aligning the identification marks of the pitman arm and sector shaft. Install the pitman arm attaching nut and tighten the nut to 15.0 ~ 18.0 m-kg (108.0 ~ 130.0 ft-lb).



Fig. 10-14 Installing pitman arm




Fig. 10-15 Identification marks

9. Adjust the backlash between the worm gear and sector shaft gear. To adjust the backlash, position the sector shaft at the center of the worm gear, then, gradually screw in or out the sector shaft

adjusting screw until the backlash is obtained 0 mm at the pitman arm end. Turn out the adjusting screw so as to give 30 degrees ($1/2$ of a turn). Tighten the adjusting screw lock nut, taking care not to disturb the backlash. Rotate the worm shaft and check to ensure that the sector shaft turns 40° smoothly to the right and left.



Fig. 10-16 Adjusting backlash

10. Check the worm shaft rotating torque. To check, attach the checking tool (Part No. 49 0180 510A) onto the worm shaft and connect a pull scale to the checking tool. Pull the scale and check the worm shaft rotating torque. If the rotating torque is less than 0.9 kg (1.98 lb) or more than 1.5 kg (3.30 lb), readjust the bearing preload.

10-B-5. Steering Gear Installation

Follow the removal procedures in the reverse order.

Note :

- Align the steering worm shaft cut portion with the and install the steering gear housing to the body, and tighten the securing bolts and nuts.
- Place the shim in original position to obtain proper shaft alignment.
- Install the pitman arm to the sector shaft aligning the identification marks and secure with the nut. Tighten the nut to 15.0 ~ 18.0 m-kg (108.0 ~ 130.0 ft-lb).
- Fill the gear housing with gear lubricant.

10-C. STEERING LINKAGE

10-C-1. Checking Ball Joint

- Check the dust seal for wear, flaw or any damage. If the dust seal is defective, this will allow entry of water and dust, resulting in ball joint wear. Replace the dust seal if necessary.
- The end play of the ball stud is preadjusted at the factory to be from 0 ~ 0.2 mm (0 ~ 0.08 in). If it exceeds 1.0 mm (0.040 in), replace the ball joint in its assembled form.

10-C-2. Ider Arm

a. Removing idler arm

- Raise the front end of the vehicle and support

with stands.

2. Remove the cotter pin and nut attaching the center link at the idler arm.
3. Disconnect the center link from the idler arm with the **ball joint puller** (Part No. 49 0727 575).
4. Remove the bolts attaching the idler arm and remove the idler arm.

b. Disassembling idler arm

1. Hold the idler arm in a vise, protecting with aluminum plates, remove the cotter pin and remove the bracket attaching nut.
2. Remove the washers, bushes and bracket.




Fig. 10-17 Idler arm cross section

c. Checking idler arm

1. Inspect the bush for wear or damage.
2. Check the end play of the ball stud. If necessary, replace the idler arm assembly.

d. Assembling idler arm

Follow the disassembly procedures in the reverse order.

Note :

Apply grease to the bracket and bushes.

e. Installing idler arm

Follow the removal procedures in the reverse order.

Note :

Tighten the idler arm attaching bolts to 4.4 ~ 5.5 m-kg (32.0 ~ 40.0 ft-lb).

10-C-3. Replacing Pitman Arm

1. Raise the front end of the vehicle and support with stands.
2. Remove the cotter pin and castellated nut that attach the steering center link to the pitman arm.
3. Disconnect the steering center link from the pitman arm with the **ball joint puller** (Part No. 49 0727 575).
4. Remove the pitman arm attaching nut.
5. Remove the pitman arm from the sector shaft using the **pitman arm puller** (Part No. 49 0223 695C).
6. Install the pitman arm onto the sector shaft, aligning the identification marks of the pitman arm and sector shaft.




Fig. 10-18 Identification marks

7. Install the pitman arm attaching nut and tighten the nut to 15.0 ~ 18.0 m-kg (108.0 ~ 130.0 ft-lb).
8. Secure the steering center link to the pitman arm with the castellated nut. Tighten the nut and install the cotter pin.

Note :

Always tighten the nut to the next castellation if necessary to install the cotter pin.

10-C-4. Replacing Tie-rod

The tie-rod should be replaced, if it becomes worn or damaged. Do not attempt to straighten the tie-rod if damaged.

1. Raise the front end of the vehicle and support with stands.
2. Remove the cotter pins and castellated nuts that attach both tie-rod ends to the center link and steering knuckle.
3. Disconnect the tie-rod ends from the center link and steering knuckle with the **ball joint puller** (Part No. 49 0727 575).




Fig. 10-19 Disconnecting tie-rod end

4. Remove the tie-rod.
5. Secure the tie-rod to the center link and steering knuckle with castellated nut. Tighten the nut and install the cotter pin.
6. Check and, if necessary, adjust toe-in.

Note :

Whenever the tie-rod or ball joint is replaced, the toe-in is reset.

10-C-5. Replacing Center Link

1. Raise the front end of the vehicle and support with stands.
2. Remove the center link from both tie rods, pitman arm and idler arm by removing the cotter pins and nuts and by using the **ball joint puller** (Part No. 49 0727 575).
3. Install the center link to the pitman arm, idler arm and tie-rods.
4. Tighten the nuts to the specifications and install new cotter pins.

10-D. FRONT WHEEL ALIGNMENT

Front wheel alignment is most important if correct

steering, and reasonable tire wear are to be obtained. Before attempting to check the wheel alignment, the following points should be investigated, and if necessary, corrected.

1. Tires for correct inflation
2. Unbalanced tires
3. Wobbling wheels
4. Front wheel bearing adjustment
5. Ball joints, and tie-rod end for looseness
6. Front coil springs for correct seating

When the above points are all in order, the vehicle should be stood on a perfectly level surface in the wheel alignment bay or stall.




Fig. 10-20

Steering linkage components

1. Tie rod
2. Dust seal
3. Dust seal ring
4. Ball joint
5. Tie rod clamp
6. Tapered bush
7. Idler bracket
8. Dust seal ring
9. Dust seal
10. Ball joint
11. Tapered bush
12. Idler arm
13. Center link
14. Insulator

10-D-1. Toe-in

a. Checking toe-in

1. Raise the front end of the vehicle until the wheels clear the ground.
2. Turning the wheel by hand, mark a line in the center of the wheel with a scribing block.
3. Lower the vehicle and place the front wheels in the straight-ahead position.
4. Measure the distances between the marked lines at the front and rear of the wheels with a suitable toe-in gauge. The difference between these two distances is the toe-in. The standard toe-in is 0 ~ 6 mm (0 ~ 0.24 in).




Fig. 10-21 Toe-in

b. Adjusting toe-in

If the toe-in is incorrect, proceed as follows :

1. Loosen the tie-rod clamp bolts at each end of the tie-rod.
2. Check that the tie-rod ends are in the same position on each rod, thus ensuring that the tie-rods are the same length.
3. Turn the both tie-rods an equal amount until the correct toe-in is obtained.

Note :

The tie-rod is threaded with right and left hand threads.

Note:

The cramps on the tie-rods must be positioned as Fig. 10-22 to prevent interference with the center link when the toe-in is readjusted.

4. Tighten the tie-rod locking nuts and recheck the toe-in.




Fig. 10-22 The tightening position of clamp

10-D-2. Camber

Camber is the outward tilting of the front wheel at the top from the vertical as shown in Fig.10-23. The




Fig. 10-23 Camber and kingpin inclination

- A. Camber
- B. Camber trail
- C. Kingpin inclination

standard camber angle is $15' \pm 20'$. The purpose of camber is to place the weight of the vehicle, as near as possible, directly above the tire contact on the road to facilitate ease of steering. Excessive camber tends to cause uneven wear of the tires and negative camber, hard steering and a possible wandering condition. Tires will wear out at the inside shoulders.

To check the camber, use a wheel aligning gauge in accordance with the manufacturer's instructions. The camber is adjusted by adding or subtracting the shim between the upper arm shaft and the support bracket. The shims are available in thicknesses of 1.0, 1.6, 2.0 and 3.2 mm (0.039, 0.063, 0.079 and 0.126 in).

10-D-3. Caster

Caster is the inclination of the upper ball joint towards the rear of the vehicle. The standard caster angle is $1^{\circ} 57' \pm 20'$. The purpose of caster is to provide steering stability by keeping the front wheels in a straight ahead position and also assisting in returning the wheels to straight ahead when coming out of a turn.

To check the caster, use a wheel aligning gauge following the manufacturer's instructions. If found incorrect, adjust the shims between the upper arm shaft and the support bracket or turn the upper arm shaft until the correct adjustment is obtained.




Fig. 10-24 Caster

10-D-4. Adjusting Turning Angle

The turning angle stop screws are located at the steering knuckle. Using a turntable, check that the

front wheels turn $33^{\circ} 18'$ inward and $32^{\circ} 26'$ outward. If necessary, adjust the turning angle by the stop screws.

SPECIAL TOOLS

49 0727 575
49 0223 695C
49 0180 510A

Ball joint puller
Pitman arm puller
Preload checking tool




Fig. 10-28 Turning angle adjustment
A. Ball joint
B. Control ball
C. Steering knuckle

standard control angle is $10^{\circ} 10'$. The purpose of center is to place the weight of the wheel on the center as possible. Check the front wheel on the ball joint to facilitate ease of steering. A steering knuckle joint is made of steel and is a heavy-duty component. The ball joint is made of steel and is a heavy-duty component. To check the center, use a wheel steering gauge to determine with the manual body's measurement. The center is adjusted by adding or subtracting the shim between the upper and lower ball joint. The shim are available in thicknesses of 1.0, 1.5, 2.0 and 2.5 mm (0.039, 0.063, 0.079 and 0.102 in).

10-D-3. Caster

Caster is the inclination of the upper ball joint to wards the rear of the vehicle. The standard caster angle is $1^{\circ} 13' \pm 30'$. The purpose of caster is to provide steering stability by keeping the front wheels in a straight ahead position and also steering in a turning the wheels at straight ahead when coming out of a turn. To check the caster, use a wheel steering gauge following the manufacturer's instructions. It helps to check the shim between the upper and lower ball joint and the upper bearing of the upper ball joint with the correct adjustment is required.



Fig. 10-29 Caster



A. Ball joint puller
B. Pitman arm puller

Fig. 10-31 Caster

Adjusting caster
If the caster is incorrect, proceed as follows:
1. Loosen the steering clamp bolts at each end of the steering.
2. Check that the tie-rod ends are in the same position on each rod, thus ensuring that the tie-rod are the same length.
3. Turn the both tie-rod to equal amount until the correct toe-in is obtained.

Photo

The tie-rod is checked with right and left hand tie-rod.

Photo

The shim on the tie-rod must be positioned as per Fig. 10-32 for correct measurement with the shim. Note when the shim is required.

4. Tighten the tie-rod locking nuts and check the tie-rod.




Fig. 10-32 The tie-rod position of shim

10-D-2. Camber

Camber is the inward tilt of the front wheel at the top from the vertical as shown in Fig. 10-33. The

BRAKES

DESCRIPTION..... 11 : 1

11-A. BRAKE ADJUSTMENT 11 : 1

 11-A-1. Adjusting Brake Pedal 11 : 1

 11-A-2. Bleeding Hydraulic System .. 11 : 1

 11-A-3. Adjusting Rear Brake Shoe 11 : 2

11-B. DUAL MASTER CYLINDER 11 : 2

 11-B-1. Removing Dual Master Cylinder 11 : 2

 11-B-2. Disassembling Dual Master Cylinder 11 : 3

 11-B-3. Checking Dual Master Cylinder 11 : 4

 11-B-4. Assembling Dual Master Cylinder 11 : 4

 11-B-5. Installing Dual Master Cylinder 11 : 4

11-C. POWER BRAKE UNIT 11 : 5

 11-C-1. Checking Power Brake Unit on Vehicle 11 : 5

 11-C-2. Removing Power Brake Unit 11 : 5

 11-C-3. Disassembling Power Brake Unit 11 : 5

 11-C-4. Checking Power Brake Unit 11 : 7

 11-C-5. Assembling Power Brake Unit 11 : 8

 11-C-6. Installing Power Brake Unit 11 : 8

11-D. HYDRAULIC LINES 11 : 8

 11-D-1. Checking Brake Lines 11 : 8

11-E. FRONT BRAKE 11 : 9

 11-E-1. Disc Brake Shoe 11 : 9

 a. Replacing disc brake shoe 11 : 9

DESCRIPTION

The brake consists of two systems, the front brake and the parking brake. The front brake is of a disc type. The rear brake is of a drum type with leading and trailing shoes. The brake pedal is of a central type.

The parking brake operates the brake shoes on the rear wheels through the wire linkage.

11-A. BRAKE ADJUSTMENT

11-A-1. Adjusting Brake Pedal

1. Disconnect the stop light switch wiring terminals

11-E-2. Caliper..... 11 : 10

 a. Removing caliper 11 : 10

 b. Disassembling caliper 11 : 10

 c. Checking caliper 11 : 10

 d. Assembling caliper 11 : 10

 e. Installing caliper 11 : 11

11-E-3. Rotor (Brake Disc) and Front Wheel Hub Assembly 11 : 12

 a. Checking rotor assembly 11 : 12

 b. Replacing rotor assembly 11 : 12

11-F. REAR BRAKE 11 : 12

11-F-1. Rear Brake Drum and Shoe 11 : 12

 a. Removing rear brake drum and shoe 11 : 12

 b. Inspecting rear brake drum and shoe 11 : 14

 c. Installing rear brake drum and shoe 11 : 14

11-F-2. Wheel Cylinder 11 : 14

 a. Removing wheel cylinder 11 : 14

 b. Disassembling wheel cylinder 11 : 14

 c. Checking wheel cylinder 11 : 14


 d. Assembling wheel cylinder 11 : 14

 e. Installing wheel cylinder 11 : 15

11-G. PARKING BRAKE 11 : 15

11-G-1. Parking Brake Adjustment.. 11 : 15

SPECIAL TOOL 11 : 15



with new brake fluid during bleeding operation.

Notes:

Always allow the brake fluid to drop on any painted surface.

1. Remove the rubber cap from the bleeder screw and connect a vinyl drain tube into the bleeder

DESCRIPTION

The brakes consist of two systems, the foot brake, and the parking brake. The front brakes are of a disc brake type.

The rear brakes are of a drum type with leading and trailing shoes. The brake pedal is of a pendant type.

The parking brake operates the brake shoes of the rear wheels through the wire linkage.

11-A. BRAKE ADJUSTMENT

11-A-1. Adjusting Brake Pedal

1. Disconnect the stop light switch wiring terminals.
2. Loosen the lock nut and adjust the pedal height to **190 mm (7.5 in)** between the pedal and the floor mat by turning the stop light switch and push rod. Next, tighten the lock nut.




Fig. 11-1 Adjusting brake pedal

- | | |
|---------------------|----------------------|
| 1. Master cylinder | 4. Lock nut |
| 2. Power brake unit | 5. Brake pedal |
| 3. Push rod | 6. Stop light switch |

11-A-2. Bleeding Hydraulic System

When any parts of the hydraulic system has been disconnected for repair or replacement, air may enter into the lines, and causes spongy pedal action.

This requires the bleeding of the hydraulic system after it has been properly connected to be sure that all air is expelled from the brake cylinders and lines. When bleeding the brake system, bleed one brake bleeder screw at a time, beginning at the bleeder screw with the longest hydraulic line first. **Never use** brake fluid which has been drained from the hydraulic system.

The bleeding procedures are as follows:

1. Keep the brake master cylinder reservoir filled with new brake fluid during bleeding operation.

Note :

Never allow the brake fluid to drop on any painted surface.

2. Remove the rubber cap from the bleeder screw, and connect a vinyl drain tube onto the bleeder




Fig. 11-2 Checking fluid level

3. Depress the brake pedal slowly several times to bleed the air, and with the brake pedal depressed, loosen the bleeder screw one-third to half of a turn, then close the bleeder screw before brake pedal is released.

Note :

Do not release the brake pedal until the bleeder screw is tightened as additional air may enter into the wheel cylinder.




Fig. 11-3 Bleeding front brake




Fig. 11-4 Bleeding rear brake

4. Repeat this operation until the brake fluid flows into the container without any air bubbles.
5. After bleeding completely, tighten the bleeder screw, and install the rubber cap onto the bleeder screw.
6. Fill the reservoir with brake fluid.

11-A-3. Adjusting Rear Brake Shoe

To adjust the brake shoe, proceed as follows:

1. Jack the rear end of the vehicle, then support with stands.
2. Make sure that the parking brake is fully released.
3. Remove the shoe adjusting hole plug from the backing plate, and expand the brake shoe by turning the adjuster toward the arrow direction (⇌) marked on the backing plate until the wheel locks. At this time, pump the brake pedal several times to make sure that the shoes contact the drum on the entire surface. If the wheel turns after removing the foot from the brake pedal, turn the adjuster further until the wheel locks firmly.




Fig. 11-5 Removing plug




Fig. 11-6 Adjusting rear brake shoe

4. Back off the adjuster 5 notches so that the drum rotates freely without any drag.
5. Check that the wheel rotates freely after pumping the brake pedal several times. Next, install the adjusting hole plug onto the backing plate.

Note : If the wheel does not rotate freely, check and repair the drum, shoes or other necessary parts.

6. Perform the same adjustment on the other side shoes of the rear wheels. The adjustments must be equal at all shoes.

11-B. DUAL MASTER CYLINDER

11-B-1. Removing Dual Master Cylinder

1. Disconnect the fluid pipes at the master cylinder outlets.
2. Remove the nuts that attach the master cylinder to the power brake unit.
3. Remove the master cylinder.

Note : Never allow the brake fluid to drop on any painted surface.




Fig. 11-7 Removing dual master cylinder




Fig. 11-8 Master cylinder cross section

- | | |
|---------------------|--------------------|
| 1. Reservoir cap | 8. Secondary cup |
| 2. Fluid baffle | 9. Stop bolt |
| 3. Reservoir | 10. Primary cup |
| 4. Bush | 11. Primary piston |
| 5. Cylinder | 12. Secondary cup |
| 6. Secondary piston | 13. Stop wire |
| 7. Primary cup | 14. Stop washer |

11-B-2. Disassembling Dual Master Cylinder

1. Clean the outside of the master cylinder.
2. Pour out any brake fluid that remains in the cylinder. Discard the old brake fluid.
3. Remove the bolts attaching the reservoir and remove the reservoir from the cylinder.
4. Depress the primary piston assembly and remove the snap ring from the retaining groove at the rear of the cylinder bore.



Fig. 11-9 Removing snap ring

5. Remove the washer, primary piston assembly and return spring from the cylinder bore.



Fig. 11-10 Removing primary piston

6. Depress the secondary piston assembly with a suitable rod and remove the secondary piston stop bolt from the outside of the cylinder, and insert a guide pin in its place.




Fig. 11-11 Piston guide pin

7. Remove the secondary piston assembly and return




Fig. 11-12 Removing secondary piston




Fig. 11-13 Dual master cylinder components

1. Reservoir cap
2. Fluid baffle
3. Packing
4. Reservoir
5. Bolt
6. Bush
7. Cylinder
8. Joint bolt
9. Gasket
10. Check valve
11. Spring
12. Secondary piston stop bolt and "O" ring
13. Spring
14. Secondary piston
15. Secondary piston cup
16. Secondary piston cup
17. Spring
18. Primary piston
19. Stop washer
20. Snap ring

spring. If necessary, blow out with compressed air from the secondary brake system outlet.

8. Remove the joint bolts from the primary and secondary brake system outlets. Then, remove the check valves and return springs from the outlets.

11-B-3. Checking Dual Master Cylinder

1. Clean all parts in clean alcohol or brake fluid. **Never use gasoline or kerosene.**

2. Check the piston cups and replace if they are damaged, worn, softened, or swelled.

3. Examine the cylinder bore and piston for wear, roughness or scoring. Check the clearance between the cylinder bore and the piston. If it is more than **0.15 mm (0.006 in)**, replace the cylinder or piston.



Fig. 11-14 Checking piston clearance

4. Check all recesses, openings and internal passages to be sure they are open and free of foreign matter. Use compressed air to blow out dirt and cleaning solvent.

5. Check the piston return spring for weakness.

11-B-4. Assembling Dual Master Cylinder

1. Dip all parts except the cylinder in clean brake fluid.

2. Insert the check valve springs into the outlets and place the check valves over the springs. Install the joint bolts and tighten them.

3. Insert the valve and secondary piston return spring assembly into the cylinder.

4. Fit the secondary piston guide pin into the secondary piston stop bolt hole and insert the secondary piston into the cylinder. Depress the secondary piston with a suitable rod and remove the guide pin. Then, install the secondary piston stop bolt.



Fig. 11-20 Removing plate and valve body assembly




Fig. 11-15 Installing stop bolt

5. Insert the primary piston return spring and the primary piston assembly into the cylinder.




Fig. 11-16 Installing primary piston

6. Hold the primary piston down and install the snap ring into position in groove of the cylinder bore.

Note :

Make sure that the piston cups do not cover the compensating port.

7. Install the reservoir to the cylinder.

11-B-5. Installing Dual Master Cylinder

Follow the removal procedures in the reverse order.

Note :

Fill the reservoir and bleed the air at each bleeder screw.

11-C. POWER BRAKE UNIT

11-C-1. Checking Power Brake Unit on Vehicle

1. Road test the brakes by making a brake application at about 30 km (20 miles) to determine if the vehicle stops evenly and quickly. If pedal has a spongy feel when applying brakes, air may be present in hydraulic system. Bleed the system as described in Par. 11-A-2.

2. With the engine stopped and transmission in neutral, apply brakes several times to deplete all vacuum reverse in the power brake unit. Depress brake pedal, hold light-foot pressure on the pedal and start the engine. If vacuum system is operating, pedal will tend to fall away under foot pressure and less pressure will be required to hold pedal in applied position. If no action is felt, vacuum system is not functioning.

3. Stop the engine. Again deplete all vacuum reverse in system. Depress the brake pedal and hold foot pressure on the pedal. If pedal gradually falls away under foot pressure, hydraulic system is leaking internally or externally.

4. Start the engine with brakes off and transmission in neutral. Run the engine to medium speed and turn off ignition switch. Immediately close throttle. This build up vacuum. Wait no less than 90 seconds, then try brake action. If not vacuum assisted for two or more applications, vacuum check valve is faulty or there is a leak in vacuum system.

11-C-2. Removing Power Brake Unit

1. Remove the brake master cylinder, as described in Par. 11-B-1.

2. Disconnect the vacuum hose at the power brake unit.

3. Disconnect the push rod from the brake pedal by removing the cotter pin at the fork end.



Fig. 11-17 Removing cotter pin

4. Remove the nuts that attach the power brake unit to the dash panel.

5. Remove the power brake unit from the dash panel.

11-C-3. Disassembling Power Brake Unit

1. Remove the check valve from the power brake unit.

2. Place the power brake unit in a vice with push rod up. Clamp the unit firmly on the flange.

3. Scribe a mark on the bottom center of the front and rear shells to facilitate reassembly.

4. Remove the fork end, lock nut and dust boot.




Fig. 11-18 Removing boot

- 1. Fork end
- 2. Lock nut
- 3. Boot

5. Attach a suitable wrench to the studs of the rear shell as shown in Fig. 11-19. Rotate the rear shell clockwise to unlocked position.

Note :

Loosen the rear shell carefully as it is spring-loaded.



Fig. 11-19 Removing rear shell




Fig. 11-20 Removing plate, and valve body assembly

- 1. Diaphragm
- 2. Plate and valve body
- 3. Reaction disc
- 4. Push rod
- 5. Spring
- 6. Front shell
- 7. Front seal
- 8. Check valve
- 9. Nut
- 10. Flange
- 11. Valve rod and plunger assembly
- 12. Retainer
- 13. Bearing
- 14. Valve body seal
- 15. Rear shell
- 16. Air silencer retainer
- 17. Retainer key
- 18. Boot

Fig. 11-28 Power brake unit components





Fig. 11-27 Clearance between piston and rod



11-C-4. Checking Power Brake Unit
 1. Check the clearance between primary piston and the push rod of the master cylinder and if necessary, adjust the push rod so that the correct clearance is obtained. The standard clearance is 0.1 ~ 0.5 mm (0.004 ~ 0.020 in).

12. Remove the push rod.
 13. Remove the front seal from the front shell if necessary.

Fig. 11-26 Reaction disc



11. Press the reaction disc out of the valve body.

9. Remove the air silencer with the air filter from the plate and valve body, being careful not to chip plastic.




Fig. 11-23 Removing air filter

10. Press in on the valve rod to remove the valve retainer key. Remove the valve rod and plunger assembly.

Note:
The valve rod and plunger are serviced as an assembly only.



Fig. 11-24 Removing retainer key

6. Lift the rear shell and plate and valve body, valve rod and plunger assembly from the unit. Then, remove the return spring.
7. Remove the plate, valve body, valve rod and plunger assembly from the rear shell.

Note:
Do not remove the rear seal from the rear shell unless seal is defective and the new seal is available. To remove the rear seal, support the rear shell and drive out the rear seal with a punch or a screwdriver.




Fig. 11-21 Removing rear seal

8. Remove the diaphragm from the plate and valve body.




Fig. 11-22 Removing diaphragm




Fig. 11-25 Power brake unit cross section

2. Inspect all rubber parts. Wipe free of fluid and carefully inspect each rubber part for cuts, nicks or other damage.
3. Check the plate and valve body for cracks, distortion, chipping and damaged seats.
4. Inspect the reaction disc for deterioration of rubber.
5. Check the valve rod and plunger for all seats to be smooth and free of nicks and dents. Replace with a new one if defective.
6. Inspect the front and rear shells for scratches, scores, pits, dents or other damage.
7. Check the diaphragm for cuts, or other damage.

11-C-5. Assembling Power Brake Unit

1. Apply power brake lubricant to the inner surface of the tube section of the plate and valve body and to the surfaces of the valve rod and plunger.
2. Insert the valve rod and plunger assembly into the tube section of the plate and valve body.
3. Press down on the valve rod and align the groove in the valve plunger with the slot of the valve body. Insert the retainer key.
4. Install the diaphragm on the plate and valve body making certain the diaphragm is seated in the groove.
5. Assemble the air filter and the air silencer over the rod and position in the valve body.
6. Apply power brake lubricant liberally to the entire surface of the reaction disc and install the reaction disc into the plate and valve body.
7. Coat the outer bead of the diaphragm with power brake lubricant where it bears against the outer rims of the front and rear shells to aid in assembly.
8. Apply power brake lubricant to the seal in the rear shell and carefully guide tube end of the plate and valve body, through the seal in the rear shell.

9. Install the plate and valve body into the front shell.
10. Install the push rod through the front of the plate and valve body.
11. Install the return spring.
12. Install the rear shell assembly by using the wrench to rotate the rear shell counter-clockwise until scribe marks align.

Note :

Press the rear shell down firmly, maintaining a pressure until the shell flanges are fully locked.

13. Install the dust boot down against the rear shell.
14. Install the check valve.

11-C-6. Installing Power Brake Unit

Follow the removal procedures in the reverse order.

Note :

After installing the unit, bleed the hydraulic system according to the procedure described in Par. 11-A-2.

11-D. HYDRAULIC LINES

11-D-1. Checking Brake Lines

Inspect all brake lines for any leakage with the foot brakes applied. Check all brake pipes, hoses and connections for signs of chafing, deterioration or replaced or repaired, always air bleed the hydraulic system.




Fig. 11-29 Hydraulic lines

11-E. FRONT BRAKE

11-E-1. Disc Brake Shoe

a. Replacing disc brake shoe

The lining should be inspected whenever the wheels are removed for any reason. The shoe and lining assembly should be replaced, if the thickness of the shoe and lining assembly is 8.0 mm (0.315 in) or less due to wear.




Fig. 11-30 Checking lining thickness

To replace the disc brake shoes, proceed as follows :

1. Raise the front end of the vehicle and support with stands.
2. Remove the front wheel.
3. Remove the hair pin retainers and pull out the stopper plates.




Fig. 11-31 Removing hair pin retainers




Fig. 11-32 Removing stopper plates

4. Remove the caliper and anti-rattle spring and pull out the brake shoes.



Fig. 11-33 Removing caliper




Fig. 11-34 Removing brake shoe

5. Remove the rubber cap from the bleeder screw, and connect a vinyl drain tube onto the bleeder screw. Submerge the other end of the vinyl tube into a suitable container.
6. Open the bleeder screw and press the piston into the cylinder with the **piston retracting tool** (Part No. 49 0221 600B).
7. Tighten the bleeder screw and remove the vinyl tube and retracting tool.



Fig. 11-35 Piston retracting tool

8. Install new brake shoes and shims on the caliper.

Note :

- (a) When the disc brake shoes are replaced, replace all shoes on both wheels at the same time.
- (b) **Do not** mix different types of linings when replacing.

9. Install the anti-rattle spring, caliper, stopper plates and hair pin retainers.

10. Install the front wheel and lower the vehicle.

11-E-2. Caliper

a. Removing caliper

1. Raise the front end of the vehicle and support with stands.
2. Remove the front wheel.
3. Remove the shoe and lining assembly as described in Par. 11-E-1.
4. Disconnect the brake fluid pipe from the caliper and plug the end of the fluid pipe to prevent entrance of dirt and loss of fluid.
5. Remove the caliper.




Fig. 11-36 Removing caliper

6. If necessary, remove the caliper bracket by removing the two bolts.




Fig. 11-37 Removing caliper bracket

b. Disassembling caliper

1. Clean outside of the caliper.
2. Place a hardwood in front of piston to prevent

damage to piston. Apply air pressure to the fluid port in the caliper to remove the piston. Remove the dust boot from the piston.

Note :

If the piston is seized and cannot be forced from the caliper, tap lightly around the piston while applying air pressure.



Fig. 11-38 Removing piston

3. Remove the retainer and dust boot from the caliper.
4. Remove the piston seal from the caliper bore.



Fig. 11-39 Removing piston seal

5. Remove the bleeder screw, if necessary.

c. Checking caliper

1. Clean the disassembled parts in clean brake fluid or alcohol and dry with compressed air.

Note :

Never use gasoline or kerosene.

2. Inspect the caliper bore and piston for scoring, scratches or rust. If any of these conditions are found, replace with a new piston or caliper. Minor damage can be eliminated by polishing with crocus cloth.
3. Discard the old piston seal and dust boot, and use new ones when reassembling.

d. Assembling caliper

1. Apply brake fluid to the piston seal and install

it into the groove of the caliper bore.

Note :

Be sure the piston seal does not become twisted and that it is seated fully in the groove.

2. Lubricate the piston and caliper bore.
3. Insert the piston into the caliper bore.



Fig. 11-40 Inserting piston

4. Install the dust boot by setting the flange squarely in the inner groove of the caliper bore. Install the dust boot retainer.



Fig. 11-41 Installing retainer

e. Installing caliper

Follow the removal procedures in the reverse order and bleed the hydraulic system.




Fig. 11-42

Caliper components

1. Bolt and washer
2. Caliper assembly
3. Bleeder screw
4. Bleeder cap
5. Caliper body
6. Piston seal
7. Piston
8. Dust boot
9. Boot retainer
10. Hair pin retainer
11. Stopper plate
12. Spring
13. Caliper bracket
14. Anti-rattle spring clip
15. Anti-rattle spring
16. Brake shoe and lining assembly
17. Shim

11-E-3. Rotor (Brake Disc) and Front Wheel Hub Assembly

a. Checking rotor assembly

1. Inspect the friction surface of the rotor and recondition if it is scored, scratched or rusted.
2. Check the run-out of the rotor with a dial indicator.

Note :

Make sure that the wheel bearings are correctly adjusted, before checking the run-out of the rotor.

If the run-out is more than 0.10 mm (0.0039 in), reface the rotor. Do not reface any more than is necessary to clean up the rotor.



Fig. 11-43 Checking rotor run-out

3. Check the rotor for thickness. If the thickness of the rotor becomes less than 11 mm (0.433 in) from excessive refacing, the rotor should be replaced.




Fig. 11-44 Checking rotor thickness

b. Replacing rotor assembly

Replace the rotor and front wheel hub assembly, as described in Par. 12-F-1.

11-F. REAR BRAKE

11-F-1. Rear Brake Drum and Shoe

a. Removing rear brake drum and shoe

1. Raise the rear end of the vehicle and support with stands.
2. Remove the rear wheel.
3. Make sure that the parking brake is fully released.
4. Remove the bolts that attach the brake drum to the rear axle shaft flange and pull the drum off the axle shaft flange. If the drum will not come off, place the drum attaching bolts into the tapped holes on the drum. Then, tighten in evenly to force the drum away from the axle shaft flange.



Fig. 11-45 Removing drum (1)



Fig. 11-46 Removing drum (2)

5. Remove the return spring located on the upper




Fig. 11-47 Removing upper spring

side of the brake shoes using a suitable tool, then remove the return spring located on the lower side of the brake shoes.
 6. Remove the shoe hold-down spring from the brake shoe by removing the shoe hold-down spring pin with a plier.




Fig. 11-48 Removing lower spring

7. Remove the primary brake shoe and the parking brake link.




Fig. 11-49 Removing primary brake shoe

8. Disconnect the parking brake lever from the secondary brake shoe by removing the retaining clip. Remove the secondary brake shoe. Do not dirty




Fig. 11-50 Rear brake components

- | | | | |
|------------------------|---------------------------------|-------------------------------|------------------------------|
| 1. Drum attaching bolt | 7. Plug | 13. Clip spring | 19. Screw and washer |
| 2. Drum | 8. Shoe hold-down spring pin | 14. Wave washer | 20. Wheel center cap |
| 3. Brake shoe | 9. Wheel cylinder nut | 15. Brake shoe retaining clip | 21. Set rubber |
| 4. Shoe return spring | 10. Parking brake opening lever | 16. Wheel cylinder | 22. Wheel center cap adaptor |
| 5. Bolt and nut | 11. Operating strut | 17. Brake lining | 23. Balance weight |
| 6. Backing plate | 12. Male-push rod | 18. Brake pipe guard | 24. Rear wheel |

the brake lining with oil.




Fig. 11-51 Removing secondary brake shoe

b. Inspecting rear brake drum and shoe

1. Brush all dust from the backing plate and interior of the brake drum.
2. Inspect the springs for weakness.
3. Inspect the brake shoes for excessive lining wear or shoe damage. If the lining is excessively worn or if the shoes are damaged, they must be replaced. Replace any lining that had been contaminated with oil, grease or brake fluid.
4. Examine the lining contact pattern. To inspect, chalk the entire inner surface of the drum and slide the lining along the chalked surface. The lining should show a uniform contact across the entire width, extending from toe to heel. Shoes having sufficient lining but improper contact should be re-ground to obtain proper contact.



Fig. 11-52 Rear brake shoe

5. Inspect the brake drum and, if necessary, refinish. Minor scores on the brake drum can be removed with sandpaper. The drum that is excessively scored or shows an out of roundness over **0.15 mm (0.0059 in)** should be turned down. Remove only enough stock to eliminate the scores and true up the drum. The refinished diameter must not exceed **261 mm (10.2758 in)**. The standard inner diameter of the drum is **260 mm (10.2364 in)**. After the drum is turned down, wipe the refinished surface with a cloth soaked in clean denatured alcohol. If one drum is turned down, the opposite drum on the same axle should

also be cut down to the same size.

6. Check the condition of the brake shoes, return springs, hold-down springs and drum for signs of overheating. If the shoes and drums are heat spotted, indicating a overheated condition, replace with new ones.

c. Installing rear brake drum and shoe

Follow the removal procedures in the reverse order.

Note :

Adjust the brake shoe clearance.

11-F-2. Wheel Cylinder

a. Removing wheel cylinder

1. Remove the rear brake shoes, as described in Par. 11-F-1.
2. Disconnect the brake fluid pipe from the wheel cylinder by removing the flare nut located on the rear side of the backing plate.
3. Remove the nuts that attach the wheel cylinder to the backing plate and remove the wheel cylinder.




Fig. 11-53 Removing wheel cylinder

b. Disassembling wheel cylinder

1. Remove the boots from both ends of the wheel cylinder.
2. Remove the piston and piston cup assemblies and return spring.
3. Remove the bleeder screw and steel ball, if necessary.

c. Checking wheel cylinder

1. Wash all parts in clean alcohol or brake fluid. **Never use gasoline or kerosene.**
2. Examine the cylinder bore, and piston for wear, roughness, or score.
3. Check the clearance between the piston and the cylinder. If it is **more than 0.15 mm (0.0059 in)**, replace with new parts.
4. Check the piston cups for wear, softening, swelling, or any damage. If any of these conditions exists, replace the cups.

d. Assembling wheel cylinder

1. Apply clean brake fluid to the cylinder bore,

pistons and piston cups.

2. Insert the steel ball into the bleeder hole and thread the bleeder screw into the bleeder hole.

3. Insert the return spring and, piston and piston cup assemblies into their respective position in the cylinder bore.

Note :

When installing the piston cups to the piston, face the lip side of the cups inward.

4. Place the boots over each end of the cylinder.

e. Installing wheel cylinder

Follow the removal procedures in the reverse order.

Note :

Bleed the hydraulic system and adjust the brake shoe clearance

11-G. PARKING BRAKE

11-G-1. Parking Brake Adjustment

The service brake must be properly adjusted before adjusting the parking brake.

Adjust the length of the front cable with the adjusting nut on the end of the front cable so that the brake is locked when the parking brake lever is pulled 5 to 10 notches [40 ~ 80 mm (1.6 ~ 3.1 in)]. After adjustment, apply the parking brake several times, then release and make sure that the rear wheels rotate freely without dragging.




Fig. 11-54 Adjusting parking brake




Fig. 11-55

Wheel cylinder component

- 1. Boot
- 2. Piston
- 3. Piston cup
- 4. Spring
- 5. Bleeder cap
- 6. Bleeder screw
- 7. Steel ball
- 8. Spring
- 9. Filling block
- 10. Adjusting screw

SPECIAL TOOL

49 0221 600B Piston retracting tool

After checking or inflating the pressure, place the valve cap back on and tighten by hand. It helps to maintain the air pressure in the tires in case of any valve leak and keeps dust and water out of the valve.

12-A INFLATION OF TIRES
Maintenance of correct inflation pressure is one of the most important elements of tire care.

Excessive inflation pressure will cause:

1. Hard ride
2. Damage to tire casing
3. Poor traction
4. Premature tread wear in center of tire

Low inflation pressure will cause:

1. Hard steering
2. Rapid and uneven wear
3. Increased road fatigue
4. High tire temperature
5. Blow outs

Check the inflation pressure when the tires are cold. The standard pressure is marked on the tire.


12-B TIRE ROTATION
To equalize wear and make a set of tires last longer, it is recommended that tires be rotated, as shown in the diagram, every 10,000 km (4,000 miles). When rotating the tires, check for signs of abnormal wear and bring any stone, nail, glass, etc. should be removed.

WHEELS AND TIRES



- 12-A. INFLATION OF TIRES.....12 : 1
- 12-B. TIRE ROTATION.....12 : 1
- 12-C. CHANGING WHEELS.....12 : 2
- 12-D. WHEEL AND TIRE RUN-OUT.....12 : 2
- 12-E. WHEEL BALANCING.....12 : 2
- 12-F. FRONT WHEEL HUB.....12 : 3
 - 12-F-1. Removing Front Wheel Hub.....12 : 3
 - 12-F-2. Checking Front Wheel Hub.....12 : 4
 - 12-F-3. Installing Front Wheel Hub.....12 : 4
- 12-G. FRONT WHEEL BEARING.....12 : 5
 - 12-G-1. Checking Front Wheel Bearing.....12 : 5
 - 12-G-2. Adjusting Front Wheel Bearing.....12 : 5
- 12-H. REAR WHEEL BEARING.....12 : 5

- 12-13 Front wheel drive
1. Caliper
 2. Wheel bolt
 3. Center cap
 4. Hub outer bearing
 5. Nut lock
 6. Bearing preload adjusting nut
 7. Grease cap
 8. Flat washer
 9. Hub
 10. Grease seal
 11. Spring
 12. Hub inner bearing
 13. Mounting bracket



WHEELS AND TIRES

12-A. INFLATION OF TIRES

Maintenance of correct inflation pressure is one of the most important elements of tire care.

Excessive inflation pressure will cause:

1. Hard rides
2. Damage to tire carcass
3. Poor traction
4. Premature tread wear in center of tire

Low inflation pressure will cause:

1. Hard steering
2. Rapid and uneven wear on the edges of tire tread
3. Increased cord fatigue or broken tire cords
4. High tire temperature
5. Blow outs

Check the inflation pressure with a reliable gauge when the tires are cold.

The standard pressure is as follows:

Rotary Pickup	Front	Rear
	24 psi	36 psi

After checking or inflating the pressure, place the valve cap back on and tighten by hand. It helps to maintain the air pressure in the tires in case of any valve leak and keeps dust and water out of the valve.

12-B. TIRE ROTATION

To equalize wear and make a set of tires last longer, it is recommended that the tires be rotated, as shown in Fig. 12-1, every 6,000 km (4,000 miles).

When rotating the tires, check for signs of abnormal wear and bulging and any stone, nail, glass, etc. should be removed.




Fig. 12-1 Tire rotation




Fig. 12-2 Front wheel cross section

1. Caliper
2. Wheel bolt
3. Center cap
4. Hub outer bearing
5. Nut lock
6. Bearing preload adjusting nut
7. Grease cap
8. Flat washer
9. Hub
10. Grease seal
11. Spacer
12. Hub inner bearing
13. Mounting adaptor

12-C. CHANGING WHEELS

1. Remove the center cap and loosen the wheel nuts.

Note :

The wheel nuts are loosened by turning these in the counter-clockwise direction on the right side wheels and in the clockwise direction on the left side wheels.

2. Jack up the vehicle until the wheel clears the ground.

3. Remove the wheel nuts and change the wheel.

4. Install the wheel nuts and alternately tighten the diametrically opposite nuts until the wheel closely touches the hub flange.

5. Lower the vehicle and firmly tighten the nuts to a torque of **8.0 ~ 9.0 m·kg (58 ~ 65 ft·lb)**.

6. Refit the center cap.

12-D. WHEEL AND TIRE RUN-OUT

Wheel and tire should be measured for both radial and lateral run-out. The radial run-out is the difference between the high and low points on the tread of tire; while the lateral run-out is the wobble of the wheel.

To measure the radial run-out, apply a dial indicator against the center rib of the tire tread and rotate the wheel slowly. This measurement should not exceed

2.0 mm (0.08 in).

To measure the lateral run-out, position a dial indicator against the side of the tire. The reading of the indicator should be within 2.5 mm (0.10 in).

12-E. WHEEL BALANCING

The allowable unbalance is 600 cm·gr (8.3 in·oz), which is less than 30 gr (1.1 oz) at the rim.

Excessive wheel unbalance causes shimmy at high speed. If unbalance exceeds 600 cm·gr (8.3 in·oz) or when a tire is disassembled for repair, the tire and wheel assembly should be statically and dynamically balanced with a wheel balancer in accordance with the manufacturer's instructions.

Balancing weight

Part No.	Weight	Length
99655 30010	10 g (0.35 oz)	16 ± 1 mm (0.63 ± 0.04 in)
99655 30015	15 g (0.53 oz)	22 ± 2 mm (0.86 ± 0.04 in)
99655 30020	20 g (0.71 oz)	29 ± 2 mm (1.14 ± 0.04 in)
99655 30025	25 g (0.81 oz)	34 ± 2 mm (1.34 ± 0.04 in)
99655 30030	30 g (1.05 oz)	40 ± 2 mm (1.57 ± 0.08 in)
99655 30035	35 g (1.23 oz)	45 ± 2.5 mm (1.77 ± 0.10 in)
99655 30040	40 g (1.41 oz)	51 ± 2.5 mm (2.01 ± 0.10 in)
99655 30045	45 g (1.50 oz)	56 ± 2.5 mm (2.20 ± 0.10 in)
99655 30050	50 g (1.75 oz)	62 ± 2.5 mm (2.44 ± 0.10 in)
99655 30060	60 g (2.12 oz)	73 ± 2.5 mm (2.87 ± 0.10 in)




Fig. 12-3 Rear wheel cross section

1. Wheel
2. Brake drum
3. Brake shoe return spring
4. Center cap
5. Set rubber
6. Center cap adaptor
7. Rear axle shaft
8. Wheel bolt
9. Oil seal
10. Backing plate
11. Wheel cylinder
12. Hub
13. Adjusting shim
14. Lock nut
15. Lock washer
16. Oil seal
17. Bearing
18. Spacer

12-F. FRONT WHEEL HUB

12-F-1. Removing Front Wheel Hub

1. Raise the vehicle with a jack until the front wheels clear the ground.
2. Remove the center cap and remove the wheel.
3. Remove the bolts that attach the caliper and bracket assembly and remove the caliper and bracket assembly.
4. Remove the grease cap from the hub. Remove the cotter pin, nut lock, adjusting nut and flat washer from the spindle.



Fig. 12-4 Removing grease cap

5. Pull the hub and rotor assembly off the spindle.
6. Remove the outer bearing from the hub.




Fig. 12-5 Removing hub and rotor assembly



Fig. 12-6 Removing outer bearing




Fig. 12-7 Front wheel hub components

- | | | | |
|------------------|------------------|----------------|------------------------------|
| 1. Knuckle | 5. Outer bearing | 9. Cotter pin | 13. Caliper mounting adaptor |
| 2. Grease seal | 6. Washer | 10. Grease cap | 14. Caliper assembly |
| 3. Inner bearing | 7. Adjusting nut | 11. Spacer | 15. Steering knuckle |
| 4. Hub | 8. Nut lock | 12. Rotor | |

7. Thoroughly clean the spindle and the inside of the hub with solvent to remove all old grease.

8. Apply the identification marks on the hub and rotor for convenience in reassembly.




Fig. 12-8 Applying identification marks

9. Remove the bolts that attach the hub to the rotor. Remove the hub from the rotor.

10. Drive out the grease seal and remove the spacer and inner bearing from the hub.

11. Clean the lubricant off the outer and inner bear-



Fig. 12-9 Removing inner bearing cup



Fig. 12-10 Installing outer bearing cup

ing cups with solvent and inspect the bearing cups for scratches, pits, excessive wear, and other damage.

If necessary, replace the cup as follows:

1) Remove the outer and inner bearing cups from the hub using a suitable brass rod.

2) Install the inner and outer bearing cups into the hub using a suitable tool. Be sure to seat the cups properly in the hub.

12-F-2. Checking Front Wheel Hub

Thoroughly clean the inner and outer bearings with solvent, and dry them thoroughly.

Note :

Do not spin the bearings dry with compressed air.

Inspect the bearing for wear and damage, and replace them if necessary. The bearing and bearing cup should be replaced as a set if damage to either is encountered.

Check the rotor for thickness. If the thickness of the rotor is less than 11 mm (0.433 in), rotor should be replaced.



Fig. 12-11 Checking rotor thickness

Thoroughly clean the spindle and the hub cavity with solvent to remove all old lubricant.

12-F-3. Installing Front Wheel Hub

1. Pack the inside of the hub with lithium grease.

2. Pack the inner and outer bearings with lithium grease, taking care to fill between rollers.




Fig. 12-12 Tightening hub attaching bolts

3. Place the inner bearing in the inner bearing cup.
4. Install the spacer and grease seal into the hub.
5. Install the hub to the rotor. Install the attaching bolts and tighten the bolts to **4.5 ~ 5.7 m-kG (32.5 ~ 41.2 ft-lb)**.
6. Install the hub and rotor assembly on the spindle.
7. Install the outer bearing, flat washer and adjusting nut.
8. Adjust the wheel bearing preload as described in Par. 12-G-2 on page 12 : 5 and install the nut lock and a new cotter pin. Pack the grease cap with lithium grease and install the grease cap.




Fig. 12-13 Installing nut lock

9. Install the caliper to the mounting adaptor and tighten the attaching bolts.
10. Position the wheel on the hub. Install the wheel bolts and tighten them alternately in order to draw the wheel evenly against the hub.
11. Install the center cap.
12. Pump the brake pedal several times to obtain normal brake lining to rotor clearance and restore normal brake pedal travel.

12-G. FRONT WHEEL BEARING

12-G-1. Checking Front Wheel Bearing

To check the front wheel bearings, raise the vehicle with a jack until the wheels clear the ground.

Grip the tire and shake it sideways. If considerable play is noticed, this indicates that the bearings are rough.

When disassembled, check the wheel bearings for pits, brinell marks or any damage. If any of above conditions exists, replace with new bearings.

12-G-2. Adjusting Front Wheel Bearing

The front wheel bearings should be adjusted if the wheel is loose on the spindle or if the wheel does not rotate freely.

- Adjusting procedures are as follows :
1. Raise the vehicle with a jack until the wheel clears ground.
 2. Remove the center cap and remove the wheel.
 3. Remove the grease cap from the hub.
 4. Wipe the excess grease from the end of the spindle, and remove the cotter pin and nut lock.
 5. Loosen the bearing adjusting nut three turns. Then, rock the hub and rotor assembly in and out several times to push the shoes away from the rotor.
 6. While rotating the hub and rotor assembly, tighten the adjusting nut to seat the bearings.
 7. Back the adjusting nut off about one-six of a turn.

Note :

The bearing preload should be **4 ~ 8 kg-cm (3.5 ~ 7.0 in-lb)** when the hub and rotor assembly is pulled using a pull scale to read the preload.




Fig. 12-14 Checking wheel bearing preload

8. Locate the nut lock on the adjusting nut so that the castellations on the lock are aligned with the cotter pin hole in the spindle.
9. Install a new cotter pin and bend the ends of the cotter pin.
10. Check the wheel rotation. If the wheel rotates properly, install the grease cap. If the wheel still rotates roughly or noisily, clean or replace the bearings and cups as required.
11. Install the grease cap.
12. Install the wheel and tighten the wheel nuts to **8.0 ~ 9.0 m-kG (58.0 ~ 65.0 ft-lb)**.
13. Install the center cap.
14. Pump the brake pedal several times to obtain normal brake lining to rotor clearance and restore normal brake pedal travel.

12-H. REAR WHEEL BEARING

Servicing the rear wheel bearing is explained in Par. 9-A on page 9 : 1.




Fig. 13-1 Front suspension components

- | | | | |
|-------------------|-------------------------|---------------------|----------------|
| 1. Plug | 8. Upper arm shaft | 15. Coil spring | 22. Stopper |
| 2. Thread bush | 9. Upper arm | 16. Seat | 23. Stopper |
| 3. Dust seal | 10. Plug | 17. Adjusting plate | 24. Lower arm |
| 4. Retainer | 11. Set ring | 18. Shock absorber | 25. Bracket |
| 5. Bush | 12. Dust seal | 19. Washer | 26. Set ring |
| 6. Retainer | 13. Ball joint assembly | 20. Bush | 27. Dust seal |
| 7. Adjusting shim | 14. Stopper | 21. Lower arm shaft | 28. Ball joint |




Fig. 13-2 Rear suspension components

- | | | |
|---------------------------|--------------------|----------------------|
| 1. Rear spring | 8. Shackle plate | 15. Stopper rubber |
| 2. Spring pin assembly | 9. Nut and washer | 16. Shock absorber |
| 3. Nut | 10. Bush | 17. Bush |
| 4. Bolt | 11. Spring clamp | 18. Retainer |
| 5. Spacer | 12. Pach | 19. Centering washer |
| 6. Bush | 13. "U" bolt | 20. Nut |
| 7. Shackle plate assembly | 14. Nut and washer | |

SUSPENSION

MAZDA Rotary pickup uses the wishbone type suspension arms with the coil springs on the front and semielliptic leaf springs on the rear.

The shock absorbers are of the hydraulic double action type.

13-A. FRONT SHOCK ABSORBER

13-A-1. Removing Front Shock Absorber

1. Loosen the nuts that attach the upper end of the shock absorber to the cross member.
2. Remove the rubber bushes and washers.
3. Loosen the bolts that attach the lower end of the shock absorber to the lower arm.
4. Remove the shock absorber from under the lower arm.
5. Worn or damaged rubber bushes should be discarded.

13-A-2. Checking Front Shock Absorber

To test the shock absorber, remove from the vehicle. Hold the shock absorber in an upright position and work it up and down in its full length of travel, four or five times.

If a strong resistance is felt due to hydraulic pressure, the shock absorber is functioning properly.

If no resistance is felt or there is a sudden free movement in travel, the shock absorber should be renewed.

If excessive amount of oil is evident on the exterior of the shock absorber, replace with a new shock absorber.

13-A-3. Installing Front Shock Absorber

Install the shock absorber in the reverse order of removing.

Note :

Tighten the shock absorber nut to the dimension shown in Fig. 13-3.




Fig. 13-3 Tightening shock absorber nut

13-B. FRONT SUSPENSION

13-B-1. Removing Front Suspension

1. Jack up the vehicle until the front wheels are clear of the ground.

2. Remove the front wheel.
3. Remove the front shock absorber, as described in Par 13-A-1.
4. Remove the upper ball joint nut and disconnect the ball stud from the steering knuckle, using the **Ball joint puller** (49 0727 575).
5. Remove the nuts and bolts that attach the upper arm shaft to the support bracket, noting the numbers and positions of the adjusting shims so that correct wheel alignment is obtained when reassembled.
6. Remove the upper arm assembly.
7. Disconnect the stabilizer from the lower arm.




Fig. 13-4 Disconnecting stabilizer

8. With the **Spring lifter** (49 0223 640A and 49 0223 641), compress the coil spring.




Fig. 13-5 Coil spring lifter

9. Remove the lower ball joint nut and disconnect the ball stud from the steering knuckle.
10. Remove the bolts that attach the lower arm to the cross member and remove the lower arm assembly and coil spring from the vehicle.

13-B-2. Checking Front Suspension

1. Check for any crack, bend or torsion on both upper and lower arms.
2. Inspect the coil spring for signs of fatigue, crack and any damage.
3. Check the dust seal of the ball joint and replace if it is defective.
4. Check end play of the upper and lower ball joints. If it exceeds 1.0 mm (0.039 in), replace with a new one.

13-B-3. Installing Front Suspension

The procedure for installing the front suspension is in reverse to the removing procedure.

When installing, be careful in the following points:

1. Grease each ball joint by applying the procedure explained in the following paragraph.
2. When fitting the stabilizer, align the white line marked on the stabilizer with the outside of the support bracket.
3. When replacing the coil spring, install a suitable coil spring and adjusting plate to get equal road clearance both on the right and left.

Do not use more than two adjusting plates at one side.

13-B-4. Greasing Front Suspension

The ball joints and the thread bushes (upper arm shaft bushes) of the suspension arms require no greasing for 32,000 miles. When greasing becomes necessary, supply Molybdenum Disulfide Lithium Grease to the ball joints and the thread bushes, proceeding as follows:

Ball Joints:

1. Remove the set ring from the groove on the dust seal and turn the dust seal inside out.
2. Remove the plug and fit the grease nipple in its stead.
3. Remove all of the used grease in the socket and the dust seal by gradually supplying new lithium grease through the nipple.




Fig. 13-6 Greasing ball joint

4. When the used grease is thoroughly removed, fit the dust seal and secure it in place with the set ring.
5. Add new grease until the dust seal begins to balloon. Then, depress the dust seal with the fingers so that about half of the grease remains in the dust seal.
6. Wipe off excess grease around the ball joint.
7. Remove the grease nipple and fit the plug.

Thread Bushes:

1. Remove the plug from one end of the thread bush and fit the grease nipple in its stead.
2. Remove all of the used grease in the thread bush and the dust seal by gradually supplying new grease

through the nipple.

3. When the used grease is thoroughly removed, add new grease until new grease appears from the brim of the dust seal.
4. Remove the grease nipple and reinstall the plug.
5. Grease to the other end of the thread bush in the same manner described above.
6. Wipe off excess grease around the thread bush.




Fig. 13-7 Greasing thread bushes

13-C. REAR SHOCK ABSORBER**13-C-1. Removing Rear Shock Absorber**

1. Remove the nuts, washers, and rubber bushes from both the upper and lower ends of the shock absorber.




Fig. 13-8 Removing rear shock absorber

2. Compress the shock absorber and remove it from the vehicle.
3. If the rubber bushes appear to be worn, damaged, or deteriorated, replace with new ones.

13-C-2. Checking Rear Shock Absorber

Check the rear shock absorber by referring to Par. 13-A-2.

13-C-3. Installing Rear Shock Absorber

Install the rear shock absorber in the reverse order of removing.

Note :

Tighten the shock absorber nuts to the dimension shown in Fig. 13-9.




Fig. 13-9 Tightening shock absorber nut

13-D. REAR SPRING

13-D-1. Removing Rear Spring

1. Raise the vehicle and place a stand under the frame side rail, permitting the spring to hang free.
2. Support the rear axle in this position with the jack.
3. Disconnect the rear shock absorber at the lower mounting point.
4. Remove the "U" bolt nuts and the spring clamp.
5. Remove the spring pin nut and remove two bolts and nuts attaching the spring pin plate to the frame bracket.
6. Remove the spring pin and bushes and remove the front end of the spring from the vehicle.
7. Remove the shackle pin nuts and shackle plate and remove the rear end of the spring from the vehicle.

13-D-2. Checking Rear Spring

1. Check the spring for corrosion, wear, fatigue or any damage. If any of these conditions exists, replace the spring.
2. Check the looseness of the spring center bolt.
3. Check the shackle pin and bushes for wear. If excessive wear is found, they should be replaced with new ones.

13-D-3. Installing Rear Spring

1. Install the rubber bushes into the front eye of the spring and position it in the frame bracket so as to align the holes of the rubber bushes with the hole of the frame bracket.
2. Insert the spring pin from the outside through the rubber bushes.
3. Tighten the nuts and bolts attaching the spring pin plate to the frame bracket with a torque of 2.0 ~ 2.5 m-kG (14 ~ 18 ft-lb). Do not tighten the spring pin nut.
4. Fit the rubber bushes to the rear eye of the spring




Fig. 13-10 Inserting spring pin

and the shackle pin. Install the spring and the shackle pin to the frame bracket. Do not tighten the nuts.



Fig. 13-11 Installing shackle pin

5. Lower the rear axle and place the center hole of the axle spring seat over the head of the spring center bolt.
6. Place the spring plate under the spring and install the "U" bolts. Tighten the nuts to a torque of 6.4 ~ 8.0 m-kG (46 ~ 58 ft-lb).
7. Remove the stand and lower the vehicle.
8. Jounce the vehicle several times, and tighten the pivot bolt and shackle pin nuts to a torque of 8.5 ~ 10.5 m-kG (61 ~ 76 ft-lb).

Note :

According to the size of camber, the rear springs are classified into the three categories of -, 0, and +. They are marked on the main leaf. Since difference in camber between the right and left springs results in a difference in road clearance causing inclination of the vehicle, those with the same mark should be installed on both sides.


SPECIAL TOOLS

- | | |
|---------------------|--------------------|
| 49 0727 575 | Ball joint puller |
| 49 0223 640 and 641 | Coil spring lifter |



BODY


- 14-A. WINDSHIELD GLASS..... 14 : 1
 - 14-A-1. Removing Windshield Glass..... 14 : 1
 - 14-A-2. Installing Windshield Glass..... 14 : 1
- 14-B. BACK WINDOW..... 14 : 1
- 14-C. DOOR..... 14 : 1
 - 14-C-1. Disassembling Door..... 14 : 1
 - 14-C-2. Assembling Door..... 14 : 2
 - 14-C-3. Adjusting Door..... 14 : 2
- 14-D. HEADLINING (Top ceiling)..... 14 : 3
 - 14-D-1. Removing Headlining..... 14 : 3
 - 14-D-2. Installing Headlining..... 14 : 4
- 14-E. INSTRUMENT PANEL..... 14 : 5
 - 14-E-1. Removing Meter Set..... 14 : 5
 - 14-E-2. Installing Meter Set..... 14 : 5
 - 14-E-3. Removing Center Panel..... 14 : 5
 - 14-E-4. Installing Center Panel..... 14 : 5



14-B. BACK WINDOW
 Remove the back window and make it spring the same direction as the windshield glass.

14-C. DOOR
 14-C-1. Disassembling Door
 1. Remove the arm rest and garnish plate.
 2. Remove the inside door handle and the window regulator handle by pressing in the regulator and moving the holding nut as shown in Fig. 14-7.
 3. Remove the trim panel and the inside screen (water shield).
 4. Remove the screws holding the window sill as written in the next chapter. Remove the door trim and slide

14-A. WINDSHIELD GLASS
 14-A-1. Removing Windshield Glass
 1. Remove the windshield wiper arm and blade.
 2. Remove the windshield from the windshield frame by removing the adhesive sealant between the window and the body frame with a weather stripping knife.
 3. Put out the hood up at the weatherstripping edge of the windshield with weatherstripping knife. Make the window frame ready for the windshield glass.



14-A-2. Installing Windshield Glass
 Before installing the windshield glass clean off all the adhesive covering thoroughly from the windshield glass and the body.
 1. Install the weatherstripping along the circumference of the windshield glass as shown in Fig. 14-8.



14-E. INSTRUMENT PANEL
 14-E-1. Removing Meter Set
 1. Apply a small amount of liquid soap to the groove of the weatherstripping which is fitted to the body frame.
 2. Put a pry bar in front of the instrument panel as shown in Fig. 14-9.

BODY

14-A. WINDSHIELD GLASS

14-A-1. Removing Windshield Glass

1. Remove the windshield wiper arms and blades.
2. Remove the windshield mould from weatherstrip.
3. Detach the adhesive cement between the weatherstrip and the body flange with a wooden spatula.
4. Push out the inner lip of the weatherstrip along the edge of the windshield with a suitable tool from inside the vehicle while pushing the windshield glass outwards.



Fig. 14-1 Pushing out inner lip of weatherstrip

5. Remove the windshield glass together with the weatherstrip.
6. Remove the weatherstrip from the windshield glass.

14-A-2. Installing Windshield Glass

Before installing the windshield glass, clean off an old adhesive cement thoroughly from the windshield glass and the body.

1. Install the weatherstrip along the circumference of the windshield glass as shown in Fig. 14-2.




Fig. 14-2 Installing weatherstrip

2. Apply a liberal amount of liquid soap in the groove of the weatherstrip, which is fitted to the body flange.
3. Fit a string of 4 mm (0.16 in) in diameter to the groove of the weatherstrip as shown in Fig. 14-3.



Fig. 14-3 Fitting string

4. Place the windshield glass and weatherstrip assembly into position on the body flange.
5. Pull the string so as to place the inner lip over the flange as shown in Fig. 14-4. At the same, tap the glass from the outside to settle it into position.




Fig. 14-4 Installing windshield glass

6. Make the weatherstrip and the body flange contact properly with a screwdriver.
7. Seal the weatherstrip against the glass and the body flange by carefully applying a thin coat of Rubber Sealer.

14-B. BACK WINDOW

Remove the back window and install it applying the same method as the windshield glass.

14-C. DOOR

14-C-1. Disassembling Door

1. Remove the arm rest and garnish plate.
2. Remove the inside door handle and the window regulator handle by pressing in the escutcheon and removing the holding pin as shown in Fig. 14-5.
3. Remove the trim board and the inside screen (water shield).
4. Remove the screws holding the window sash assembly to the door. Lower the door glass and slide



Fig. 14-5 Removing regular handle



Fig. 14-6 Removing trim board

If it becomes necessary to remove the headliner, proceed as follows to remove the window sash up out of the door.



Fig. 14-7 Removing window sash

5. Disengage the guide groove at the glass from the regulator arm and remove the glass.
6. Remove the screws attaching the door handle and remove the outer handle.



Fig. 14-8 Removing glass

7. Using a screw driver, pry the retainer off from the key cylinder groove and remove the key cylinder.



Fig. 14-9 Prying cylinder retainer

8. Remove the screws that attach the door lock assembly to the door. Remove the screws that attach the remote control assembly to the door inner panel, and remove the door lock and remote control assembly.
9. Remove the four screws attaching the regulator assembly to the door inner panel, and remove the regulator assembly.

14-C-2. Assembling Door

Assemble the door in the reverse order of disassembling noting the following point. Install each water shield securely and apply Sealer to the screw threads, as faulty sealing will cause water leaks.

14-C-3. Adjusting Door

The door hinges are constructed to permit up and

down, and in and out adjustments. To adjust, loosen the upper and lower door hinge attaching screws and move the door up or down, in or out until correct alignment is obtained. Fore and aft door adjustments are also possible through the use of shims between the hinge and hinge pillar.



Fig. 14-10 Adjusting door hinge

The door striker is attached to the pillar through oversize holes permitting movement of the striker up and down, in and out. Fore and aft adjustment can be made by adding or subtracting shims between the striker and pillar. The striker should be adjusted so that the door lock enters freely and door will remain in closed position.




Fig. 14-11 Adjusting door striker

14-D. HEADLINING (Top ceiling)

14-D-1. Removing Headlining

If it becomes necessary to remove the headlining, proceed as follows:

1. Remove the windshield glass and the rear window,




Fig. 14-12

Door components

1. Striker seat
2. Door look striker
3. Door look rack
4. Door look
5. Seat No. 1
6. Outer handle
7. Seat No. 2
8. Door hinge
9. Bush
10. Hinge pin
11. Spacer
12. Door checker set plate
13. Check sub spring
14. Check spring
15. Checker washer
16. Checker pin
17. Checker roller
18. Window regulator
19. Escutcheon crown
20. Handle escutcheon
21. Regulator handle
22. Tapered pin
23. Inner handle
24. Anti-burst block
25. Anti-burst block shim
26. Arm rest
27. Garnish

- as described in Par. 14-A and 14-B.
- 2. Remove the rear view mirror and sun visor.
- 3. Pull the headlining loose from the cemented area at the windshield headers and the door openings.
- 4. Disengage the front and center listing wires from the holes in the left and right roof rails.
- 5. Remove the interior lamp attaching screws, disconnect the wire and remove the interior lamp.
- 6. Remove the screws that attach the rear listing wire brackets to the back plate.
- 7. Pull the rear listing wire upward and remove the headlining from the vehicle.

14-D-2. Installing Headlining

- 1. Beginning at the rear, insert both ends of rear listing wire into the holes of the back plate, as shown in Fig. 14-13.




Fig. 14-13 Inserting rear listing wire

- 2. Install the fixing brackets, attached to rear listing wire, to the back plate with screws.



Fig. 14-14 Installing listing wire bracket

- 3. Cut a hole in the headlining material for the interior lamp and connect the wire through the headlining.
- 4. Install the remaining two listing wires into the side roof rails, making sure to stretch the headlining evenly as shown in Fig. 14-15.
- 5. Apply cement to the front and rear headers.

- 6. Wait until it becomes tacky, then cement the headlining in place at front and rear, stretching the headlining to make it taut.




Fig. 14-15 Installing listing wire



Fig. 14-16 Gluing headlining

- 7. Trim the material properly at the corners to prevent wrinkling, as shown in Fig. 14-17, and cement to the pillars.



Fig. 14-17 Trimming headlining material

- 8. Tighten the interior lamp attaching screws.
- 9. Trim the excess material at the front and rear.
- 10. Install the rear view mirror and sun visor.
- 11. Install the windshield glass and the rear window, as described in Par. 14-A-2.

14-E. INSTRUMENT PANEL

14-E-1. Removing Meter Set

1. Remove the two bolts attaching the steering shaft bracket to the instrument panel.
2. Remove the four screws attaching the meter set to the instrument panel.




Fig. 14-18 Meter set attaching screws

3. Reach under the instrument panel and disconnect the speedometer cable by pressing on the flat surface of the plastic connector and pulling the cable away from the head.




Fig. 14-19 Disconnecting speedometer cable

4. Disconnect the wiring connectors from the meter set and remove the meter set.

14-E-2. Installing Meter Set

Follow the removal procedures in the reverse order.

14-E-3. Removing Center Panel

1. Pull and remove the heater control knobs, radio control knobs and resistor knob.
2. Remove the nuts attaching the radio to the center panel.




Fig. 14-20 Removing nuts

3. Remove the cigar lighter from the center panel.
4. Remove the nut attaching the panel resistor to center panel and disconnect the wirings from the resistor.




Fig. 14-21 Removing panel resistor

5. Loosen the two screws attaching the center panel to the instrument panel and remove the center panel.

14-E-4. Installing Center Panel

Follow the removal procedures in the reverse order.

ELECTRICAL SYSTEM

(BODY)

DESCRIPTION.....	15 : 1
15-A. COMBINATION SWITCH.....	15 : 1
15-A-1. Checking Combination Switch.....	15 : 1
15-B. IGNITION SWITCH.....	15 : 2
15-B-1. Checking Ignition Switch.....	15 : 2
15-C. INHIBITOR SWITCH.....	15 : 2
15-C-1. Checking Inhibitor Switch.....	15 : 2
15-D. HEATER FAN SWITCH.....	15 : 2
15-D-1. Checking Heater Fan Switch.....	15 : 2
15-E. CENTRAL CONTROL UNIT.....	15 : 2
15-E-1. Checking Central Control Unit.....	15 : 2
15-F. WIPER MOTOR.....	15 : 3
15-F-1. Checking Wiper Motor.....	15 : 3
15-G. METER.....	15 : 3
15-G-1. Checking Meter Set Print Panel.....	15 : 3
15-G-2. Checking Fuel Meter.....	15 : 3
15-G-3. Checking Water Thermometer.....	15 : 3



The electrical PM and HP are connected through the light switch and are fed on the supply.

Fig. 2. Light, Ignition and Heating Switch Interconnection Diagram.

DESCRIPTION

As a simple method of inspecting each unit of the body electrical equipment, a circuit tester has been taken up in the Workshop Manual. In this case, however, possible contact resistance is not taken into account. Accordingly, please note that even when the circuit tester shows that the continuity to a unit is satisfactory, in case constant resistance has increased, there is a possibility of the unit not working properly. So pay due attention to this point.

15-A. COMBINATION SWITCH

15-A-1. Checking Combination Switch

Check the continuity between the coupler terminals using the circuit tester according to the following switch interconnection diagram.

1. Turn Signal and Hazard Switch




Fig. 15-1 Turn signal and hazard switch interconnection diagram

2. Light, Dimmer and Passing Switch




Fig. 15-2 Light, dimmer and passing switch interconnection diagram

3. Wiper and Washer Switch




Fig. 15-3 Wiper and washer switch interconnection diagram

15-B. IGNITION SWITCH

15-B-1. Checking Ignition Switch

Check the continuity between the switch terminals using the circuit tester according to Fig. 15-4, interconnecting diagram.





Fig. 15-4 Ignition switch interconnection diagram

15-C. INHIBITOR SWITCH

15-C-1. Checking Inhibitor Switch

Check the continuity between the coupler terminals using the circuit tester according to the following diagram.

Inhibitor Switch Interconnection Diagram



Notes:

- a. Solid lines show the connection for indicator light circuit.
- b. Dotted lines show the connection for starting circuit.




Fig. 15-5 Inhibitor switch coupler

15-D. HEATER FAN SWITCH

15-D-1. Checking Heater Fan Switch

Check the continuity between the coupler terminals using the circuit tester according to Fig. 15-6.




Fig. 15-6 Heater fan switch interconnection diagram

15-E. CENTRAL CONTROL UNIT

The central control unit is composed of wiper relay (R1 and R2), flasher relay (R3), horn relay (R4) and flasher unit (U1), each of which is a plug-socket connection type. Each relay and unit are easy to replace. In replacing the flasher unit, care should be taken that its capacity differs depending upon area. Also, the "multi-grade relay" has been prepared which is applicable as replacement of any of the relays.

15-E-1. Checking Central Control Unit

Check the central control unit using the battery and circuit tester as follows:

1. Wiper relay (R1)

When the battery ⊕ is connected to the WIG terminal and the battery ⊖ to the S2 terminal, LOW terminal and unit body should be in continuity with each other.

2. Wiper relay (R2)

(a) When the battery ⊕ is connected to the WIG terminal and the battery ⊖ to the S2 and S3 terminals, H1 terminal and unit body should be in continuity with each other.

(b) AS terminal and LOW terminal should be in continuity with each other without connecting the battery to them.

3. Horn relay (R4)

When the battery ⊕ is connected to the HZB terminal and the battery ⊖ to the HNS terminal, HZB terminal and HON terminal should be in continuity with each other.




Fig. 15-7 Central control unit coupler

4. Flasher unit (U1)

In checking the flasher unit, connect a prescribed lamp as indicated on the central control unit cover between the unit (with the flasher relay R3) and battery as shown in Fig. 15-8.

(a) Turn signal

When the battery ⊕ is connected to the FB terminal and a prescribed lamp between the battery ⊖ and TFU terminal, the lamp must turn on and off 90 ± 10 times per minute with interval between flasher under 1.5 second.

(b) Hazard

When the battery ⊕ is connected to the HFU terminal and a prescribed lamp between the battery ⊖ and TFU terminal, the lamp must turn on and off 90 ± 10 times per minute with the interval between flasher under 1.5 second.




Fig. 15-8 Hazard and flasher unit interconnection diagram

Note:

The flashing on and off of the lamp varies depending upon the lamp capacity and the central control unit earth condition as follows:

Flasher

Faulty unit earth	Lamp remains lighted
Lamp capacity decreased	Flash becomes slower or lamp remains lighted
Lamp capacity increased	Number of flashes remains unchanged

Hazard

Faulty unit earth	Lamp remains lighted
Lamp capacity decreased	Number of flashes remains unchanged
Lamp capacity increased	Number of flashes remains unchanged




Fig. 15-9 Central control unit circuit

15-F. WIPER MOTOR

15-F-1. Checking Wiper Motor

Connect the wiper motor, ammeter and battery according to the following diagram, and check the number of wiping revolutions and amperage.

Wiper motor	Wiping revolution number	Amperage
Low	42 ~ 55 RPM	Less than 2.5A
High	62 ~ 85 RPM	Less than 2.5A

Notes:

- a. The difference in number of revolutions between Low and High should be more than 15 RPM.
- b. The Auto Stop does not work in the case of faulty wiper motor earth.




Fig. 15-10 Wiper motor interconnection diagram

15-G. METER

15-G-1. Checking Meter Set Print Panel

Check the continuity between connector pin and lamp, and that between connector pin and meter using the circuit tester according to the interconnection diagram below.




Fig. 15-11 Print panel interconnection diagram

15-G-2. Checking Fuel Meter

Connect the battery, meter and resistor according to the following diagram, and check the meter indicator in the order of F, 1/2 and E.




Fig. 15-12 Fuel meter interconnection diagram

Note:

The permissible error of the fuel meter indication is a width of the indicator needle to either upper or lower side as shown in Fig. 15-13.




Fig. 15-13 Fuel meter

15-G-3. Checking Water Thermometer

Connect the battery, meter and resistor according to the following diagram, and check the meter indicator in the order of 35°, 110° and 120°C.




Fig. 15-14 Water thermometer interconnection diagram

Note:

The permissible error of the water thermometer indication is a width of the indicator needle to either upper or lower side as shown in Fig. 15-15.




Fig. 15-15 Water thermometer

ENGINE (General Data)			
Type	Rotary Pickup	Height	3.5 mm (0.138")
Displacement	Rotary piston engine, 2 rotors in line, water cooled	Clearance of side seal and rotor groove (ΔW)	
Compression ratio	654 cc (40.0 cu-in) x 2 rotors	New	0.04 ~ 0.07 mm (0.0016 ~ 0.0028")
Compression pressure	9.2 : 1	Limit	0.10 mm (0.004")
Limit	6 kg/cm ² (85 lb/in ²) at 250 rpm	Clearance of side seal and corner seal (ΔE)	
Max. permissible difference between chambers	0.5 kg/cm ² (7 lb/in ²)	New	0.05 ~ 0.15 mm (0.0020 ~ 0.0059")
Port timing		Limit	0.40 mm (0.016")
Intake opens	32° ATDC	Side seal spring	
Intake closes	50° ABDC	Free height	
Exhaust opens	75° BBDC	New	1.9 mm (0.075")
Exhaust closes	38° ATDC	Limit	1.7 mm (0.067")
		Oil seal	
		Height	5.6 mm (0.220")
		Contact width of oil seal lip	
		New	0.2 mm (0.008")
		Wear limit	0.8 mm (0.031")
		Oil seal spring	
		Free height	
		New	Inner : 2.8 mm (0.110")
		Limit	Outer : 2.6 mm (0.102")
		Corner seal	2.0 mm (0.079")
		Outer diameter	
		Standard	11.0 ^{-0.020} _{-0.030} mm (0.4331 ^{-0.0008} _{-0.0012})
		0.03 over size	11.0 ⁺⁰ _{-0.015} mm (0.4331 ⁺⁰ _{-0.0006})
		0.20 over size	11.2 ^{-0.020} _{-0.030} mm (0.4410 ^{-0.0008} _{-0.0012})
		Height	
		Standard	7.0 ⁺⁰ _{-0.2} mm (0.2756 ⁺⁰ _{-0.0079})
		0.03 over size	6.8 ⁺⁰ _{-0.2} mm (0.2677 ⁺⁰ _{-0.0079})
		0.20 over size	(7.0 ⁺⁰ _{-0.2} mm) (0.2756 ⁺⁰ _{-0.0079})
		Clearance of corner seal and rotor groove (ΔC)	
		New	0.020 ~ 0.048 mm (0.0008 ~ 0.0019")
		Limit	0.08 mm (0.0031")
		Corner seal spring	
		Free height	
		New	2.5 mm (0.098")
		Limit	1.7 mm (0.067")
		Main bearing	
		Inner diameter (Installed)	43 ^{+0.050} _{+0.025} mm (1.6929 ^{+0.0020} _{+0.0010})
Side housings (Front, intermediate and rear housings)			
Limit of distortion	0.04 mm (0.0016")		
Limit of wear			
Sliding surface	0.10 mm (0.0039")		
Joint surface	0.05 mm (0.0020")		
Rotor housing			
Width	80 mm (3.1497")		
Max. permissible difference in width	0.06 mm (0.0024")		
Limit of distortion	0.04 mm (0.0016")		
Limit of wear	0.07 mm (0.0028")		
Rotor			
Width	79.85 mm (3.1438")		
Clearance of side housing and rotor (ΔR)			
New	0.12 ~ 0.21 mm (0.0047 ~ 0.0083")		
Minimum	0.10 mm (0.0039")		
Protrusion of land (ΔH)			
New	0.10 ~ 0.15 mm (0.004 ~ 0.006")		
Limit	Minimum : 0.085 mm (0.003")		
	Maximum : 0.20 mm (0.008")		
Apex seal			
Length	79.85 mm (3.1438")		
Width	3 mm (0.1181")		
Height			
New	8.5 mm (0.335")		
Limit	7.0 mm (0.276")		
Clearance of apex seal and side housing (ΔS)			
New	0.13 ~ 0.17 mm (0.0051 ~ 0.0067")		
Limit	0.30 mm (0.012")		
Clearance of apex seal and rotor groove (ΔG)			
New	0.051 ~ 0.089 mm (0.0020 ~ 0.0035")		
Limit	0.15 mm (0.006")		
Apex seal spring			
Free height			
New	4.7 mm (0.185") or more		
Limit	3.8 mm (0.150")		
Side seal			
Thickness	1.0 mm (0.039")		

<p>Bearing clearance New Wear limit Rotor bearing Inner diameter (Installed) Bearing clearance New Wear limit Eccentric shaft Eccentricity of rotor journal Main journal diameter Rotor journal diameter Max. permissible run-out End play New Limit Oil capacity Oil pan Full capacity</p>	<p>0.04 ~ 0.07 mm (0.0016 ~ 0.0028") 0.10 mm (0.0039") 74^{+0.050}_{+0.025} mm (2.9134^{+0.0020}_{+0.0010}) 0.04 ~ 0.08 mm (0.0016 ~ 0.0031") 0.10 mm (0.0039") 15.0 mm (0.59") 43^{-0.015}_{-0.030} mm (1.6929^{-0.0006}_{-0.0012}) 74^{-0.015}_{-0.030} mm (2.9134^{-0.0006}_{-0.0012}) 0.06 mm (0.0024") 0.04 ~ 0.07 mm (0.0016 ~ 0.0028") 0.09 mm (0.0035") 5.0 liters (5.3 U.S. quarts) 6.4 liters (6.8 U.S. quarts)</p>	<p>Operating pressure Free length of spring Pressure control valve (Front cover) Operating pressure Free length of spring Oil thermo pellet (Oil cooler) Starts to close Fully closes Oil filter Type Relief valve opens at Oil metering pump Feeding capacity of 2000 rpm of engine Lubricant -10°C ~ 40°C (15°F ~ 100°F) -18°C ~ 50°C (0°F ~ 120°F) -18°C ~ 40°C (0°F ~ 100°F) -18°C ~ 30°C (0°F ~ 85°F) Below -18°C (0°F)</p>	<p>5.0 kg/cm² (71 lb/in²) 46.4 mm (1.827") 11.0 kg/cm² (156 lb/in²) 73.0 mm (2.874") 60 ~ 65°C (140 ~ 149°F) 70 ~ 75°C (158 ~ 167°F) Full flow, cartridge 0.8 ~ 1.2 kg/cm² (11 ~ 17 lb/in²) 2.2 cc/6min. (0.074 U.S. oz/6 min.) SAE 20W-40 or 20W-50 SAE 10W-50 SAE 10W-40 SAE 10W-30 SAE 5W-20 or 5W-30</p>
<p>LUBRICATING SYSTEM</p>		<p>COOLING SYSTEM</p>	
<p>Oil pump Type Feeding capacity at 1000 rpm (Engine revolution) Oil pump driven by Limit of chain adjuster protrusion Outer rotor and body clearance New Wear limit Clearance between rotor lobes New Wear limit Rotor end float New Wear limit Oil pressure at 3000 rpm of engine Safe minimum pressure at idle Pressure regulator valve (Rear housing)</p>	<p>Rotor 6 liter/min (1.59 U.S. gal/min) Chain and sprockets 12 mm (0.47") 0.20 ~ 0.25 mm (0.008 ~ 0.010") 0.30 mm (0.012") 0.01 ~ 0.09 mm (0.0004 ~ 0.0035") 0.15 mm (0.006") 0.03 ~ 0.13 mm (0.001 ~ 0.005") 0.15 mm (0.006") 5.0 kg/cm² (71 lb/in²) 0.3 kg/cm² (4.3 lb/in²)</p>	<p>Water pump Type Feeding capacity at 6500 rpm of engine Pump driven by Pulley ratio of eccentric shaft and pump Fan Fan diameter Number of blades Fan drive Standard revolution of fan "V" belt tension (Slack) New belt Used belt Thermostat Type Starts to open Fully opens at Lift Radiator Type Pressure cap opens at Cooling capacity With heater</p>	<p>Centrifugal impeller 160 ~ 170 liter/min. (42 ~ 45 U.S. gal/min.) "V" belt 1 : 1.18 390 mm (15.4") 8 1400 rpm or more at 1500 rpm of engine 2000 ~ 2500 rpm at 5000 rpm of engine 13 mm (0.51") 15 mm (0.59") Wax pellet 82 ± 1.5°C (180 ± 2.7°F) 95°C (203°F) 8 mm (0.315") or more Corrugated fin, with expansion tank 0.9 kg/cm² (13 lb/in²) 10.2 liters (10.8 U.S. quarts)</p>

FUEL SYSTEM		Canada		Battery			
Fuel tank capacity	78.5 liters (20.4 U.S. gal)			Type	N70Z	N70Z	Y110-5
Fuel pump				Voltage	12 volt	12 volt	12 volt
Type	Electrical, plunger			Capacity (20 hour rate)	70 amp- hr	70 amp- hr	60 amp- hr
Fuel pressure	0.25 ~ 0.35 kg/cm ² (3.6 ~ 5.0 lb/in ²)			Terminal ground	Negative	Negative	Negative
Feeding capacity	More than 1150 cc/min (1.2 U.S. quart/min)			Specific gravity at 20°C (68°F)			
Fuel filter	Cartridge, paper element			Fully charged	1.28	1.28	1.28
Carburetor				Recharge at	1.22	1.22	1.22
Type	Down draft, two stage four barrel			Alternator			
Throat diameter				Ground	Negative		
Primary	28 mm (1.10")			polarity			
Secondary	34 mm (1.34")			No load test			
Venturi diameter				Voltage	14 volt		
Primary	22 x 13 x 6.5 mm (0.87 x 0.51 x 0.26")			Current	0 amp		
Secondary	28 x 10 mm (1.10 x 0.39")			Revolution	1050 rpm or less		
Main nozzle				Load test			
Primary	2.5 mm (0.0984")			Voltage	14 volt		
Secondary	3.0 mm (0.1181")			Current	40 amp		
Main jet				Revolution	2500 rpm or less		
Primary	#106			Number of brushes	2		
Secondary	#140			Brush length			
Main air bleed				New	16 mm (0.63")		
Primary	# 80			Wear limit	10 mm (0.39")		
Secondary	#160			Brush spring pressure	330 ~ 450 gr (12 ~ 16 oz)		
Slow jet				Slip ring diameter			
Primary	# 50			New	33 ± 0.2 mm (1.299 ± 0.008")		
Secondary	# 90			Limit	32.5 mm (1.280")		
Slow air bleed				Pulley ratio of eccentric shaft and alternator	1 : 2.08		
Primary	#190			Regulator			
Secondary	#150			Constant voltage relay			
Vacuum jet				Air gap	0.7 ~ 1.3 mm (0.028 ~ 0.051")		
Primary	# 2.2			Point gap	0.3 ~ 0.45 mm (0.012 ~ 0.018")		
Secondary	# 1.2			Back gap	0.7 ~ 1.5 mm (0.028 ~ 0.059")		
Fast idle adjustment	M/T: 1.01 ~ 1.33 mm (0.040 ~ 0.052")			Regulated voltage without load at 4000 rpm of alternator	14.5 ± 0.5 volt		
(Clearance between Primary throttle valve and bore when choke valve is fully closed)	A/T: 1.22 ~ 1.57 mm (0.048 ~ 0.062")			Pilot lamp relay			
Secondary throttle valve adjustment	7.1 mm (0.280")			Air gap	0.9 ~ 1.4 mm (0.035 ~ 0.055")		
(Clearance between primary throttle valve and bore when secondary throttle valve starts to open)				Point gap	0.7 ~ 1.1 mm (0.028 ~ 0.043")		
Idle speed				Back gap	0.7 ~ 1.5 mm (0.028 ~ 0.059")		
Manual transmission	900 ⁺⁷⁰ - 0 rpm			Pilot lamp lights on	3.5 volt or less		
Automatic transmission (D range)	750 ⁺⁷⁵ - 0 rpm			Pilot lamp light out	3.5 ~ 5.7 volt		
CO concentration at idle	0.1 ~ 2.0 %			Ignition coil			
HC concentration at idle	Less than 200 ppm			Primary resistance			
ELECTRICAL SYSTEM				Leading	1.35 Ω at 20°C (68°F)		
		Canada		Trailing	1.46 Ω at 20°C (68°F)		
		U.S.A.		Secondary resistance			
			M/T	Leading	8.7 KΩ at 20°C (68°F)		
			A/T	Trailing	9.5 KΩ at 20°C (68°F)		
				External resistance			
				Leading	1.4 Ω at 20°C (68°F)		
				Trailing	1.6 Ω at 20°C (68°F)		

	M/T	A/T	Timing mark location	Eccentric shaft pulley	Eccentric shaft pulley
Starting motor			Standard type	N.G.K.B-7EM, BR-7EM, B-7EMV or BR-7EMV Nippon Denso W22EA, W22EAR, W22EA-G or W22EAR-G Champion N-80B or RN-80B 0.6 ~ 0.7 mm (0.024 ~ 0.028")	
Capacity	1.2 kw	2.0 kw	Spark plug Type		
Lock test					
Voltage	5.0 volt	5.0 volt			
Current	780 amp or less	1100 amp or less			
Torque	1.1 m-kg (8.0 ft-lb)	2.4 m-kg (17.4 ft-lb)			
Free running test			Spark plug gap		
Voltage	11.5 volt	11.5 volt	CLUTCH		
Current	75 amp or less	100 amp or less	Type	Single dry plate, diaphragm spring	
Speed	4900 rpm or more	7800 rpm or more	Pressure plate	Permissible lateral run-out 0.05 mm (0.0020")	
Number of brushes	4	4	Clutch disc	Lateral run-out of clutch disc Limit 1.0 mm (0.039")	
Brush length			Clutch release mechanism	Hydraulic	
New	18.5 mm (0.73")	18.5 mm (0.73")	Release fork free play	-	
Wear limit	11.5 mm (0.45")	11.5 mm (0.45")	Clutch pedal free play (Before push rod contacts with piton)	0.5 ~ 3.0 mm (0.02 ~ 0.12")	
Brush spring pressure	1.4 ~ 1.8 kg (49 ~ 63 oz)	1.4 ~ 1.8 kg (49 ~ 63 oz)	Master cylinder bore	15.87 mm (5/8")	
Control switch	Solenoid	Solenoid	Clearance between piston and master cylinder bore	New 0.032 ~ 0.102 mm (0.0013 ~ 0.0040")	
Voltage required to close solenoid contacts	8 volt or less	8 volt or less	Wear limit	0.15 mm (0.006")	
			Release cylinder bore	Clearance between piston and release cylinder bore New 0.040 ~ 0.125 mm (0.0016 ~ 0.0049")	
			Wear limit	0.15 mm (0.006")	
				MANUAL TRANSMISSION	
				Type	4-speed manual transmission
				Gear ratio	
				First	3.683
				Second	2.263
				Third	1.397
				Top	1.000
				Reverse	3.692
				Main shaft	
				Max. permissible run-out	0.03 mm (0.0012")
				Clearance between main shaft and gear (or bush)	
				Wear limit	0.15 mm (0.006")
				Reverse idle gear	
				Clearance between reverse idle gear bush and shaft	
				Wear limit	0.15 mm (0.006")
				Shift fork and rod	
				Clearance between shift fork and clutch sleeve	
				Wear limit	0.5 mm (0.020")
				Clearance between shift fork and reverse idle gear	
Distributor					
Number of contact points	2	2			
Contact point gap	0.45±0.05 mm (0.018±0.002")	0.45±0.05 mm (0.018±0.002")			
Contact point pressure	500 ~ 650 gr (18 ~ 23 oz)	500 ~ 650 gr (18 ~ 23 oz)			
Dwell angle	55~61°	55~61°			
Centrifugal advance					
Leading	Starts : 0±1° at 500 rpm Maximum : 10±1° at 2000 rpm	Starts : 0±1° at 500 rpm Maximum : 10±1° at 2000 rpm			
Trailing	Starts : 0±1.5° at 500 rpm Maximum : 10±1.5° at 1500 rpm	Starts : 0±1.5° at 500 rpm Maximum : 10±1.5° at 2000 rpm			
Vacuum advance					
Leading	-	-			
Trailing	Starts : 0±1.5° at 100 mm-Hg (3.94 in-Hg) Maximum : 15±1.5° at 400 mm-Hg (15.75 in-Hg)	Starts : 0±1.5° at 100 mm-Hg (3.94 in-Hg) Maximum : 13±1.5° at 400 mm-Hg (15.75 in-Hg)			
Condenser capacity	0.24~0.30μF	0.24~0.30μF			
Firing order	1 - 2	1 - 2			
Ignition timing					
Leading	5° ATDC	5° ATDC			
Trailing	15° ATDC	15° ATDC			

Wear limit Clearance between shift rod gate and control lever	0.5 mm (0.020")	Drive plate run-out New	Less than 0.3 mm (0.012")	
Wear limit Synchronizer ring Clearance between synchronizer ring and side of gear when fitted	0.8 mm (0.031")	Limit Rear clutch Number of drive plates or driven plates	0.5 mm (0.020")	
New	1.5 mm (0.059")	Thickness of drive plate	5	
Wear limit	0.8 mm (0.031")	Total clearance measured between retaining plate and stopper	1.6 mm (0.063")	
Lubricant		Low and reverse brake Number of friction plates or steel plates	1.0 ~ 1.5 mm (0.039 ~ 0.059")	
Above -18°C (0°F)	EP. SAE 90	Thickness of friction plate	4	
Below -18°C (0°F)	EP. SAE 80	Total clearance measured between retaining plate and stopper	2.0 mm (0.079")	
Oil capacity	1.7 liters (1.8 U.S. quarts)	Gear assembly Total end play	0.8 ~ 1.05 mm (0.031 ~ 0.041")	
AUTOMATIC TRANSMISSION				
Model	JATCO R3A	Planetary gear side play New	0.25 ~ 0.50 mm (0.010 ~ 0.020")	
Gear ratio		Limit	0.2 ~ 0.7 mm (0.008 ~ 0.028")	
Low	2.458	Engine stall speed In break-in period	0.8 mm (0.031")	
Second	1.458	After break-in period	2400 ~ 2650 rpm	
Top	1.000	Shift speed (1) Throttle condition (Manifold vacuum)	2450 ~ 2700 rpm	
Reverse	2.181			
Torque converter Type	Symmetrical 3-element 1 - stage 2 - phase torque converter coupling	Kickdown 0~100mm-Hg (0~3.94 in-Hg)	D1 → D2 D2 → D3 D3 → D2 D2 → D1	30~44 mph 55~74 mph 48~62 mph 21~31 mph
Stall torque ratio	2.0 : 1	Half throttle 200 mm-Hg (7.87 in-Hg)	D1 → D2 D2 → D3	7~17 mph 17 ~37 mph
Fluid type	M2C33F (Type F)	Fully closed throttle	D3 → D1	6~11 mph
Fluid capacity	6.2 liters (6.6 U.S. quarts (5.5 Imp. quarts))	Manual 1	I2 → I1	25~32 mph
Oil pump Side play of inner gear and outer gear		Governor pressure		
New	0.02 ~ 0.04 mm (0.001 ~ 0.002")	Driving speed	Output shaft speed	Governor pressure
Limit	0.08 mm (0.003")	mph	rpm	kg/cm ² lb/in ²
Clearance between outer gear and crest		20	1150 ~ 1240	0.9 ~ 1.4 13 ~ 20
New	0.14 ~ 0.21 mm (0.006 ~ 0.008")	35	2030 ~ 2150	1.7 ~ 2.4 24 ~ 34
Limit	0.25 mm (0.010")	55	3190 ~ 3350	3.5 ~ 4.5 50 ~ 64
Clearance between outer gear and housing		Line pressure		
New	0.05 ~ 0.20 mm (0.002 ~ 0.008")		Engine idling condition	Engine stall condition
Limit	0.25 mm (0.010")			
Side clearance between oil seal ring and groove on oil pump cover	0.04 ~ 0.16 mm (0.002 ~ 0.006")	R	4.0~7.0 kg/cm ² (57 ~ 100 lb/in ²)	15.5 ~ 19.0 kg/cm ² (220 ~ 270 lb/in ²)
Front clutch Number of drive plates or driven plates	4	D	3.0 ~ 4.0 kg/cm ² (43 ~ 57 lb/in ²)	9.5 ~ 11.0 kg/cm ² (135 ~ 156 lb/in ²)
Thickness of drive plate	1.60 mm (0.063")	2	8.0 ~ 12.0 kg/cm ² (114 ~ 170 lb/in ²)	10.0 ~ 12.0 kg/cm ² (142 ~ 171 lb/in ²)
Total clearance measured between retaining plate and stopper	1.0 ~ 1.5 mm (0.039 ~ 0.059")	1	3.0 ~ 4.0 kg/cm ² (43 ~ 57 lb/in ²)	9.5 ~ 11.0 kg/cm ² (135 ~ 156 lb/in ²)
End play of front clutch drum	0.5 ~ 0.8 mm (0.020 ~ 0.031")			
Governor Type	38 type			

Max. permissible diameter	261 mm (10.2758")	DIMENSIONS	
Thickness of lining		Overall length	4402 mm (173")
New	5.5 mm (0.217")	Overall width	1695 mm (67")
Limit	1.0 mm (0.039")	Overall height	1540 mm (61")
Rear wheel cylinder		Wheelbase	2650 mm (104")
Bore	19.05 mm (3/4")	Tread	
Clearance between piston and bore		Front	1450 mm (57")
New	0.040 ~ 0.125 mm (0.0016 ~ 0.0049")	Rear	1430 mm (56")
Wear limit	0.15 mm (0.006")	Min. road clearance	195 mm (8")
Parking brake		Min. turning radius	5.0 m (16'5")
Type	Mechanical	Seating capacity	2
Operates at	Rear wheels	TIGHTENING TORQUE	
WHEELS AND TIRES			m-kg
			ft-lb
Wheel disc		Engine	
Front	5½J x 14 WDC	Oil pump sprocket	3.0 ~ 3.5 22 ~ 25
Rear	5½J x 14 WDC	Oil pan	0.7 ~ 1.0 5 ~ 7
Tire		Eccentric shaft pulley	7.5 ~ 9.5 54 ~ 69
Front	7.35-14-6PR	Inlet manifold	1.6 ~ 2.3 12 ~ 17
Rear	7.35-14-6PR	Exhaust manifold	4.4 ~ 5.9 32 ~ 43
Inflation pressure		Spark plugs	1.3 ~ 1.8 9 ~ 13
Front	24 psi	Oil filter cartridge	0.7 ~ 1.0 5 ~ 7
Rear	36 psi	Oil pressure switch	1.2 ~ 1.8 9 ~ 13
FRONT SUSPENSION		Temperature gauge unit	0.7 ~ 0.8 5 ~ 6
Type	Wishbone, coil spring	Tension bolts	3.2 ~ 3.8 23 ~ 27
Coil spring		Clutch	
Spring constant	9.13 kg/mm (511 lb/in)	Flywheel	40.0 ~ 50.5 289 ~ 362
Wire diameter	16.5 mm (0.65")	Clutch cover	1.8 ~ 2.7 13 ~ 20
Coil diameter	100.5 mm (3.96")	Transmission	
Free length	298 mm (11.73")	Shift lock spring cap	4.5 ~ 5.5 33 ~ 40
Fitting length	218 mm (8.58")	Plug for interlock pin hole	1.0 ~ 1.5 7 ~ 11
Fitting load	694 ~ 766 kg (1530 ~ 1689 lb)	Reverse lock spring cap	4.5 ~ 5.5 33 ~ 40
Note :		Control lever to control rod	1.8 ~ 2.7 13 ~ 20
When replacing the coil spring, install an adjusting plate/plates to get equal road clearance both on the right and left. But, do not use more than two plates at one side.		Shift fork set bolts	0.8 ~ 1.2 6 ~ 9
		Main shaft lock nut	20.0 ~ 28.0 145 ~ 203
		Under cover	0.6 ~ 0.9 4 ~ 7
		Reverse lamp switch	2.8 ~ 4.5 20 ~ 33
		Automatic transmission	
		Drive plate to crankshaft	14.0 ~ 16.0 101 ~ 116
		Drive plate to torque converter	4.0 ~ 5.0 29 ~ 36
		Converter housing to engine	4.0 ~ 5.0 29 ~ 36
		Converter housing to transmission case	4.5 ~ 5.5 33 ~ 40
		Extension housing to transmission case	2.0 ~ 2.5 14 ~ 18
		Pil pan	0.5 ~ 2.7 3.6 ~ 5.1
		Piston stem (When adjusting band brake)	1.2 ~ 1.5 9 ~ 11
		Stem lock nut	3.0 ~ 4.0 22 ~ 29
		Servo piston retainer	0.5 ~ 0.7 3.6 ~ 5.1
		One-way clutch inner race	1.3 ~ 1.8 9 ~ 13
		Control valve body	0.55 ~ 0.75 4.0 ~ 5.4
		Lower valve body to upper valve body	0.25 ~ 0.35 1.8 ~ 2.5
REAR SUSPENSION			
Type	Leaf spring		
Leaf spring			
Spring constant	5.54 kg/mm (310 lb/in)		
Number of leaves	6		
Length	1200 mm (47.24")		
Width	60 mm (2.36")		
Thickness	No. 1, 2, 3, & 4 :		
	6 mm (0.24")		
	No. 5 :		
	5 mm (0.20")		
	Helper : 12 mm (0.47")		

PROPELLER SHAFT		shaft and column bush With sector shaft and column bush Clearance between sector shaft and housing (or bush) New Wear limit End clearance of adjusting screw and sector shaft Lubricant End play of ball stud of center link and tie rods New Limit Max. wheel angle on full lock		(0.9 ~ 3.5 in-lb) 7 ~ 9 cm-kg (6.1 ~ 7.8 in-lb) 0.007 ~ 0.049 mm (0.0003 ~ 0.0019") 0.20 mm (0.008") 0 ~ 0.1 mm (0 ~ 0.004") EP. SAE 90 0 ~ 0.25 mm (0 ~ 0.010") 1.0 mm (0.039") 33°18' 32°36' 5.5 m (18"1')Steering geometry King pin inclination Camber Max. permissible difference in camber between sides Camber offset Caster Max. permissible difference in caster between sides Caster trail Toe-in	
Max. permissible run-out Max. permissible unbalance at 4000 rpm At front At center At rear Universal joint Spider diameter Wear limit	0.4 mm (0.016") 15 cm-gr (0.21 in-oz) 30 cm-gr (0.42 in-oz) 30 cm-gr (0.42 in-oz) 16.549 mm (0.6515")	Wheels and Axles	33°18'	32°36'	5.5 m (18"1')
REAR AXLE		BRAKES		FRONT SUSPENSION	
Type Reduction ratio Number of gear teeth Backlash of ring gear and pinion Max allowable variation of backlash Pinion bearing preload (Without pinion oil seal) Differential side bearing preload (Without pinion) Note: The above preload on the differential side bearings is obtained by tightening the adjusters until the distance between both pilot sections on the bearing caps ("L" shown in figure) becomes as follows: "L" (Case spread)	Semi-floating, hypoid gears 4.625 37 : 8 0.19 ~ 0.21 mm (0.0075 ~ 0.0083") 0.08mm (0.0031") 13 ~ 18 cm-kg (11.3 ~ 15.6 in-lb) 5 ~ 15 cm-kg (4.3 ~ 13.0 in-lb) 204.5 ⁺⁰ -0.072 mm (8.0513 ⁺⁰ -0.0028")	Brake pedal free travel Before push rod contacts with piston Before power brake piston operates Master cylinder Type Bore Clearance between piston and bore New Wear limit Front disk brake Brake disk outer diameter Thickness of brake disk New Limit Max. allowable lateral run-out of brake disk Thickness of lining and shoe New Wear limit Wheel cylinder bore Rear drum brake Type Drum diameter New	8.5 ~ 10 mm (0.33 ~ 0.39") Tandem 22.22 mm (7/8") 0.040 ~ 0.125 mm (0.0016 ~ 0.0049") 0.15 mm (0.006") 256 mm (10.079") 12 mm (0.4724") 11 mm (0.4331") 0.10 mm (0.0039") 14 mm (0.551") 7 mm (0.276") 53.97 mm (2.1248") Dual-acting two-leading shoes 260 mm (10.2364")	20°57' ± 20' 20'	5.0 mm (0.20") 0 ~ 6 mm (0 ~ 0.24")
Backlash of side gear and pinion gear Clearance between rear axle shaft and thrust block (Rear axle shaft end play) First installed Second installed Rear wheel bearing end play Lubricant Above -18°C (0°F) Below -18°C (0°F) Oil capacity	0 ~ 0.2 mm (0 ~ 0.008") 0.65 ~ 0.85 mm (0.026 ~ 0.033") 0.05 ~ 0.15 mm (0.002 ~ 0.006") HP. SAE 90 HP. SAE 80 1.3 liters (1.4 U.S. quarts)				
STEERING					
Type Reduction ratio Free play of steering wheel (Turning direction) New Limit Backlash between rack and sector gear Worm bearing preload Without sector	Recirculating ball nut 20.2 : 1 20 ~ 30 mm (0.8 ~ 1.2") 50 mm (2.0") 0 ~ 0.1 mm (0. ~ 0.004") 1 ~ 4 cm-kg				

Side plate to control valve body	0.25 ~ 0.35	1.8 ~ 2.5	Idler arm to bracket	4.5 ~ 6.5	33 ~ 47
Reamer bolt of control valve body	0.5 ~ 0.7	3.6 ~ 5.1	Idler arm to center link	4.5 ~ 6.5	33 ~ 47
Oil strainer	0.25 ~ 0.35	1.8 ~ 2.5	Pitman arm to center link	4.5 ~ 6.5	33 ~ 47
Governor valve body to oil distributor	0.5 ~ 0.7	3.6 ~ 5.1	Tire rod to center link	2.5 ~ 3.5	18 ~ 25
Oil pump cover	0.6 ~ 0.8	4.3 ~ 5.8	Tie rod to knuckle arm	4.5 ~ 6.5	33 ~ 47
Inhibitor switch	0.5 ~ 0.7	3.6 ~ 5.1	Tie rod lock nut	1.8 ~ 2.5	13 ~ 18
Manual shaft lock nut	3.0 ~ 4.0	22 ~ 29	Wheels		
Oil cooler pipe set bolt	2.4 ~ 3.6	17 ~ 26	Wheel nuts	8.0 ~ 9.0	58 ~ 65
Oil pressure test plug	0.5 ~ 1.0	3.6 ~ 7.2	Suspension		
Actuator for parking rod to extension housing	0.8 ~ 1.1	5.8 ~ 8.0	Ball joints to knuckle	7.0 ~ 9.0	51 ~ 65
Note : When adjusting the band brake, tighten the piston stem to a torque of 1.2 ~ 1.5 m-kg (9 ~ 11 ft-lb), and then loosen it by two turns.			Ball joint to lower suspension arm	8.3 ~ 9.7	60 ~ 70
Propeller shaft			Upper suspension arm shaft to frame	8.5 ~ 10.5	61 ~ 76
Yoke to rear axle companion flange	5.5 ~ 6.5	40 ~ 47	Lower suspension arm shaft to frame	8.5 ~ 10.5	61 ~ 76
Yoke to front propeller shaft	16.0 ~ 18.0	116 ~ 130	"U" bolts	6.4 ~ 8.0	46 ~ 58
Center bearing support	2.0 ~ 2.9	14 ~ 21	Spring pin nuts	8.5 ~ 10.5	61 ~ 76
Rear axle			Spring pin to frame bracket	2.0 ~ 2.5	14 ~ 18
Ring gear	5.5 ~ 6.5	40 ~ 47	Shackle pin nuts	6.0 ~ 8.0	46 ~ 58
Differential side bearing caps	6.5 ~ 7.7	47 ~ 56	Unless otherwise specified		
Companion flange to pinion	20.0 ~ 35.0	145 ~ 253		6T	8T
Steering				m-kg	ft-lb
Steering wheel nut	3.0 ~ 4.0	22 ~ 29	6mm bolt/nut	0.7 ~ 1.0	5 ~ 7
Steering gear housing to frame	4.5 ~ 5.7	33 ~ 41	8mm bolt/nut	1.6 ~ 2.3	12 ~ 17
Pitman arm to sector shaft	15.0 ~ 18.0	108 ~ 130	10mm bolt/nut	3.2 ~ 4.7	23 ~ 34
Idler arm bracket to frame	4.5 ~ 5.7	33 ~ 41	12mm bolt/nut	5.6 ~ 8.2	41 ~ 59
			14mm bolt/nut	7.7 ~ 10.5	56 ~ 76
					10.4 ~ 14.0
					6 ~ 9
					13 ~ 20
					27 ~ 40
					46 ~ 69
					75 ~ 101

JC 020 B 02	1	60335 4
LOCATION	QUANTITY	DLR
9599 95 0128	74	47041
PART NUMBER		INVOICE