



INDEX

| COMPONENT | LOCATION |
|----------------------------------|----------------|
| AIR CUT VALVE | I - 17 |
| ALTERNATOR | I - 3 |
| ALTERNATOR WARNING LIGHT | I - 6 |
| ANTI-AFTERBURN VALVE(A.V.) | I - 21 |
| AMMETER | C - 2 |
| BACK LIGHT | T - 22 |
| BACK LIGHT SWITCH | O - 22 |
| BRAKE WARNING LIGHT | E - 15 |
| CARBURETOR HEATER | I - 28 |
| CENTRAL CONTROL UNIT | T - 12 |
| CHOKE SWITCH | G - 28 |
| CIGAR LIGHTER | R - 20 |
| COASTING VALVE (CST) | K - 23 |
| COMBINATION SWITCH | O - 16 |
| CONDENSER | E - 3, K - 11 |
| COOLER RELAY | C - 19 |
| COOLER UNIT | C - 18 |
| DIMMER SWITCH | P - 5 |
| DISTRIBUTOR | I - 13, I - 14 |
| DOOR SWITCH | T - 2 |
| EMISSION CONTROL BOX | E - 19 |
| EXTERNAL RESISTOR | E - 12, E - 13 |
| FAIL INDICATOR SWITCH | I - 16 |
| FUEL METER (FUEL) | G - 23 |
| FUEL PUMP | I - 16 |
| FUEL TANK GAUGE UNIT | I - 23 |
| HAND BRAKE SWITCH | I - 15 |
| HEAD LIGHT | T - 3 |
| HEATER FAN SWITCH | O - 29 |
| HEATER ILLUMINATION LIGHT | O - 9 |
| HEATER MOTOR | Q - 29 |
| HEAT HAZARD SENSOR | E - 25 |
| HEAT HAZARD WARNING LIGHT | I - 26 |
| HIGH BEAM INDICATOR LIGHT | T - 4 |
| HORN | T - 21 |
| HORN RELAY | O - 21 |
| HORN SWITCH | R - 21 |
| IDLE SWITCH | J - 20 |
| IGNITION COIL | F - 12, F - 13 |
| IGNITION RELAY | F - 11 |
| IGNITION SWITCH | C - 4 |
| INHIBITOR SWITCH | G - 7 |
| KICK DOWN SOLENOID | I - 27 |
| KICK DOWN SWITCH | E - 27 |
| LICENCE LIGHT | T - 7 |
| LIGHT SWITCH | O - 3 |
| METER ILLUMINATION LIGHT | O - 6 |
| OIL PRESSURE SWITCH | I - 22 |
| OIL PRESSURE WARNING LIGHT (OIL) | G - 22 |
| PANEL LIGHT RESISTOR | T - 10 |
| PASSING HIGH BEAM SWITCH | P - 4 |
| RADIO | H - 9 |
| REGULATOR | I - 5 |
| ROOM LIGHT | P - 2 |
| SCREEN WASHER MOTOR | Q - 26 |
| SELECT INDICATOR LIGHT | O - 9 |
| SIDE LIGHT | T - 5 |
| SIDE MARKER LIGHT | T - 6 |
| SPEAKER | I - 9 |
| STARTER | I - 8 |
| STOP LIGHT SWITCH | O - 19 |
| SUB ZERO MOTOR | G - 8 |
| SUB ZERO SWITCH | I - 8 |
| TACHOMETER | G - 14 |
| TAIL LIGHT | T - 7 |
| THERMOCOUPLER | H - 19 |
| THERMOSENSOR | H - 18 |
| THREE POINT RELAY | G - 26 |
| TURN SIGNAL INDICATOR LIGHT | T - 16 |
| TURN SIGNAL LIGHT | T - 16 |
| TURN SIGNAL RELAY | R - 16 |
| TURN SIGNAL & STOP LIGHT | T - 15 |
| WASHER MOTOR | Q - 26 |
| WATER THERMO METER (TEMP) | G - 24 |
| WATER THERMO SWITCH | I - 28 |
| WATER THERMO UNIT | I - 24 |
| WIPER MOTOR | Q - 24 |
| WIPER RELAY | S - 25 |
| WIPER & WASHER SWITCH | T - 28 |

NOTE:
 ○ Dotted lines show the wiring for Automatic Transmission Model.

| WIRING CODE | |
|-------------|-------------|
| CODE | COLOR |
| W | WHITE |
| Y | YELLOW |
| L | BLUE |
| R | RED |
| G | GREEN |
| B | BLACK |
| Br | BROWN |
| Lg | LIGHT GREEN |

EXAMPLE
 LR BLUE RED RL RED BLUE

1974 MAZDA ROTARY PICKUP WIRING DIAGRAM